



# CYCLES

by Rockford

## PARTS PRICE LIST



ALL MODELS

Bridgestone

Chibi

Chibi DeLuxe

Tora

Tora DeLuxe

Taka

M C B

Zundapp

EFFECTIVE JANUARY 1 1974

Contains all Rockford interchangeable and replacement part numbers

**ROCKFORD MOTORS, INC.**

1911 Harrison Ave. Rockford, Ill. 61103

## INTRODUCTION

This Parts Price List covers:

All Bridgestone Models	Page 1 thru 34
Rockford, Chibi, Chibi Deluxe, Tora, Tora Deluxe and Taka	Page 35 thru 40
MCB by Rockford	Page 41 thru 44
Zundapp	Page 45 thru 49
NGK Spark Plugs	Page 50
Literature	Page 51
Accessories	Page 52

This price list cancels "Cycles by Rockford" parts price list dated July 1, 1972. The July 1, 1972, price list and all previous lists should be destroyed.

When using this list, please note:

1. All prices shown are suggested list prices.
2. Parts listings, within each group shown above, are in order by part number.
3. This list includes specification changes and corrections to date of issue. Cross reference to new part numbers are shown in the parts description as a "use" number, the list price shown is for that "use" number.
4. Some part numbers are listed several times for color distinction. The color code is as follows:

BLE=BS7 blue	FAB=blue	MS=metallic silver
CBK=black	FAR=candy apple red	OMB=candy apple blue
CCG=charcoal grey	FBG=gold	OUR=BS7 red
CFG=grey	FDG=green	PSW=pearl white
CHG=HMS green	FO=orange	XCI=chrome plated
CUR=60 Sport	FOG=gold	

The part numbers in this price list are divided into sections by manufacturer. Each manufacturer uses different sets and series of numbers. Some part numbers may contain the same number of digits but are divided differently. Example: An eight digit number divided 4-4 will be found in the Bridgestone section; an eight digit number divided 3-2-3 will be found in the Zundapp section. To locate the section in which a part number will be found, identify the number below and turn to the section indicated.

E-12345  
M-12345  
EA1-12345  
GA1-12345  
GB1-12345

Bridgestone Part Number Cross Reference  
To Current Bridgestone Part Numbers.

Page 1 to 13

$\frac{4}{1234} - \frac{4}{5678}$

$\frac{5}{12345} - \frac{3}{678}$

$\frac{2}{12} - \frac{4}{3456} - \frac{2}{78}$

Current Bridgestone Part Numbers

All  
Bridgestone  
models

Page 14 to 34

$\frac{3}{123} - \frac{5}{45678} - \frac{3}{910}$

$\frac{4}{1234} - \frac{4}{5678}$

$\frac{5}{12345} - \frac{3}{678}$

$\frac{2}{12} - \frac{4}{3456} - \frac{2}{78}$

Rockford Model Part Numbers

Page 35 to 40

Rockford Model Part Numbers  
Interchangeable with current  
Bridgestone Part Numbers

Chibi  
Chibi Deluxe  
Tora  
Tora Deluxe  
Taka

Page 14 to 34

$\frac{4}{1234} - \frac{3}{567} - \frac{3}{890}$

$\frac{5}{12345}$

$\frac{5}{12345} - \frac{1}{1}$

$\frac{5}{12345} - \frac{2}{67}$

MCB by Rockford

MCB

Page 41 to 44

DIN  $\frac{2}{12} - \frac{3}{345}$

DIN  $\frac{3}{123} - \frac{3}{456}$

$\frac{3}{123} - \frac{2}{45} - \frac{3}{678}$

Zundapp

Page 45 to 49

Zundapp  
Motocross  
and  
Enduro

# BRIDGESTONE BY ROCKFORD

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
E 02115	1 USE 2141 3001 STOP	.50	E 05311	4 USE 2461 3004 GEAR	6.18
E 02163	USE 09090 103 SEAL	.82	E 05312	2 USE 2456 3002 GEAR	4.30
E 02201	2 USE 2130 3000 CASE	18.02	E 05313	2 USE 2451 3002 GEAR	4.30
E 02311	2 USE 2161 3002 COVER	11.80	E 05314	5 USE 2446 3005 SHAFT	5.20
E 02411	3 USE 2151 3003 CASE	7.12	E 05315	0 USE 09006 101 RING	.26
E 02412	1 USE 2153 3001 COVER	.58	E 05316	3 USE 2483 3003 SPACR	.66
E 02502	1 USE 2164 3001 GAGE	1.32	E 05317	1 USE 2484 3001 SPRKT	4.90
E 02512	1 USE 2138 3001 CASE	2.16	E 05319	2 USE 2481 3002 SPACR	.66
E 02513	2 USE 2145 3002 HOLD	.36	E 05321	USE 2484 3010 SPRKT	3.56
E 02514	USE 2129 3000 CLAMP	.08	E 05322	1 USE 2452 3001 BUSH	1.76
E 02515	USE 09058 101 PLUG	.50	E 05323	USE 2487 3000 WASH	.36
E 02516	USE 09057 101 PIN	.18	E 05324	USE 2486 3000 RING	1.76
E 02517	1 USE 2125 3001 COVER	1.16	E 05326	USE 09047 101 WASH	.26
E 02518	1 USE 2119 3001 COVER	2.66	E 05327	USE 09021 101 NUT	.26
E 02519	3 USE 2126 3003 HOLDER	.50	E 05411	USE 07 6302 03 BEAR	3.40
E 02611	USE 09090 105 SEAL	.92	E 06102	2 USE 2554 3002 PLATE	1.82
E 02612	USE 09090 104 SEAL	.92	E 06103	USE 2530 3000 STOP	1.16
E 02613	USE 09090 103 SEAL	.82	E 06104	1 USE 2555 3002 STOP	1.82
E 02614	USE 09090 101 SEAL	.86	E 06111	1 USE 2511 3001 SHAFT	3.78
E 02615	USE 09066 101 RING	.42	E 06113	1 USE 2551 3001 SPRNG	.58
E 02621	1 USE 2181 3001 PACK	.26	E 06113	2 USE 2551 3002 SPRNG	.50
E 02622	1 USE 2183 3001 GASKET	.18	E 06114	2 USE 2552 3002 WASH	.26
E 02623	USE 2187 3100 GASKET	.08	E 06115	USE 09041 102 WASH	.08
E 02624	USE 2188 3000 GASKET	.18	E 06116	1 USE 09002 101 RING	.42
E 02631	USE 09064 101 GASKET	.08	E 06117	USE 09004 101 RING	.18
E 02632	USE 09064 102 GASKET	.08	E 06133	1 USE 2538 3001 SPRNG	.26
E 03101	1 USE 1301 3001 SHAFT	28.90	E 06201	2 USE 2510 3002 ARM	4.46
E 03122	1 USE 1334 3001 BUSH	.92	E 06221	1 USE 2517 3001 SPRNG	.18
E 03123	NUT AVAILABLE	.00	E 06301	1 USE 2520 3001 DRUM	7.12
E 03124	NUT AVAILABLE	.00	E 06313	3 USE 2549 3003 PLATE	1.16
E 03125	NUT AVAILABLE	.00	E 06314	1 USE 09041 104 WASH	.18
E 03126	USE 09049 101 SHIM	.18	E 06315	1 USE 0411-0613 WASH	.08
E 03127	USE 09049 102 SHIM	.18	E 06322	3 USE 2541 3003 FORK	6.40
E 03210	25 USE 1342 3001 PISTON	5.20	E 06323	1 USE 2544 3001 GUIDE	.66
E 03210	50 USE 1343 3001 PISTON	5.20	E 06324	USE 09047 102 WASH	.08
E 03210	3 USE 1341 3003 PISTON	5.20	E 07101	2 USE 2620 3000 SHAFT	3.78
E 03211	3 USE 1341 3003 PISTON	5.20	E 07121	1 USE 2631 3001 GEAR	4.00
E 03212	USE 1305 3000 RINGS	3.40	E 07122	4 USE 2632 3004 ARM	4.00
E 03213	0 USE 1305 3000 RINGS	3.40	E 07123	1 USE 2633 3001 RATCH	1.58
E 03214	USE 1381 3000 PIN	1.08	E 07124	USE 2634 3000 SPRNG	.36
E 03215	USE 1382 3000 CLIP	.06	E 07125	USE 2635 3000 STOP	.26
E 03221	USE 1342 3001 PISTON	5.20	E 07126	1 USE 09041 105 WASH	.08
E 03222	USE 1343 3001 PISTON	5.20	E 07128	USE 09006 104 RING	.26
E 03223	USE 1306 3000 RINGS	3.80	E 07211	USE 2636 3000 SPRNG	.92
E 03224	USE 1307 3000 RINGS	3.80	E 07212	1 USE 2637 3001 HOOK	1.58
E 03225	USE 1306 3000 RINGS	3.80	E 07213	USE 09041 106 WASH	.08
E 03226	USE 1307 3000 RINGS	3.80	E 07215	USE 09006 101 RING	.26
E 03241	USE 1305 3000 RINGS	3.40	E 07311	NOT USED	.00
E 03242	USE 1306 3000 RINGS	3.80	E 08100	5 USE 1600 3005 CARB	14.58
E 03243	USE 1307 3000 RINGS	3.80	E 08111	0 CARBURETOR BODY	6.80
E 03311	USE 07 6303 03 BEAR	3.96	E 08121	VALVE	3.30
E 03312	USE 07 6003 01 BEAR	3.40	E 08122	USE 1615 3102 JET	1.32
E 03313	USE 09041 101 WASHER	.18	E 08123	NOT AVAILABLE	.00
E 03314	USE 0671 3013 KEY	.18	E 08124	CIRCLIP	.18
E 03315	USE 1382 3000 CLIP	.08	E 08128	CABLE ADJUSTER	.38
E 04100	USE 2200 3000 CLUTH	20.52	E 08129	USE 1623 3020 NUT	.08
E 04102	3 USE 2220 3003 HUB	8.58	E 08144	IDLE JET	.90
E 04111	1 USE 2211 3001 PLATE	3.96	E 08145	MAIN JET	3.30
E 04112	2 USE 2214 3002 PLATE	2.72	E 08146	U RING	.42
E 04113	1 USE 2215 3001 PLATE	.66	E 08153	LEVER	2.40
E 04114	1 USE 2216 3001 PLATE	.92	E 08161	FLOAT NEEDLE	.90
E 04115	1 USE 2218 3001 SPRNG	.36	E 08162	STARTER JET	2.88
E 04116	USE 2224 3000 RING	1.08	E 08163	NUT AVAILABLE	.00
E 04117	USE 2225 3000 RING	.66	E 08164	FLOAT	2.22
E 04201	3 USE 2260 3003 ARM	3.96	E 08165	FLOAT PIN	.46
E 04311	1 USE 2265 3001 SCREW	1.48	E 08166	FLOAT CHAMBER	3.66
E 04313	USE 09045 101 WASHR	.08	E 08167	COVER	2.98
E 04314	USE 2269 3000 HANGR	.36	E 08168	NOT AVAILABLE	.00
E 04315	USE 2271 3000 SPRNG	.36	E 08171	NOT AVAILABLE	.00
E 04316	USE 2186 3000 GASKT	.08	E 08200	2 NOT AVAILABLE	.00
E 04411	USE 2231 3000 RACE	.82	E 08200	3 USE 6201 3003 CLEAN	5.28
E 04412	USE 0611 0516 BALL	.08	E 08201	NOT AVAILABLE	.00
E 04414	USE 09029 102 NUT	.18	E 08202	COVER	.76
E 04428	USE 2335-3100 HOLOR	.26	E 08203	USE 6201 3003 CLEAN	5.28
E 05111	USE 1385 3000 GEAR	3.72	E 08205	USE 6211 3000 ELEMNT	3.72
E 05112	2 USE 2411 3002 GEAR	13.86	E 08231	ELEMENT	2.68
E 05113	1 USE 2478 3001 BUSH	1.58	E 08231	3 NOT USED	.00
E 05114	2 USE 2479 3002 BOLT	.66	E 08240	AIR PIPE OLD STYL	1.26
E 05115	2 USE 0441 1221 WASHR	.08	E 08241	USE 6241 3010 PIPE	.66
E 05211	4 USE 2431 3004 GEAR	5.12	E 08245	FUEL PIPE	.18
E 05212	2 USE 2426 3002 GEAR	4.56	E 08301	1 USE 1820 3011 COVER	8.06
E 05213	1 USE 2421 3001 SHAFT	7.28	E 08304	BATTERY BAND	.52
E 05214	1 USE 2476 3001 SPACR	.50	E 08309	NOT AVAILABLE	.00
E 05215	1 USE 09006 101 RING	.26	E 08312	USE 1822 3000 CAP	1.48

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
E 08321	2 USE 1841 3002 COVER	3.40	E 28185	WASHER	.18
E 08325	USE 09504-101 RING	.08	E 28186	USE 1658 3010 SPRNG	1.26
E 08327	USE 1843 3000 SPACR	.08	E 28191	USE 1613 3020 SCREW	.36
E 08330	KNDB	.72	E 28241	USE 6241 3010 PIPE	.66
E 08351	USE 1823 3000 STAY	.50	E 28411	2 USE 2581 3012 PEDAL	3.72
E 08511	0 NUT AVAILABLE	.00	E 28500	USE 2680 3100 ARM	7.08
E 09100	USE 1702 3002 START	67.20	E 28511	USE 2681 3010 ARM	7.12
E 09101	USE 1725 3001 ROTDR	26.64	E 28512	1 USE 2690 3010 PEDAL	3.06
E 09102	USE 1720 3001 STATR	34.20	E 38175	NEEDLE VALVE	1.06
E 09103	USE 1722 3001 BRUSH	1.48	E 38176	VALVE ROD	.26
E 09104	USE 1752 3001 POINT	3.52	E 38177	NUT AVAILABLE	.00
E 09105	USE 1753 3001 CONU	2.30	M 2498	USE 8141 3010 RIM	9.30
E 09111	USE 0671 3010 KEY	.36	M 2499	USE 8102 3020 LAMP	14.46
E 09121	USE 1720 3001 STATR	34.20	M 2519	NUT AVAILABLE	.00
E 09122	USE 1751 3001 BASE	3.62	M 2525	HD LIGHT ASSY CHP	14.46
E 09123	USE 1723 3001 SPRNG	.50	M 3497	CLUTCH GRIP CHP	10.48
E 09124	USE 1754 3001 FELT	.50	M 3511	USE 8205 3011 LIGHT	13.66
E 09126	USE 1755 3001 GRUM	.36	M 3512	USE 8205 5011 LIGHT	13.66
E 09161	1 USE 1811 3003 FAN	10.30	M 3513	USE 8251 3020 LENS	4.08
E 09162	1 USE 1812 3002 CAP	.36	M 3514	USE 8240 5010 SOCKT	5.96
E 09171	USE 1726 3001 BOLT	1.16	M 3524	USE 8240 5010 SOCKT	5.96
E 09200	USE 8703 3001 REGUL	27.26	M 3526	USE 8102 3020 LAMP	14.46
E 09301	0 USE 8501 3000 COIL	11.56	M 4497	USE M3497 GRIP	8.38
E 09302	USE 8531 3000 WIRE	.92	M 4501	USE 8160 3010 SOCKT	4.52
E 09303	USE 8521 3000 CAP	.92	M 4502	USE 8171-5000 BULB	1.16
E 09305	USE 86 NGK PLUG	1.30	M 4507	USE 8203 3010 REFLT	2.66
E 09400	2 USE 1760 3002 SWTCH	1.16	M 4515	USE 8252 3031 BULB	.82
E 09402	USE 1785 3000 WIRE	.50	M 4516	USE 8252 3040 BULB	1.78
E 09412	2 USE 1762 5000 PLATE	.26	M 4517	USE 8253 3020 PACK	.18
E 12101	USE 2110 3010 CASE	23.06	M 4518	USE 8256 3010 GRUM	.08
E 13101	1 USE 1301 3011 CRANK	28.90	M 4527	USE 8171 3030 BULB	1.16
E 13212	USE 1334 3001 BUSH	.92	M 4544	USE 3702 3020 REST	1.48
E 18232	BAND	.46	M 01100	2 USE 3110 3002 CUR	62.04
E 18511	2 USE 2681 3010 ARM	7.12	M 01100	2 USE 3110 3002 CBK	62.04
E 18512	USE 2690 3010 PEDAL	3.06	M 01100	2 USE 3110 3002 BLE	62.04
E 18513	1 USE 2683 3011 RUBBR	.36	M 01811	USE 3315 3000 RACE	1.08
E 18514	USE 2684 5000 WASH	.26	M 01812	1 USE 3311 3200 RACE	1.76
E 18515	USE 0411 1022 WASH	.08	M 01813	1 USE 3312 3001 RACE	1.32
E 19100	4 USE 1701 3014 MAG	34.74	M 01814	USE 3314 3000 RACE	1.58
E 19111	2 USE 1718 3013 FLYWL	24.60	M 01815	USE 0611 0316 BALL	.08
E 19112	PLATE	1.12	M 01816	USE 3321 3000 NUT	.58
E 19113	NUT FLYWHEEL	.92	M 01817	USE 3323 3000 NUT	1.08
E 19114	USE 09041 108 WASH	.08	M 01818	1 USE 3322 3001 ADJTR	1.32
E 19115	USE 1811 3010 FAN	3.62	M 01819	WASHER	.18
E 19201	1 USE 1710 3011 PLATE	25.98	M 01821	1 USE 3372 3001 HANGR	.50
E 19203	0 USE 1752 5000 POINT	4.08	M 01822	1 USE 3371 3001 HANGR	.50
E 19211	0 USE 1712 3100 COIL	9.38	M 01823	1 USE 3368 3001 SPACR	.36
E 19221	USE 1714 3010 COIL	6.08	M 01824	TANK COLLAR	.32
E 19241	USE 1753 3010 CONU	1.86	M 01825	USE 3384 3000 HOLDR	.26
E 19245	USE 1754 3020 FELT	.36	M 01826	USE 4281 3000 CUR	1.66
E 19402	USE 1785 3010 WIRE	.26	M 01826	USE 4281 3000 CBK	1.66
E 19403	1 USE 8702 3001 RECTR	1.82	M 01827	3 USE 3334 3003 CUR	4.00
E 21311	USE 1131 3020 ADAPT	1.08	M 01827	3 USE 3334 3003 CBK	4.00
E 28100	USE 1600 3005 CARB	14.58	M 01827	3 USE 3334 3003 BLE	4.00
E 28105	2 USE 1640 3012 LEVER	1.98	M 01829	USE 3335 3000 STOP	.18
E 28107	USE 1660 3010 VALVE	6.18	M 01831	USE 3412 3000 GRUM	.08
E 28111	1 USE 1611 3021 BODY	7.06	M 01832	USE 3367 3000 RUBBR	.66
E 28121	USE 1614 3021 VALVE	2.66	M 01833	1 USE 3353 3001 BAND	.50
E 28122	1 USE 1615 3021 NEEDL	1.48	M 01836	3 USE 3414 3003 SHAFT	1.58
E 28123	1 USE 1616 3021 CLIP	.36	M 01837	4 USE 3415 3004 SHAFT	1.98
E 28124	USE 1617 3021 SEAT	.26	M 01838	1 USE 09525 101 NUT	.66
E 28125	USE 1618 3020 SPRNG	.58	M 01839	USE 09525 102 NUT	.50
E 28126	USE 1619 3020 TOP	.82	M 01841	1 USE 3354 3001 BAND	.36
E 28127	USE 1622 3020 ADJTR	.58	M 01844	USE 09541 101 WASH	.08
E 28128	USE 1623 3020 NUT	.08	M 01847	1 USE 09541 102 WASH	.18
E 28131	1 USE 1627 3021 SCREW	.66	M 01848	USE 0411 1022 WASH	.08
E 28132	USE 1628 3010 SPRNG	.36	M 01849	1 USE 3423 3001 WASH	.08
E 28134	USE 1631 3010 SCREW	1.32	M 01851	BUSHING	.26
E 28135	USE 1632 3010 SCREW	.26	M 01852	USE 3425 3000 GRUM	.18
E 28144	JET 90 NUT AVAILABL	.00	M 01854	USE 3411 3000 SPACR	.26
E 28144	NUT AVAILABLE	.00	M 01855	1 USE 3441 3001 CLAMP	.50
E 28144	75 JET 75 NUT AVAILABL	.00	M 01858	GROMMET	.26
E 28144	85 USE 1635 3010 85 JET	1.08	M 02201	USE 4230 3001 ARM	7.12
E 28144	0 USE 1635 3000 80 JET	1.08	M 02201	1 USE 4230 3001 ARM	7.12
E 28144	1 USE 1635 3010 65 JET	1.08	M 02202	1 USE 4220 3001 ARM	6.60
E 28145	USE 1633 3021 JET	1.90	M 02231	1 USE 4241 3001 RING	.92
E 28161	USE 1645 3010 PLUNG	1.90	M 02232	1 USE 4242 3001 RING	1.08
E 28162	USE 1646 3010 SPRNG	.36	M 02233	1 USE 4243 3001 RING	1.16
E 28163	USE 1647 3010 CAP	.92	M 02241	USE 4251 3000 BUSH	.82
E 28164	USE 1648 3010 CLIP	.36	M 02242	USE 4253 3000 CULLR	.26
E 28181	USE 1666 3020 FLDAT	2.40	M 02243	USE 4252 3000 COLLR	.36
E 28182	USE 1667 3020 PIN	.26	M 02244	3 USE 4254 3003 STOP	1.08
E 28183	1 USE 1656 3021 BODY	4.68	M 02245	0 USE 09064 102 GASKT	.08
E 28184	USE 1657 3020 GASK	.50	M 02246	USE 4255 3000 STOP	.36

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
M 02248	USE 4224 3000 NIPPL	.26	M 04156	SPACER	.46
M 02301 CBK	USE 4411 3000 CBK	10.90	M 04157	SPACER	.18
M 02301 CUR	USE 4411 3000 CUR	10.90	M 04159	NUT USED	.00
M 02331	USE 4431 3000 CLIP	.08	M 04171	NUT USED	.00
M 02332	USE 4286 3000 CAP	.18	M 04172 2	NOT AVAILABLE	.00
M 02406	NOT AVAILABLE	.00	M 04173 2	USE 7221 3002 AXLE	2.22
M 02409	STAY	1.36	M 04176	USE 0232 1200 NUT	.36
M 02431	MOUNTING RUBBER	.18	M 04177	USE 09524 101 NUT	.26
M 02432	WASHER	.18	M 04178	USE 0232 1200 NUT	.36
M 02433	WASHER	.18	M 04181	USE 7441 3000 RIM	11.36
M 02434	BUMPER	.18	M 04182	USE 7108 3000 EA	.16
M 02501 1	USE 8111 3004 CUR	8.20	M 04182 2	USE 7108 3000 SPKE	3.40
M 02501 1	USE 8111 3004 CBK	8.20	M 04190	NOT USED	.00
M 02501 1	NUT AVAILABLE	.00	M 04191	USE 225 X 17 FS TIRE	
M 02632	USE 8122 3006 ORNAM	.08	M 04192	USE 225 X 17 TUBE	
M 02633	USE 8121 3010 ORNAM	1.08	M 04193	USE 7253 3000 BAND	.42
M 03100 BLE	BLUE NOT AVAILABLE	.00	M 04199	USE 7101 3000 WHEEL	57.36
M 03100 CUR	USE 4810 3003 CUR	18.88	M 04200 3	USE 7302 3003 HUB	28.66
M 03100 CBK	USE 4810 3003 CBK	18.88	M 04201 2	USE 7311 3002 DRUM	17.16
M 03100 CHG	USE 4810 3003 CHG	18.88	M 04203 2	USE 7331 3002 PANEL	6.40
M 03100 CFG	USE 4810 3003 CFG	18.88	M 04210	OIL SEAL	.26
M 03117	SWITCH BUTTON	.68	M 04215 1	USE 7314 3001 COLLR	.32
M 03171 2	USE 4851 3002 BUSH	1.48	M 04217 1	USE 09590 103 SEAL	.42
M 03172 2	USE 4853 3001 PACK	1.16	M 04219	USE 0411 0613 WASH	.08
M 03174 1	USE 4852 3001 CAP	.18	M 04220	USE 7402 3000 WHEEL	57.36
M 03181 2	USE 4861 3002 ADJTR	.98	M 04247 3	USE 7351 3003 CAM	1.32
M 03200 BLE	USE 4901 3005 BLE	15.98	M 04248 1	USE 7152 3001 LEVER	.18
M 03200 CBK	USE 4901 3005 CBK	15.98	M 04249 2	USE 0111 0630 BOLT	.16
M 03200 CUR	USE 4901 3005 CUR	15.98	M 04251 4	USE 7353 3004 LEVER	1.40
M 03200 CFG	USE 4901 3005 CFG	15.98	M 04252 3	USE 7361 3003 PIN	.26
M 03200 CHG	USE 4901 3005 CHG	15.98	M 04254	USE 7366 3000 LINK	.66
M 03211	USE 4901 3005 CUR	15.98	M 04259 1	USE 7367 3001 BOLT	.36
M 03212 0	RUBBER BUSH COLLA	.42	M 04261	USE 7381 3000 SPRKT	5.20
M 03214	USE 4901 3005 BLK	15.98	M 04262	USE 09511 105 BOLT	.26
M 03214 0	OUTER COVER GREEN	1.48	M 04271 1	USE 7427 3001 COLLR	.66
M 03214 0	USE 4901 3005 RED	15.98	M 04272 1	USE 7426 3001 COLLR	.26
M 03215 0	SPRING	2.80	M 04273 2	USE 290 34501 200	4.02
M 03222 0	LOWER BRACKET	1.26	M 04281	USE 7441 3000 RIM	11.36
M 03227 0	RUBBER BUSH	.26	M 04282	USE 7308 3000 EA	.16
M 03244 0	LOWER CASE CUMP	2.08	M 04282 2	USE 7308 3000 SPUKE	3.80
M 03300	USE 4701 3001 BLE	9.78	M 04291	USE 225 X 17 SS TIR	
M 03300	USE 4701 3100 CHG	9.78	M 04299	USE 7402 3000 WHEEL	57.36
M 03300 1	USE 4701 3001 CUR	8.38	M 04301 5	USE 3810 3005 XCI	3.96
M 03300 1	USE 4701 3001 CBK	8.38	M 04305	USE 7501 3000 CHAIN	7.78
M 03301 CBK	USE 4711 3000 CBK	6.02	M 04313	NOT AVAILABLE	.00
M 03301 CUR	USE 4711 3000 CUR	6.02	M 04321 1	USE 3821 3001 SPRNG	.18
M 03301 CHG	USE 4711 3000 CHG	6.32	M 04331 1	USE 3831 3001 ROD	1.08
M 03304 BLE	NUT AVAILABLE	.00	M 04332 0	USE 3832 3000 NUT	.26
M 03304 CBK	USE 4721 3000 CBK	6.32	M 04333	USE 3833 3000 SPRNG	.18
M 03304 CUR	USE 4721 3000 CUR	6.32	M 04357	USE 7520 3000 LINK	.68
M 03304 CHG	USE 4721 3000 CHG	6.32	M 04464	USE 8121 3020 ORNAM	1.08
M 03361	USE 4731 3000 CAP	.18	M 05100	THRITTLE GRIP	10.90
M 03362	USE 09511 126 BOLT	.08	M 05102	GRIP PIPE	3.46
M 04100 3	USE 7102 3003 HUB	31.36	M 05103	COVER	4.00
M 04101 3	USE 7111 3004 DRUM	24.96	M 05106 1	USE 6176 3001 CABLE	.82
M 04101 4	USE 7111 3004 DRUM	24.96	M 05108	USE 6181 3000 CABLE	1.98
M 04103 4	USE 7131 3005 PANEL	11.82	M 05111	HOLDER	3.46
M 04103 5	USE 7131 3005 PANEL	11.82	M 05112	LEVER	2.40
M 04104 3	USE 7105 3003 SHOE	6.02	M 05113	CABLE ADJUSTER	.26
M 04107	WASHER	.18	M 05114	NUT	.18
M 04115 2	USE 7114 3002 COLLR	.36	M 05115	USE 6124 3100 COLLR	.36
M 04116 1	USE 07 6201 03 BEAR	3.06	M 05116	WIRE	1.36
M 04117	USE 09590 102 SEAL	1.00	M 05117	SWITCH BUTTON	.26
M 04118	USE 09590 101 SEAL	.42	M 05118	SPRING	.26
M 04118 3	USE 09590 101 SEAL	.42	M 05119	WIRE HOLDER	.26
M 04119	USE 7115 3000 SPACR	.08	M 05121	PIPE	2.38
M 04120	USE 7100 3000 WHEEL	57.36	M 05122	GRIP RUBBER	1.36
M 04121	USE 7116 3000 GEAR	3.62	M 05123	WIRE END	.38
M 04122	USE 09590 102 SEAL	1.00	M 05137	BUTTON	.26
M 04124	USE 07 6201 03 BEAR	3.06	M 05141	SCREW	.26
M 04125	USE 7118 3000 COLLR	.58	M 05200	CLUTCH GRIP	9.30
M 04126	NUT AVAILABLE	.00	M 05203	COVER	2.86
M 04127	USE 7121 3000 SEAL	.66	M 05206 1	USE 6186 3001 CABLE	2.58
M 04133	BUSHING	1.66	M 05207 1	USE 9421 3001 CABLE	1.08
M 04137 A1	USE 7134 3002 NIPPL	.30	M 05208	USE 9422 3001 CABLE	1.66
M 04138 A1	USE 7134 3002 NIPPL	.30	M 05211	HOLDER	1.80
M 04141 3	USE 7105 3003 SHOE	6.02	M 05212	LEVER L H	2.40
M 04145 1	USE 7145 3001 SPRNG	.26	M 05217	CONTACT	.26
M 04147 1	USE 7151 3003 CAM	2.22	M 05218	SPRING	.26
M 04147 3	USE 7151 3003 CAM	2.22	M 05222	GRIP RUBBER	1.36
M 04148	USE 7152 3001 PACK	.18	M 05234	CLAMP	.18
M 04149	USE 0111 0630 BOLT	.16	M 05267	NUT AVAILABLE	.00
M 04151 4	USE 7153 3004 LEVER	2.90	M 05291 1	USE 9423 3000 LINK	.50
M 04155 1	NUT USED	.00	M 05292	USE 9424 3000 HOOK	.18

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
M 05293	USE 9425 3000 CLIP	.08	M 08100	USE 6460 3012 SEAT	30.52
M 05300 0	USE 8401 3004 METER	16.78	M 08153	NOT AVAILABLE	.00
M 05304 3	USE 7261 3003 GEAR	9.96	M 08154	NOT USED	.00
M 05307	USE 6171 3001 CABLE	2.66	M 08155	NOT USED	.00
M 05312	USE 8421 3002 SOCKT	.46	M 08201	NOT AVAILABLE	.00
M 05313	USE 8422 3002 SOCKT	.52	M 08202	USE 6460 3012 SEAT	30.52
M 05314	USE 8423 3002 SOCKT	.52	M 08300 1	GN USE 3610 3100 CHG	6.18
M 05315 0	USE 8424 3000 BULB	.50	M 08300 1	GY USE 3610 3100 CFG	6.18
M 05318	USE 8427 3000 GASKT	.08	M 08300 CBK	USE 3610 3001 CBK	5.66
M 05357	PACKING	.38	M 08300 CUR	USE 3610 3001 CUR	5.66
M 05371	USE 9412 3000 TUBE	1.58	M 08304	USE E08304 BAND	.42
M 05372	USE 9411 3000 CABLE	1.08	M 08319 2	USE 3621 3002 SHAFT	.66
M 06100 2	USE 8102 3004 LAMP	7.98	M 08331	USE 3624 3000 SPRNG	.66
M 06102 2	USE 8160 3004 SOCKT	1.40	M 08332	USE 09541 103 WASH	.18
M 06111 1	USE 8141 3002 RIM	4.00	M 08400 CBK	NOT AVAILABLE	.00
M 06112 1	USE 8150 3002 LENS	5.20	M 08400 CUR	NOT AVAILABLE	.00
M 06113 1	USE 8177 3010 SCREW	.18	M 08401 CBK	USE 3710 3001 CBK	4.06
M 06114 1	USE 8173 3001 NUT	.18	M 08401 CUR	USE 3710 3001 CUR	4.06
M 06115	USE 8176 3000 SCREW	.18	M 08421 2	USE 3721 3002 RUBBR	1.30
M 06116	USE 8174 3000 SPRNG	.18	M 08422 1	USE 3725 3001 STOP	.08
M 06117 0	USE 8175 3010 NUT	.18	M 08501 2	USE 6301 3002 MUFFL	12.16
M 06118	USE 8154 3000 CLAMP	.26	M 08515	TAIL PIPE	2.86
M 06121 0	USE 8171 8010 BULB	1.52	M 08516	USE 6320 3000 PIPE	2.22
M 06122	NOT AVAILABLE	.00	M 08531 1	USE 6351 3001 PIPE	3.96
M 06123	NOT AVAILABLE	.00	M 08532	USE 6361 3000 CLAMP	1.16
M 06126	NOT AVAILABLE	.00	M 08533 1	USE 6362 3002 JOINT	1.32
M 06200	USE 8201 3010 CBK	11.76	M 08533 2	USE 6362 3002 JOINT	1.32
M 06211 1	USE 8211 3001 BODY	4.30	M 08534 1	USE 6363 3001 STOP	.26
M 06213	USE 8240 3010 LIGHT	2.98	M 08535	USE 6364 3000 RING	.18
M 06215 1	USE 8259 3001 SPACR	.08	M 08601 CBK	USE 6802 3001 CFG	5.06
M 06216 1	USE 8251 3001 LENS	2.58	M 08601 CFG	USE 6802 3001 CFG	5.06
M 06217	USE 8252 3000 BULB	.50	M 08602 CBK	USE 6801 3001 CFG	5.06
M 06231	USE 8362 3000 BASE	1.16	M 08611	USE 6802 3001 CFG	5.06
M 06232	USE 8371 3000 LENS	1.16	M 08621	USE 6801 3001 CFG	5.06
M 06233 1	USE 8332 3000 BULB	.50	M 08631 2	USE 6831 3002 CBK	.82
M 06241	USE 8352 3000 BASE	1.16	M 08633	USE 09504 101 RING	.08
M 06301	SIGNAL LIGHT	2.40	M 08700	USE 9201 3000 TOOL	4.08
M 06302	SIGNAL LIGHT	2.40	M 08711 1	NOT AVAILABLE	.00
M 06305 2	USE 8305 3002 UNIT	3.22	M 08712	USE 823 20000 200SPR	.82
M 06311	BASE	.98	M 08713 0	USE 9231 3000 GRIP	.50
M 06312	PACKING	.26	M 08714 1	USE 9212 3001 SPANR	.66
M 06313	LENS	.66	M 08715	USE 9216 3000 SPANR	1.76
M 06321	BASE	.90	M 08716 0	NOT AVAILABLE	.00
M 06400 2	USE 8601 3002 SWTCH	4.22	M 08717 0	USE 9228 5000 DRIVR	.76
M 06411 11	USE 8621 3002 11	.50	M 09100 2	USE 6460 3012 SEAT	30.52
M 06411 12	USE 8621 3002 12	.50	M 09602	USE 8650 5000 SWTCH	2.90
M 06411 13	USE 8621 3002 13	.50	M 09622	CLAMP	.26
M 06411 14	USE 8621 3002 14	.50	M 09623	CLAMP	.26
M 06411 77	USE 8621 3002 77	.50	M 09624	SEAT	.28
M 06411 78	USE 8621 3002 78	.50	M 09625	USE 8661 3001 SPRNG	.42
M 06411 79	USE 8621 3002 79	.50	M 09801	USE 8240 3010 BASE	2.98
M 06411 80	USE 8621 3002 80	.50	M 09900	USE 9300 3010 TOOLS	25.00
M 06412	USE 8621 3002 11	.50	M 09901	USE 9301 3010 PULLR	11.50
M 06500	USE 8402 3000 HORN	4.68	M 09922 0	PISTON SEAT	2.08
M 06600 A1	USE 8701 3002 BATTY	16.62	M 09923 0	RUBBER RING RELEA	1.90
M 06701	USE 8810 3000 WIRE	5.42	M 09924 0	RUTOR PULLER	1.08
M 06731	USE 8822 3000 WIRE	.42	M 09925 0	CLUTCH DISC TOOL	2.72
M 06732	USE 8831 3000 WIRE	.66	M 09926 0	TOOL BAG	1.08
M 06733	USE 8535 3000 WIRE	.82	M 09927 0	FAN PULLER	.66
M 06736	WIRE	.46	M 09929	USE 9328 3001 TOOL	2.72
M 06738 1	USE 8829 3001 TUBE	.66	M 09931 0	NEEDLE JET PULLER	.92
M 06800	USE 8802 3021 FUSE	1.08	M 09932 0	BEARING REMOVER	3.80
M 06800 2	USE 8802 3030 FUSE	1.08	M 09936 0	ARBOR OIL SEAL	2.40
M 06811 1	USE 8861 3020 FUSE	.18	M 11853 1	USE 3433 3011 LOCK	3.78
M 07100 CBK	USE 5101 3001 CUR	36.92	M 11854 2	USE 3434 3012 611	.66
M 07100 CBN	USE 5101 3001 CBN	36.92	M 11854 2	USE 3434 3012 612	.66
M 07100 CUR	USE 5101 3001 CUR	36.92	M 11854 2	USE 3434 3012 613	.66
M 07101 1	USE 5101 3001 CUR	36.92	M 11854 2	USE 3434 3012 614	.66
M 07105 2	USE 5160 3002 CAP	2.66	M 15200	USE 6101 3010 GRIP	11.16
M 07106	USE 5103 3000 COCK	3.06	M 16200 BLE	NOT AVAILABLE	.00
M 07134	USE 5148 3000 WASH	.18	M 16200 CBK	USE 8201 3010 CBK	11.76
M 07135	USE 5149 3000 GRUM	.18	M 16200 CUR	USE 8201 3010 CUR	11.76
M 07137	USE 5142 3000 GRIP	1.16	M 16800 1	USE 8802 3021 FUSE	1.08
M 07138	USE 5141 3000 GRIP	1.16	M 16811	USE 8861 3030 FUSE	.18
M 07139	USE 5143 3000 MARK	1.48	M 18107	USE EA1 91150 SEAT	10.04
M 07152 1	USE 5171 3001 GASKT	.66	M 18174	PLATE	1.32
M 07158	NOT USED	.00	M 18175	NUT	.32
M 07161	USE 5181 3000 BODY	1.76	M 18176	SET BAND	3.60
M 07162 0	USE 5182 5000 BOWL	.76	M 19140 1	USE 3702 3020 FOOT	1.48
M 07163	USE 5183 3000 PACK	.08	M 19401	USE 3702 3020 FOOT	1.48
M 07166	USE 5184 3000 PACK	.08	M 19402	USE 3702 3020 FOOT	1.48
M 07182 1	USE 5172 3001 PIPE	.26	M 21100	FRAME RED	25.44
M 07183	USE 5187 3004 CLIP	.08	M 21106	NOT AVAILABLE	.00
M 07184	SPRING	.46	M 21121	CLAMP	1.20

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
M 21122	BRACKET	1.20	M 52000	USE 4100 3010 CFG	43.40
M 21125	USE 3424 3010 STRAP	.26	M 52000 CBK	USE 4100 3010 CUR	43.40
M 21131	SPACER	1.36	M 52000 CHG	USE 4100 3010 CHG	43.40
M 21181	STIFFENER	4.80	M 66200 CBK	USE 8201 3040 CBK	12.20
M 21189	TUBE	3.00	M 66200 CUR	USE 8201 3040 CUR	12.20
M 21191	TUBE	.76	EAL 10000	ENG 90 USE SCL326	370.00
M 21802	HANGER	3.76	EAL 11111	USE 1111 5000 HEAD	17.10
M 21833 1	USE 3353 3011 BAND	.50	EAL 11112	USE 1115 5000 NUT	.50
M 21861	STOPPER	1.80	EAL 11211	USE 1121 5030 CYLND	25.08
M 21865	HANGER R	1.36	EAL 11212	USE 1126 5000 STUD	.36
M 21867	HANGER L	1.06	EAL 11411	USE 1141 5000 GASKT	.42
M 21871	LINER	.60	EAL 11412	USE 1142 5000 GASKT	.58
M 21872	RUBBER MOUNT	.60	EAL 11413	USE 1143 5000 PACK	.26
M 21881	HANGER UPPER	1.20	EAL 13100	USE 1301 5010 CRANK	47.94
M 21882	HANGER LOWER	2.40	EAL 13111	NUT USED	.00
M 21883	LINER	.76	EAL 13121	NUT AVAILABLE	.00
M 21885	HANGER R	1.80	EAL 13151	USE 1321 5000 PIN	2.30
M 21886	HANGER L	1.66	EAL 13152	USE 1326 5000 RETNR	3.86
M 21891	TOOL BOX	4.12	EAL 13153	NUT AVAILABLE	.00
M 21895	NOT AVAILABLE	.00	EAL 13210	USE 1331 5010 ROD	10.98
M 21913	BUSHING	.60	EAL 13212	USE 1334 5000 BUSH	1.00
M 21914	USE 3382 3010 BUSH	.50	EAL 13221	USE 09021 103 NUT	.18
M 21915	BUSHING	1.36	EAL 13310	USE 1341 5000 STD	6.70
M 21916	COLLAR	.46	EAL 13310 25	USE 1342 5000 25	6.70
M 21917	USE 3387 3010 COLLR	.28	EAL 13310 50	USE 1343 5000 50	6.70
M 22501 2	USE 8111 3012 CUR	8.20	EAL 13320	USE 1305 5000 STD	3.72
M 22501 2	USE 8111 3012 CBK	8.20	EAL 13320 25	USE 1306 5000 25	3.72
M 23172 1	USE 4853 3011 PROTR	1.16	EAL 13320 50	USE 1307 5000 50	3.72
M 25100	GRIP	10.50	EAL 13331	USE 1381 5000 PIN	.82
M 25111	LEVER HOLDER	3.76	EAL 13332	USE 1382 5000 CLIP	.08
M 25300	USE 8401 3030 METER	17.26	EAL 13411	USE 09049 106 SAIM	.26
M 25314	USE 8421 3002 SOCKET	.46	EAL 13413	USE 09062 103 DOWEL	.08
M 25315	USE 8424 3010 BULB	.50	EAL 13421	USE 1385 5000 GEAR	6.72
M 25318	USE 8427 3000 GASKT	.08	EAL 13422	USE 09046 101 WASH	.18
M 26100 2	USE 8102 3012 LAMP	7.98	EAL 13423	USE 09029 103 NUT	.42
M 26121	USE 8171 3010 BULB	1.16	EAL 14110	USE 1412 5010 VALVE	6.90
M 26203	LIGHT R	2.70	EAL 14121	USE 1451 5000 COLLR	3.72
M 26204	LIGHT L	2.70	EAL 14122	USE 09066 102 RING	.42
M 26217	USE 8252 3020 BULB	.50	EAL 14131	USE 1431 5000 COVER	6.40
M 26232	USE 8371 3011 LENS	1.06	EAL 14132	USE 09066 103 RING	1.16
M 26233 1	USE 8332 3010 BULB	.50	EAL 14133	USE 09066 104 RING	.36
M 26235	NOT AVAILABLE	.00	EAL 14141	USE 09090 108 SEAL	1.66
M 26241	WINKER BASE	1.16	EAL 16100	USE 1600 5000 CARB	19.40
M 26245	NOT AVAILABLE	.00	EAL 16111	USE 1611 5000 BODY	14.26
M 26301	SIGNAL LIGHT R	2.40	EAL 16121	USE 1614 5000 VALVE	3.86
M 26302	SIGNAL LIGHT L	2.40	EAL 16122	USE 1615 3021 JET	1.48
M 26305 2	USE 8305 3012 UNIT	3.22	EAL 16123	USE 1616 3021 CLIP	.36
M 26314	USE 8332 3020 BULB	.50	EAL 16124	USE 1617 3021 SEAT	.26
M 26400 3	USE 8601 3013 SWITCH	4.22	EAL 16125	USE 1618 5000 SPRNG	.58
M 26411 67	USE 8621 3011 67	.50	EAL 16126	USE 1619 5000 TOP	2.30
M 26411 68	USE 8621 3011 68	.50	EAL 16127	USE 1621 5000 CAP	1.58
M 26411 69	USE 8621 3011 69	.50	EAL 16128	USE 1622 5000 ADJTR	.58
M 26411 70	USE 8621 3011 70	.50	EAL 16129	USE 1623 5000 NUT	.18
M 26500 1	USE 8402 5600 HORN	4.52	EAL 16131	USE 1626 5000 ROD	.36
M 26600	USE 8701 3040 BATTY	6.76	EAL 16132	USE 1627 5000 STOP	.82
M 26700	USE 8810 3011 WIRE	3.62	EAL 16133	USE 1628 5000 SPRNG	.26
M 26800 1	USE 8802 3011 FUSE	1.08	EAL 16135	USE 1631 5000 SCREW	1.32
M 26811	USE 8861 3010 FUSE	.18	EAL 16136	USE 1632 3010 SCREW	.26
M 28601	USE 6802 3001 CFG	5.06	EAL 16141	USE 1635 5000 100	1.16
M 28602 CBK	USE 6801 3012 CBK	5.06	EAL 16141 110	USE 1635 5000 110	1.16
M 28602 CFG	USE 6801 3030 CFG	5.06	EAL 16142	USE 1633 3100 JET	1.58
M 28621	USE 6801 3012 CBK	5.06	EAL 16143	USE 1634 3110 JET	1.32
M 29904 1	MAGNETO PULLER	7.08	EAL 16151	USE 1651 5000 BOLT	1.22
M 40217	USE 8252 3020 BULB	.50	EAL 16152	USE 1652 5010 CONN	1.40
M 41826	USE 4281 3010 BRCKT	1.72	EAL 16153	USE 1654 3100 GASKT	.08
M 42100	USE 4100 3010 CUR	43.40	EAL 16161	USE 1645 5000 PLUNG	1.82
M 42100 CFG	USE 4100 3010 CFG	43.40	EAL 16162	USE 1646 5000 SPRNG	.26
M 42100 CUR	USE 4100 3010 CUR	43.40	EAL 16163	USE 1647 5000 CAP	1.00
M 42401 1	USE 4511 3010 BAR	6.90	EAL 16170	USE 1660 5010 VALVE	6.18
M 42422 1	USE 4283 3012 HOLDR	3.40	EAL 16173	USE 1665 3100 GASKT	.08
M 42423 1	USE 4282 3012 BASE	6.18	EAL 16183	USE 1656 5000 BODY	2.30
M 42435	USE 09511 106 BOLT	.42	EAL 16184	USE 1657 3100 PACK	.42
M 42513 1	USE 8124 3011 PROTR	.08	EAL 16191	USE 1613 3020 SCREW	.36
M 45200 1	USE 6101 3021 GRIP	11.16	EAL 17100	USE 1701 5000 MAG	43.18
M 45211 1	USE 6111 3011 HOLDR	2.90	EAL 17111	USE 1718 5000 FLYWL	25.44
M 45212 1	USE 6122 3011 LEVER	2.40	EAL 17210	USE 1710 5000 FRAME	26.46
M 46217	USE 8252 3020 BULB	.50	EAL 17212	USE 1713 5000 COIL	5.66
M 46600	USE 8701 3040 BATTY	6.76	EAL 17213	USE 1714 5000 COIL	6.70
M 46800	USE 8802 3030 FUSE	1.08	EAL 17230	USE 1752 5000 POINT	4.08
M 46811	USE 8861 3020 FUSE	.18	EAL 17241	USE 1753 5000 CONU	2.90
M 49625 1	USE 8661 3001 SPRNG	.42	EAL 17251	USE 1755 5000 GRUM	.58
M 51100	USE 3110 3040 CUR	62.04	EAL 17252	USE 1764 5000 GRUM	.58
M 52000	USE 4100 3010 CUR	43.40	EAL 17311	USE 1761 5000 CASE	.66
M 52000	USE 4100 3010 BLE	43.40	EAL 17312	USE 1762 5000 PLATE	.26

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
EAL 17313	USE 1763 5000 PACK	.08	EAL 24212	USE 2522 5000 PIN	.18
EAL 17410	USE 87HS NGK PLUG	1.30	EAL 24213	USE 2523 5000 STOP	.18
EAL 21110	USE 2110 5010 CASE	27.32	EAL 24214	USE 2524 5000 HOLDR	.36
EAL 21121	USE 07 6304 03 BEAR	3.78	EAL 24215	USE 2541 5001 FORK	8.22
EAL 21122	USE 07 6201 03 BEAR	3.06	EAL 24216	USE 2544 5000 PIN	.36
EAL 21124	USE 09090 106 SEAL	.92	EAL 24221	0 USE 2549 5000 PLATE	.92
EAL 21127	USE 2121 5000 STUD	.26	EAL 24221	1 USE 2549 5001 PLATE	1.48
EAL 21210	USE 2130 5001 CASE	27.78	EAL 24222	USE 0441 0611 WASH	.08
EAL 21210	1 USE 2130 5001 CASE	27.78	EAL 24230	USE 2531 5001 STOP	2.16
EAL 21213	USE 2133 5000 BUSH	2.22	EAL 24231	USE 2531 5001 STOP	2.16
EAL 21222	USE 07 6006 01 BEAR	4.60	EAL 24232	USE 2536 5000 BOLT	.78
EAL 21224	USE 2145 5000 HOLDR	.66	EAL 24233	USE 2538 5000 SPRNG	.18
EAL 21310	USE 2160 5000 CASE	22.30	EAL 24234	USE 2537 5000 COLLR	.22
EAL 21321	0 USE 2162 5002 PIPE	.82	EAL 24235	USE 2538 5000 SPRNG	.18
EAL 21321	1 USE 2162 5002 PIPE	.82	EAL 24236	USE 2536 5000 BOLT	.78
EAL 21322	USE 2162 5002 PIPE	.82	EAL 24237	USE 2537 5000 COLLR	.22
EAL 21322	1 USE 2162 5002 PIPE	.82	EAL 24311	USE 2581 5000 PEDAL	5.12
EAL 21332	USE 2165 5000 COCK	1.16	EAL 24312	USE 2582 5000 RUBBR	.76
EAL 21333	USE 09066 105 RING	.38	EAL 25111	0 USE 2621 5002 SHAFT	6.40
EAL 21334	USE 09058 102 PLUG	1.00	EAL 25111	1 USE 2621 5002 SHAFT	6.40
EAL 21335	USE 09065 102 GASKT	.18	EAL 25112	USE 2631 5000 GEAR	15.68
EAL 21337	USE 2168 5000 PLUG	.18	EAL 25113	USE 2632 5000 ARM	4.76
EAL 21351	USE 2176 5000 COVER	5.42	EAL 25114	USE 2633 5000 RATCH	1.58
EAL 21352	USE 2179 5000 CAP	.36	EAL 25115	USE 2634 5000 SPRNG	.36
EAL 21353	USE 2177 5000 CAP	3.78	EAL 25120	USE 2635 5000 STOP	2.30
EAL 21355	USE 2178 5000 RING	.36	EAL 25131	USE 2636 5001 SPRNG	1.16
EAL 21411	USE 2151 5020 COVER	16.38	EAL 25132	USE 2638 3200 SPACR	.82
EAL 21412	USE 2152 5001 COVER	3.12	EAL 25200	USE 2680 5000 PEDAL	9.88
EAL 21422	USE 2156 5000 RUBBR	.36	EAL 25214	USE 2684 5000 WASH	.26
EAL 21431	1 USE 2153 5001 COVER	2.08	EAL 31100	08 USE 3110 5011 CBK	73.82
EAL 21511	USE 2181 5000 PACK	1.00	EAL 31100	0MB USE 3110 5011 OMB	73.82
EAL 21512	USE 2183 5000 PACK	1.00	EAL 31320	USE 3331 5000 TUBE	5.42
EAL 21513	USE 2185 5000 PACK	.50	EAL 31410	USE 3318 5000 CAGE	1.00
EAL 21514	USE 2184 5000 PACK	.58	EAL 31411	USE 3313 5000 RACE	1.40
EAL 21515	USE 2186 5000 GASKT	.08	EAL 31412	USE 3311 5000 RACE	1.32
EAL 22111	USE 2221 5000 BRCKT	14.12	EAL 31414	USE 3321 5000 NUT	.82
EAL 22112	USE 2210 5000 PLATE	4.60	EAL 31415	USE 3322 5000 NUT	1.32
EAL 22115	USE 2227 5000 PLATE	.76	EAL 31416	USE 3319 5000 CAP	.26
EAL 22118	USE 2218 5000 SPRNG	.36	EAL 31417	USE 3334 5000 BRCKT	2.16
EAL 22119	USE 2216 5000 PLATE	1.08	EAL 31419	NOT AVAILABLE	.00
EAL 22120	USE 2215 5000 PLATE	1.00	EAL 31421	USE 3414 5000 BOLT	1.76
EAL 22121	USE 2214 5000 DISC	2.16	EAL 31422	USE 3415 5000 BOLT	1.00
EAL 22221	USE 2260 5000 ARM	1.82	EAL 31423	USE 3416 5000 RUBBR	.26
EAL 22225	USE 2264 5000 SCREW	1.08	EAL 31424	USE 3417 5000 RUBBR	.26
EAL 22226	USE 2265 5000 SCREW	2.26	EAL 31425	USE 3419 5000 BOLT	.50
EAL 22227	USE 2267 8000 SCREW	.36	EAL 31426	MS USE 3422 5000 MS	1.40
EAL 22228	USE 2268 5000 WASH	.30	EAL 31427	USE 3422 5000 MS	1.40
EAL 22229	USE 2271 5000 SPRNG	.36	EAL 31428	USE 09525 105 NUT	.42
EAL 22230	USE 09090 102 SEAL	.82	EAL 31429	USE 3418 5000 BRCKT	2.40
EAL 22231	USE 09056 105 PIN	.30	EAL 31432	USE 0411 1022 WASH	.08
EAL 22232	USE 2272 5000 WASH	.08	EAL 31440	USE 3354 5001 BAND	.50
EAL 22240	USE 6186 5000 CABLE	3.12	EAL 31450	USE 3433 5000 LOCK	4.30
EAL 23110	USE 2410 5001 GEAR	26.38	EAL 31459	911 USE 3435 5010 911	.66
EAL 23211	USE 2421 5000 SHAFT	11.88	EAL 31459	912 USE 3435 5010 912	.66
EAL 23211	1 USE 2421 5001 SHAFT	18.98	EAL 31459	913 USE 3435 5010 913	.66
EAL 23212	USE 2426 5000 GEAR	7.72	EAL 31459	914 USE 3435 5010 914	.66
EAL 23213	USE 2431 5000 GEAR	11.56	EAL 31459	915 USE 3435 5010 915	.66
EAL 23214	USE 2436 5000 GEAR	9.10	EAL 31459	949 USE 3435 5010 949	.66
EAL 23215	USE 09002 103 CLIP	.26	EAL 31459	950 USE 3435 5010 950	.66
EAL 23216	USE 2478 5000 BUSH	2.40	EAL 31459	951 USE 3435 5010 951	.66
EAL 23217	USE 09048 101 WASH	.36	EAL 31459	952 USE 3435 5010 952	.66
EAL 23220	USE 2610 5000 GEAR	14.02	EAL 31459	953 USE 3435 5010 953	.66
EAL 23231	USE 09021 102 NUT	.36	EAL 31459	954 USE 3435 5010 954	.66
EAL 23232	USE 09047 103 WASH	.26	EAL 41000	08 USE 4100 5000 CBK	100.26
EAL 23236	USE 2536 5000 BOLT	.78	EAL 41000	0MB USE 4100 5000 OMB	100.26
EAL 23311	0 USE 2446 5000 SHAFT	7.06	EAL 41110	1 USE 4111 5001 MS	21.66
EAL 23311	1 USE 2446 5001 SHAFT	14.28	EAL 41120	1 USE 4113 5001 TUBE	15.98
EAL 23312	USE 2451 5000 GEAR	11.56	EAL 41125	NOT AVAILABLE	.00
EAL 23313	USE 2456 5000 GEAR	9.06	EAL 41131	USE 4114 5000 NUT	7.72
EAL 23314	USE 2461 5000 GEAR	18.60	EAL 41132	USE 09566 102 RING	.42
EAL 23315	USE 2466 5000 GEAR	8.68	EAL 41133	USE 09590 108 SEAL	2.16
EAL 23316	USE 2616 5000 GEAR	3.86	EAL 41134	USE 4115 5000 SEAT	.26
EAL 23317	USE 09048 102 WASH	.36	EAL 41141	USE 4116 5000 BUCH	1.00
EAL 23318	USE 2481 5000 COLLR	.66	EAL 41161	USE 09531 101 PLUG	.08
EAL 23321	USE 2483 5000 COLLR	1.08	EAL 41162	USE 4118 5000 PACK	.08
EAL 23322	USE 2484 5000 SPRKT	5.42	EAL 41171	USE 4121 5000 SPRNG	3.40
EAL 24110	0 USE 2510 5000 SHAFT	7.20	EAL 41172	USE 4122 5000 GUIDE	.66
EAL 24110	1 USE 2510 5002 SHAFT	8.70	EAL 41181	USE 4123 5000 PACK	.26
EAL 24115	USE 2517 5000 SPRNG	.36	EAL 41182	USE 4124 8000 BOLT	.76
EAL 24117	USE 2551 5000 SPRNG	.76	EAL 41183	USE 0411 1022 WASH	.08
EAL 24118	USE 2553 5000 PIN	.92	EAL 41210	1 USE 4131 5001 MS	21.66
EAL 24210	0 USE 2502 5000 DRUM	8.90	EAL 41251	USE 09511 116 BOLT	.26
EAL 24210	1 USE 2502 5001 DRUM	22.78	EAL 41310	USE 4151 5000 CBK	3.62
EAL 24211	USE 2502 5000 DRUM	8.90	EAL 41321	USE 09511 137 BOLT	.42

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
EA1 41410	OB USE 4171 5000 CBK	7.98	EA1 68112	USE 6831 5000 KNUB	.92
EA1 41410	OMB USE 4171 5000 OMB	7.98	EA1 68121	OB USE 6821 3210 CBK	6.70
EA1 41420	OB USE 4181 5000 CBK	7.98	EA1 68121	OMB USE 6821 3220 OMB	9.10
EA1 41420	OMB USE 4181 5000 OMB	7.98	EA1 68121	OUR USE 6821 3200 OMB	9.10
EA1 41432	USE 0411 1022 WASH	.08	EA1 69100	USE 9201 5000 TOOLS	8.66
EA1 41511	USE 4161 5000 BRCKT	13.68	EA1 69111	USE 9211 5000 BAG	.76
EA1 41521	USE 4162 5000 HOLDR	4.22	EA1 69112	USE 9225 5000 PLIER	2.58
EA1 41541	USE 0133 0836 BOLT	.82	EA1 69113	USE 9218 5000 BOX	.82
EA1 41551	USE 4164 5000 NUT	4.00	EA1 69114	USE 9217 5000 BOX	2.30
EA1 41552	USE 4165 5000 WASH	.50	EA1 69115	USE 9215 5000 BUX	1.40
EA1 42120	CBK USE 4421 5000 CBK	2.40	EA1 69116	USE 9213 5000 DRIVR	.76
EA1 42130	CBK USE 4422 5000 CBK	2.40	EA1 69117	USE 9226 5000 DRIVR	.76
EA1 42221	USE 4432 5000 PROTR	.50	EA1 71020	USE 7101 5000 WHEEL	36.48
EA1 43111	USE 4511 5000 BAR	6.90	EA1 71110	1 USE 7111 5002 DRUM	22.30
EA1 45100	USE 4701 5000 MS	8.46	EA1 71110	2 USE 7111 5002 DRUM	22.30
EA1 47100	CBK USE 4810 5000 CBK	23.96	EA1 71114	USE 7114 5000 PIPE	.50
EA1 47100	MB USE 4810 5000 MB	23.96	EA1 71116	USE 07 6201 03 BEAR	3.06
EA1 47211	USE 4851 5000 RUBBR	1.48	EA1 71118	SNAP RING	.72
EA1 47212	USE 4854 5000 SPRNG	.18	EA1 71130	1 USE 7130 5002 PANEL	23.70
EA1 47213	USE 4852 5000 CAP	.18	EA1 71130	3 USE 7130 5003 PANEL	23.70
EA1 48100	CBK USE 4901 5000 CBK	11.88	EA1 71141	USE 7148 5001 GEAR	2.58
EA1 48100	MB USE 4901 5000 MB	13.66	EA1 71142	USE 7149 3110 CONN	.36
EA1 51110	CBK USE 5110 5001 CBK	41.02	EA1 71150	USE 7140 5000 SHOE	3.70
EA1 51110	OMB USE 5110 5001 MB	41.02	EA1 71161	USE 7145 3110 SPRNG	.30
EA1 51211	USE 5141 5000 GRIP	1.40	EA1 71181	USE 7221 5000 SHAFT	3.16
EA1 51212	USE 5142 5000 GRIP	1.40	EA1 71191	USE 7166 5000 BAR	1.76
EA1 51213	USE 5143 5000 MARK	1.40	EA1 71192	USE 7167 5000 BOLT	.36
EA1 52113	USE 5182 5000 BOWL	.76	EA1 71200	USE 7241 5000 RIM	11.60
EA1 52121	USE 5186 5000 TUBE	.36	EA1 71300	USE 7108 5000 SPUKE	3.40
EA1 52122	USE 5172 5000 PIPE	.58	EA1 71300	USE 7108 5000 EA	.16
EA1 61100	USE 6101 5000 GRIP	10.38	EA1 71410	USE 250 X 17 FS TIR	
EA1 61111	USE 6111 5000 HOLDR	3.12	EA1 71420	USE 250 X 17 TUBE	
EA1 61120	USE 6115 5000 WIRE	4.38	EA1 71999	USE 7101 5000 WHEEL	36.48
EA1 61141	USE 6121 5000 COVER	3.12	EA1 72020	USE 7301 5000 WHEEL	43.76
EA1 61143	USE 6119 5000 KNUB	.36	EA1 72110	0 USE 7311 5001 DRUM	23.22
EA1 61170	USE 6103 5000 LEVER	2.66	EA1 72110	1 USE 7311 5001 DRUM	23.22
EA1 61200	USE 6104 5020 GRIP	11.28	EA1 72114	USE 7314 5000 PIPE	.66
EA1 61220	NUT USED	.00	EA1 72141	USE 7376 5001 FLANG	3.92
EA1 61241	USE 6151 5020 COVER	3.12	EA1 72142	USE 7377 5000 COLLR	.26
EA1 61244	USE 6147 3100 CLAMP	.36	EA1 72151	USE 7381 5000 SPRKT	5.80
EA1 61300	USE 8401 5011 METER	20.20	EA1 72155	USE 0431 0820 WASH	.08
EA1 61321	1 USE 8833 5001 WIRE	.58	EA1 72160	USE 7331 5001 PANEL	18.20
EA1 61510	USE 6171 5000 CABLE	3.40	EA1 72160	2 USE 7331 5001 PANEL	18.20
EA1 61512	USE 9411 5000 CABLE	1.32	EA1 72181	USE 7421 3110 SHAFT	4.02
EA1 61520	USE 6176 5000 CABLE	1.48	EA1 72191	USE 7366 5000 BAR	1.76
EA1 61530	USE 6178 5000 CABLE	2.90	EA1 72300	USE 7308 5000 SPUKE	4.46
EA1 61541	USE 6181 5000 CABLE	3.30	EA1 72300	USE 7308 5000 EA	.16
EA1 61542	USE 6182 5000 SPRNG	.18	EA1 72350	USE 7308 5000 SPUKE	4.46
EA1 61543	USE 6183 5000 BOOT	.76	EA1 72410	USE 250 X 17 RS TIR	
EA1 61551	CABLE GUIDE	.58	EA1 72420	USE 250 X 17 TUBE	
EA1 61561	USE 6189 5000 CLAMP	.42	EA1 72999	USE 7301 5000 WHEEL	43.76
EA1 61562	USE 6189 5000 CLAMP	.42	EA1 73000	USE 7501 5000 CHAIN	9.70
EA1 61610	USE 3810 5030 PEDAL	6.18	EA1 73150	USE 7520 5000 LINK	.68
EA1 61621	USE 3821 5000 SPRNG	.26	EA1 73200	USE 7520 5000 LINK	.68
EA1 62110	1 USE 6211 5001 CLEAN	6.88	EA1 81110	OB USE 8111 5000 CBK	5.88
EA1 62121	USE 6241 5000 PIPE	1.58	EA1 81110	OMB USE 8111 5020 MB	14.80
EA1 62122	USE 6242 5000 JOINT	1.26	EA1 81110	OUR USE 8111 5020 OUR	14.80
EA1 62123	USE 6243 5000 RING	.36	EA1 81112	USE 8125 5020 GRUM	.18
EA1 63111	USE 6351 5030 PIPE	6.18	EA1 81113	USE 8126 5000 NUT	.82
EA1 63121	USE 6362 5000 JOINT	1.98	EA1 81200	USE 8102 5000 LIGHT	7.98
EA1 63122	USE 6364 5000 RING	.26	EA1 81210	USE 8140 5000 RIM	4.38
EA1 63123	USE 6361 5000 NUT	2.30	EA1 81220	USE 8150 5000 LENS	5.42
EA1 63124	USE 6363 5000 STOP	.18	EA1 81230	USE 8160 5000 SOCKT	1.40
EA1 63125	DISCONTINUED	.00	EA1 81241	USE 8172 5000 STOP	.18
EA1 63300	USE 6301 5000 MUFFR	20.52	EA1 81242	USE 8171 5000 BULB	1.16
EA1 63313	USE 6320 5000 PIPE	4.76	EA1 81311	USE 8834 5000 WIRE	.26
EA1 64100	USE 6410 5020 SEAT	19.40	EA1 85110	USE 8402 5600 HORN	4.52
EA1 65100	OMB USE 6510 5000 RACK	8.46	EA1 86100	USE 8601 5000 SWITCH	6.20
EA1 66410	USE 3610 5000 CBK	6.70	EA1 87110	USE 8701 5010 BATTY	9.88
EA1 66421	USE 3621 3200 TUBE	1.40	EA1 88110	USE 8810 5010 WIRE	4.38
EA1 66422	USE 3622 5000 GUIDE	.26	EA1 88300	USE 8802 5000 FUSE	1.00
EA1 66423	USE 3623 5000 PIN	.08	EA1 89100	USE 8650 5000 SWITCH	2.90
EA1 66424	USE 3624 5000 SPRNG	.26	EA1 89110	USE 8650 5000 SWITCH	2.90
EA1 67110	USE 3710 5000 CBK	5.80	EA1 89121	0 USE 8661 3001 SPRNG	.42
EA1 67210	USE 3650 5000 STAND	4.00	EA1 89121	1 USE 8661 5001 SPRNG	.42
EA1 67211	USE 3662 5000 BOLT	.50	EA1 89310	USE 8501 5001 COIL	18.48
EA1 67212	USE 3663 5000 SPRNG	.58	EA1 89320	USE 8520 5000 CAP	1.00
EA1 67300	USE 3702 5000 REST	1.82	EA1 89510	USE 8702 5000 RECTR	3.56
EA1 67322	USE 3762 5000 WASH	.08	EA1 91100	USE 6460 5030 SEAT	44.66
EA1 67323	USE 3763 5000 PIN	.18	EA1 91150	REAR SEAT 8590M	12.56
EA1 68111	UB USE 6811 5030 CBK	6.70	EA1 91200	USE 6531 3220 RACK	11.96
EA1 68111	OMB 90M USE 6811 50300M	6.70	EA1 91550	USE EA1 91150 SEAT	10.04
EA1 68111	OMB 90T USE 6811 50300M	6.70	EA1 91720	USE 4421 5010 STAY	2.30
EA1 68111	OUR USE 6811 5030 DUR	9.12	EA1 91730	USE 4422 5010 STAY	2.40

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
EA1 91741	USE 4435 5010 PLUG	.18	EA2 16183	USE 1656 5010 BODY	5.88
EA1 91751	USE 4451 5010 FLAP	1.16	EA2 16184	USE 1657 5010 GASKT	.58
EA1 91752	USE 4452 5010 BAND	.26	EA2 16191	USE 1613 5010 SCREW	.36
EA1 91800	USE 4751 5010 CASE	5.12	EA2 21351	USE 2176 5010 COVER	14.80
EA1 99100	USE 9300 5010 TOOLS	25.00	EA2 21353	USE 2177 5010 CAP	3.40
EA1 99111	35 MM WRENCH	5.66	EA2 21355	USE 2178 5010 RING	.42
EA1 99112	FRONT FORK TOOL	3.12	EA2 22118	USE 2218 5010 SPRNG	.36
EA1 99113	NUT AVAILABLE	.00	EA2 31100	CBK USE 3110 5031 CBK	82.04
EA1 99114	PISTON SEAT	2.90	EA2 31110	OB USE 3110 5031 CBK	82.04
EA1 99115	NOT AVAILABLE	.00	EA2 47100	OB USE 4810 5021 CBK	23.96
EA1 99116	USE 9375 5000 PULLR	7.98	EA2 47214	USE 4855 5010 BOLT	.58
EA1 99117	NOT AVAILABLE	.00	EA2 51110	OB USE 5110 5011 FAR	60.14
EA11 91311	USE 6548 5010 PLATE	1.76	EA2 51211	USE 5141 5010 GRIP	2.90
EA13 16100	USE 1600 5030 CARB	19.40	EA2 51212	USE 5142 5010 GRIP	2.90
EA13 16141	130 USE 1635 5000 130	1.16	EA2 61520	USE 6176 5040 CABLE	2.58
EA13 17410	USE 87HZ NGK PLUG	1.30	EA2 61530	USE 6178 5030 CABLE	2.66
EA13 21411	USE 2151 5020 COVER	16.38	EA2 62110	USE 6211 5010 CLEAN	7.98
EA13 21431	USE 2153 5001 GPVER	2.08	EA2 62121	USE 6241 5010 PIPE	1.58
EA13 31417	USE 3336 5010 STOP	1.40	EA2 62122	USE 6242 5010 JOINT	1.40
EA13 31431	USE 0411 1022 WASH	.08	EA2 63111	USE 6351 5010 PIPE	6.18
EA13 31433	USE 3389 5010 COLLR	.58	EA2 63300	USE 6301 5020 MUFFL	22.78
EA13 31434	USE 0231 1000 NUT	.08	EA2 63313	USE 6320 5010 PIPE	4.90
EA13 31437	USE 3336 5010 STOP	1.40	EA2 64100	USE 6430 5030 SEAT	27.34
EA13 41000	OMB USE 4100 5020 MB	100.28	EA2 68121	CUR USE 6821 5070 FAR	6.90
EA13 41171	USE 4121 5010 SPRNG	3.78	EA2 68121	OB USE 6821 5040 CBK	9.10
EA13 41422	USE 3415 5010 BOLT	1.76	EA2 72191	USE 7366 5010 BAR	1.98
EA13 42110	USE 4411 5011 XCI	15.98	EA2 83100	USE 8205 5021 LIGHT	13.66
EA13 43111	USE 4511 5040 BAR	9.12	EA21 61300	USE 8401 5030 METER	20.20
EA13 45100	USE 4751 5030 CASE	6.88	EA22 16140	USE 1690 5010 JET	3.90
EA13 48100	MB USE 4901 5010 MB	13.68	EA22 22240	USE 6186 5020 CABLE	3.62
EA13 61610	USE 3810 5021 PEDAL	6.18	EA22 23322	USE 2484 5010 SPRKT	4.42
EA13 63111	USE 6351 5040 PIPE	6.18	EA22 31121	USE 3342 5010 CASE	13.80
EA13 63300	USE 6301 5010 MUFFR	22.78	EA22 31433	COIL BRACKET	5.42
EA13 63310	USE 6301 5010 MUFFR	22.78	EA22 31434	USE 3166 5010 BRCKT	2.10
EA13 63327	USE 6332 5010 PROTR	3.96	EA22 41431	NUMBER PLATE BRAC	2.30
EA13 63328	USE 6333 5010 PROTR	3.16	EA22 41432	NUMBER PLATE	10.60
EA13 63329	USE 6334 5010 BRCKT	.82	EA22 41511	USE 4161 5010 BRDGE	14.36
EA13 63331	USE 6335 5010 STAY	1.40	EA22 41521	USE 4162 5010 HOLDR	8.12
EA13 67110	OB USE 3710 5020 CBK	6.88	EA22 43110	USE 4511 8020 BAR	9.38
EA13 67121	USE 3711 5010 SHAFT	1.82	EA22 61100	CLUTCH GRIP ASSY	27.40
EA13 67122	USE 3722 5010 WASH	.76	EA22 61200	THROTTLE GRIP ASS	27.40
EA13 67123	USE 09546 104 WASH	.08	EA22 61520	USE 6176 5030 CABLE	3.40
EA13 67124	USE 3723 5010 BOLT	.82	EA22 61540	USE 6181 5020 CABLE	2.36
EA13 71410	USE 250 X 17 HK TIRE		EA22 61610	USE 3810 5410 PEDAL	5.66
EA13 72150	USE 7411 5020 SPRKT	41.80	EA22 62100	USE 6201 5010 CLEAN	44.54
EA13 73000	USE 7502 5020 EXT	2.26	EA22 63300	USE 6310 5020 MUFFR	32.00
EA13 91310	USE 6541 5030 RACK	21.52	EA22 64100	USE 6430 5020 SEAT	45.56
EA2 10000	ENG 905P USE SCI327	390.00	EA22 67110	FOOTREST SOLID TY	5.92
EA2 11211	USE 1121 5020 CYLR	53.22	EA22 72151	46 USE 7381 5020 46T	8.92
EA2 11212	USE 09016 106 STUD	.42	EA22 72151	44 USE 7381 5030 44T	8.92
EA2 11411	USE 1141 5010 GASKT	.42	EA22 72151	42 USE 7381 5040 42T	8.92
EA2 13100	USE 1301 5010 CRANK	47.94	EA22 72151	40 USE 7381 5050 40T	8.92
EA2 13111	NOT USED	.00	EA22 72151	38 USE 7381 5060 38T	8.92
EA2 13121	NOT USED	.00	EA22 72151	48 NOT AVAILABLE	.00
EA2 13211	USE 1331 5010 ROD	10.98	EA22 86100	USE 8601 5010 SWTCH	4.60
EA2 13212	USE 1333 5010 BEAR	3.88	EA24 61520	USE 6176 5040 CABLE	2.58
EA2 13310	USE 1341 5010 PISTN	6.70	EA24 61530	USE 6178 5030 CABLE	2.66
EA2 13320	USE 1305 5010 RING	3.40	EA24 64100	USE 6430 5030 SEAT	27.34
EA2 14110	ROTARY VLV OLD STYL	.00	EA24 83100	USE 8205 5021 LIGHT	13.66
EA2 14112	USE 1412 5010 VALVE	6.90	EAE 11211	USE 1121 5030 CYLR	25.08
EA2 14131	USE 1431 5010 COVER	10.70	EAE 16100	0 USE 1600 5030 CARB	19.40
EA2 16100	USE 1600 5080 CARB	29.92	EAE 16141	120 USE 1635 5000 120	1.16
EA2 16111	USE 1611 5010 BODY	20.52	EAE 17410	USE 87HS NGK PLUG	1.30
EA2 16121	USE 1614 5010 VALVE	6.18	EAE 31100	OB USE 3110 5011 CBK	73.82
EA2 16122	USE 1615 5010 JET	1.40	EAE 31100	UMB USE 3110 5011 OMB	73.82
EA2 16123	USE 1616 5010 CLIP	.36	EAE 42100	OB USE 4410 5002 CBK	15.90
EA2 16124	USE 1617 5010 SEAT	.76	EAE 61200	USE 6104 5020 GRIP	11.28
EA2 16125	USE 1618 5010 SPRNG	.58	EAE 61241	USE 6151 5020 COVER	3.12
EA2 16126	USE 1619 5010 TOP	1.40	EAE 61300	USE 8401 5011 METER	20.20
EA2 16127	USE 1621 5010 CAP	1.40	EAE 63111	USE 6351 5030 PIPE	6.18
EA2 16131	USE 1626 5010 ROD	.42	EAE 81100	USE 8102 5020 LAMP	14.62
EA2 16132	USE 1627 5010 SCREW	.76	EAE 81111	MB USE 8111 5020 MB	14.80
EA2 16133	USE 1628 5010 SPRNG	.26	EAE 81111	OB USE 8111 5020 CBK	14.80
EA2 16141	USE 1635 5010 100	1.16	EAE 81111	CUR USE 8111 5020 FAR	17.10
EA2 16141	USE 1635 5010 110	1.16	EAE 81111	OUR USE 8111 5020 OUR	14.80
EA2 16141	120 USE 1635 5010 120	1.16	EAE 81112	USE 8125 5020 GRDM	.18
EA2 16141	130 USE 1635 5010 130	1.16	EAE 81200	USE 8102 5020 LAMP	14.62
EA2 16141	140 USE 1635 5010 140	1.16	EAE 81210	USE 8140 5010 XCI	5.62
EA2 16141	150 USE 1635 5010 150	1.16	EAE 81220	USE 8150 5020 LENS	5.62
EA2 16141	95 USE 1635 5010 95	1.16	EAE 81230	USE 8160 5020 SOCKT	3.90
EA2 16142	USE 1633 5010 JET	1.76	EAE 83100	USE 8205 5011 LIGHT	13.66
EA2 16143	USE 1634 5010 JET	1.76	EAE 83110	USE 8240 5010 SOCKT	5.96
EA2 16163	USE 1647 5010 CAP	.92	EAE 87110	USE 8701 5010 BATTY	9.88
EA2 16181	USE 1666 5010 FLOAT	3.16	EAE 88110	USE 8810 5010 WIRE	4.38

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
EAE 88120	USE 8810 5010 WIRE	4.38	GAI 18412	USE 1832 3100 RUBBR	.26
EAE 88121	USE 8824 5010 CONN	.76	GAI 21110	USE 2110 3100 CASE	29.82
EAE 91200	USE 5531 3220 RACK	11.96	GAI 21114	USE 2112 3000 BUSH	1.98
EAE 91710	USE 4410 5012 XCI	15.98	GAI 21117	USE 2121 3100 STUD	.58
EAT1 39111	USE 6761 5010 GUARD	5.42	GAI 21151	USE 2129 3100 CLAMP	.26
EAT1 42110	USE 4411 5011 XCI	15.98	GAI 21181	USE 2187 3100 GASKT	.08
EAT1 42110	MS USE 4411 5501 MS	15.98	GAI 21210	USE 2130 3100 CASE	28.26
EAT1 42120	USE 4425 5011 XCI	5.66	GAI 21213	USE 2133 3100 BUSH	2.22
EAT1 42131	USE 4428 5010 CLAMP	1.32	GAI 21222	USE 2142 3100 HOLDR	.66
EAT1 45100	USE 4751 5020 CASE	7.20	GAI 21261	USE 09090 107 SEAL	1.08
EAT1 71410	USE 250 X 17 TR TIRE		GAI 21311	USE 2160 3100 COVER	14.12
EAT1 72150	USE 7411 5010 SPRKT	35.00	GAI 21411	USE 2151 3100 COVER	7.08
EAT1 72151	USE 7416 5010 SPRKT	5.80	GAI 21431	USE 2154 3100 COVER	.58
EAT1 72159	USE 0123 0816 BULT	.18	GAI 21441	USE 09516 101 STUD	.26
EAT1 73000	USE 7902 5010 EXT	2.26	GAI 21511	USE 2181 3100 GASKT	.26
GAI 00031	USE 6401 3030 METER	17.26	GAI 21512	USE 2183 3100 GASKT	.26
GAI 00046	USE 6615 3110 MARK	1.00	GAI 22100	USE 2300 3101 CLUTH	31.00
GAI 00047	USE 6615 3120 MARK	1.00	GAI 22110	USE 2310 3100 HUB	12.26
GAI 00140	USE 6460 3110 SEAT	38.28	GAI 22113	USE 2315 3100 BUSH	3.72
GAI 00141	USE 6581 3110 RACK	15.78	GAI 22114	USE 2317 3100 BOSS	2.22
GAI 00250	CFG USE 3260 3130 CFG	18.48	GAI 22115	USE 09062 101 ROLLR	.18
GAI 00250	CHG USE 3260 3130 CHG	18.48	GAI 22118	USE 2318 3100 WASH	.26
GAI 00354	CFG USE 8111 3120 CFG	8.52	GAI 22119	USE 2319 3100 WASH	.18
GAI 00354	CHG USE 8111 3120 CHG	8.96	GAI 22120	USE 2320 3100 BOSS	6.18
GAI 00358	USE 6102 3130 GRIP	9.58	GAI 22123	1 USE 2325 3101 SPRNG	.18
GAI 00362	USE 6115 3110 WIRE	3.96	GAI 22125	USE 2326 3100 PLATE	.66
GAI 00427	CHG USE 6811 3131 CHG	6.62	GAI 22126	USE 2327 3100 PLATE	1.16
GAI 00427	CFG USE 6811 3131 CFG	6.62	GAI 22127	USE 2328 3100 PLATE	1.32
GAI 00436	USE 3421 3110 BOLT	.92	GAI 22128	USE 09062 102 ROLLR	.18
GAI 00442	USE 6426 3110 PIVOT	1.32	GAI 22131	1 USE 2331 3101 SPRNG	.36
GAI 00457	USE 6104 5020 GRIP	11.28	GAI 22132	USE 2332 3100 SPRNG	.50
GAI 00458	USE 6102 3130 GRIP	9.58	GAI 22133	USE 2333 3100 WASH	2.16
GAI 00459	USE 6151 5020 COVER	3.12	GAI 22134	USE 09049 103 SHIM	.26
GAI 00461	LENS BLANK	1.48	GAI 22135	USE 09002 102 RING	.36
GAI 00463	USE GAI11 00463 WIRE	2.64	GAI 22136	USE 2335 3100 HOLDR	.26
GAI 00464	USE GAI11 00464 GRIP	7.66	GAI 22137	USE 2336 3100 SPRNG	.58
GAI 01220	NOT AVAILABLE	.00	GAI 22141	USE 2338 3100 COLLR	.26
GAI 08300	1 USE 3610 3100 CHG	6.18	GAI 22150	1 USE 2340 3101 HOUSE	6.18
GAI 08300	1 USE 3610 3100 CFG	6.18	GAI 22155	USE 2345 3100 RING	.36
GAI 10000	ENG HMS USE SC1321	220.00	GAI 22161	USE 2351 3100 ROD	.92
GAI 11111	USE 1111 3100 HEAD	7.98	GAI 22162	USE 2352 3100 RACE	1.32
GAI 11210	USE 1120 3100 CYLR	23.70	GAI 22163	USE 2353 3100 CLIP	.18
GAI 11311	USE 1131 3100 ADAPT	1.76	GAI 22164	USE 0611 0532 BALL	.08
GAI 11413	USE 1143 3100 GASKT	.18	GAI 22173	USE 2356 3100 SPACR	.50
GAI 11414	USE 1144 3100 GASKT	.18	GAI 22174	USE 2357 3100 NUT	.36
GAI 13100	USE 1301 3100 CRANK	31.00	GAI 22211	2 USE 2371 3102 CAM	2.66
GAI 13311	USE 07 6303 03BEAR	3.96	GAI 22221	USE 2373 3100 ARM	3.12
GAI 13411	USE 1336 3100 WASH	1.00	GAI 22222	USE 2374 3100 SHAFT	.58
GAI 14141	USE 09090 109 SEAL	1.16	GAI 22223	USE 2375 3100 ROLLR	.42
GAI 16100	2 USE 1600 3102 CARB	17.56	GAI 22224	USE 2376 3100 CLIP	.08
GAI 16105	2 USE 1640 3100 LEVER	2.22	GAI 22225	USE 2378 3100 SCREW	.42
GAI 16111	2 USE 1611 3102 BODY	12.72	GAI 22226	USE 09049 104 SHIM	.18
GAI 16112	NOT AVAILABLE	.00	GAI 22227	USE 09065 101 WASH	.08
GAI 16121	USE 1614 3100 VALVE	3.72	GAI 22228	USE 09011 101 BOLT	.36
GAI 16122	2 USE 1615 3102 JET	1.32	GAI 22229	USE 2379 3100 SPRNG	.18
GAI 16126	USE 1619 3100 TOP	1.32	GAI 22241	USE 2385 3100 COVER	1.00
GAI 16127	USE 1622 3100 ADJTR	.50	GAI 22242	USE 2386 3100 GASKT	.36
GAI 16129	USE 1624 3100 GUIDE	.82	GAI 23110	USE 2410 3100 GEAR	13.68
GAI 16130	USE 1625 3100 CAP	.82	GAI 23212	USE 2426 3100 GEAR	4.52
GAI 16144	NOT AVAILABLE	.00	GAI 23213	USE 2421 3100 SHAFT	9.80
GAI 16144	75 JET 75 NOT AVAILABL	.00	GAI 23215	USE 09006 102 RING	.18
GAI 16144	85 USE 1635 3010 85	1.08	GAI 23313	USE 2451 3100 GEAR	6.18
GAI 16144	90 JET 90 NUT AVAILABL	.00	GAI 23314	USE 2446 3100 SHAFT	6.90
GAI 16144	80 USE 1635 3000 80	1.08	GAI 23412	USE 2481 3100 SPACR	.50
GAI 16145	USE 1633 3100 JET	1.58	GAI 23413	USE 2486 3100 RING	1.66
GAI 16146	USE 1634 3101 JET	1.16	GAI 23414	USE 09041 109 WASH	.26
GAI 16164	USE 1648 3010 CLIP	.36	GAI 23415	USE 09006 103 RING	.26
GAI 16170	USE 1660 5010 VALVE	6.18	GAI 24111	USE 2511 3100 SHAFT	5.12
GAI 16173	USE 1665 3100 GASKT	.08	GAI 24150	USE 2554 3100 PLATE	2.22
GAI 16181	USE 1666 3100 FLOAT	2.90	GAI 24160	USE 2530 3100 STOP	1.26
GAI 16182	USE 1667 3100 PIN	.18	GAI 24170	USE 2556 3110 ARM	2.22
GAI 16183	USE 1656 3100 CHAMP	6.18	GAI 24180	1 USE 2555 3101 PLATE	2.22
GAI 16184	USE 1657 3100 PACK	.42	GAI 24210	USE 2510 3100 ARM	3.40
GAI 16193	USE 1652 5010 UNION	1.40	GAI 24310	USE 2520 3100 DRUM	7.08
GAI 16194	USE 1651 5000 BOLT	1.22	GAI 24312	USE 2549 3100 GUIDE	1.58
GAI 16196	USE 1654 3100 GASKT	.08	GAI 24324	USE 09049 105 SHIM	.08
GAI 17100	1 USE 1701 3101 MAC	33.74	GAI 25101	USE 2620 3100 SHAFT	7.08
GAI 17201	USE 1710 3100 PLATE	26.46	GAI 25110	USE 2620 3100 SHAFT	7.08
GAI 17211	USE 1712 3100 COIL	9.38	GAI 25200	USE 2680 3100 ARM	7.08
GAI 17251	USE 1755 5000 GRUM	.58	GAI 25211	USE 2681 3100 ARM	6.90
GAI 18211	0 USE 1821 3100 COVER	7.98	GAI 31100	USE 3110 3101 CHG	42.14
GAI 18311	USE 1841 3100 COVER	2.50	GAI 31100	USE 3110 3101 CCG	42.14
GAI 18312	USE 1842 3100 RUBBER	.18	GAI 31210	USE 3260 3130 CHG	18.48
GAI 18411	USE 1831 3100 COVER	3.40	GAI 31431	0 BULT CARRIER	.26

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
GA1 31432	USE 0411 1022 WASH	.08	GA1 65110	NOT AVAILABLE	.00
GA1 31433 0	WASHER ENGINE	.08	GA1 66111 CHW	USE 6610 3120 CHW	19.40
GA1 31433 1	USE 09541 104 WASH	.08	GA1 66111 CCG	USE 6610 3120 CCG	19.40
GA1 31434 0	RUBBER ENGINE	.26	GA1 66112	USE 6622 3100 STAY	.66
GA1 31434 1	USE 3378 3101 RUBBR	.26	GA1 66113	USE 6623 3100 BOLT	.28
GA1 31435 1	USE 3374 3101 BRCKT	.66	GA1 66114 0	USE 09064 102 GASKT	.08
GA1 31436 1	USE 3375 3101 HANGR	1.90	GA1 66115	USE 09541 105 WASH	.18
GA1 31437	USE 3378 3101 RUBBR	.26	GA1 66116	USE 6621 3100 STAY	.66
GA1 31438 2	USE 3376 3102 RUBBR	.36	GA1 66117	USE 6624 3100 NUT	.26
GA1 31439	USE 09525 104 NUT	.26	GA1 66118	USE 6615 3110 MARK	1.00
GA1 31440	USE 09516 101 STUD	.26	GA1 66211	USE 6711 3100 COVER	8.90
GA1 31441	USE 3382 3010 BUSH	.50	GA1 66213	USE 6731 3100 STOP	.08
GA1 31450	USE 3433 3100 LOCK	3.30	GA1 66221	USE 6721 3100 COVER	9.78
GA1 31459 621	USE 3435 3101 621	1.26	GA1 66231	USE 6732 3100 SPACR	.08
GA1 31459 622	USE 3435 3101 622	1.26	GA1 66232	USE 6733 3100 GROM	.08
GA1 31459 623	USE 3435 3101 623	1.26	GA1 66311 1	USE 6751 3101 CHG	1.58
GA1 31459 624	USE 3435 3101 624	1.26	GA1 67100	USE 3710 3100 CHG	5.12
GA1 31459 625	USE 3435 3101 625	1.26	GA1 67110 CFG	USE 3710 3100 CHG	5.12
GA1 31459 626	USE 3435 3101 626	1.26	GA1 67110 CHG	USE 3710 3100 CHG	5.12
GA1 31459 627	USE 3435 3101 627	1.26	GA1 68111	USE 6811 3131 COVER	8.62
GA1 31459 628	USE 3435 3101 628	1.26	GA1 68120	USE 6831 3100 KNUB	.76
GA1 31460	USE 3341 3100 CHG	3.72	GA1 69100 CFG	USE 3610 3100 CFG	6.18
GA1 42111 CFG	USE 4411 3100 CFG	7.08	GA1 69100 CHG	USE 3610 3100 CHG	8.18
GA1 42111 CHG	USE 4411 3100 CHG	7.08	GA1 82110 CHG	USE 8111 3100 CHG	6.70
GA1 42112	USE 4433 3100 WASH	.08	GA1 82115	USE 0411 0410 WASH	.08
GA1 43111 1	USE 4511 3101 BAR	6.90	GA1 84100	T SIG L H OLD STY	2.40
GA1 44100 1	USE 4601 3101 MRROR	3.72	GA1 84100 1	USE 8303 3101 LIGHT	2.40
GA1 44110	USE 4610 3100 MRROR	1.76	GA1 84111	USE 8371 3100 LENS	.46
GA1 44121 1	USE 4621 3101 STAY	.92	GA1 85100	T SIG R H OLD STY	2.40
GA1 44122	SET NUT MIRROR	.66	GA1 85100 1	USE 8304 3101 LIGHT	2.40
GA1 44140	USE 4622 3102 CLAMP	.76	GA1 85110 1	USE 8601 3100 SWTCH	5.12
GA1 44141	USE 0431 0820 WASH	.08	GA1 86100 1	USE 8601 3100 SWTCH	5.12
GA1 45100 CFG	USE 4701 3100 CFG	9.78	GA1 88100	USE 8810 3100 WIRE	7.02
GA1 45100 CHG	USE 4701 3100 CHG	9.78	GA1 88110	USE 8810 3100 WIRE	7.02
GA1 51110 CFG	USE 5110 3101 CFG	17.50	GA1 99000	USE 9300 3110 TOOLS	25.00
GA1 51110 CHG	USE 5110 3101 CHG	17.50	GA1 99111 0	CIRCLIP EXPANDER	2.40
GA1 51260	USE 5160 3100 CAP	2.22	GA1 99211 0	NOT AVAILABLE	.00
GA1 51271	USE 5171 3100 GASKT	.50	GA1 99212 0	RELEASE CAM ADJ G	1.22
GA1 52100	USE 5103 5000 COCK	3.40	GA1 99213 0	CLUTCH ADJ GAGE	.32
GA1 52211	USE 5172 3100 TUBE	.58	GA1 99311 0	PUSH RING SOCKET	.66
GA1 61100	USE 6102 3100 GRIP	8.90	GA1 99911 0	SPECIAL TOOL BAG	.92
GA1 61111 1	USE 6111 3101 CASE	1.90	GA11 00463	WIRE ASSY	3.30
GA1 61112	USE 6112 3100 PLATE	.42	GA11 00464	THROTTLE GRIP ASS	9.58
GA1 61113	USE 6113 3100 BUTTN	.18	GA11 61152	USE 8332 3110 BULB	.42
GA1 61114	USE 6114 3100 SPRNG	.18	GA11 61200	USE 6104 3120 GRIP	12.28
GA1 61120	USE 6115 3100 WIRE	4.38	GA11 61211	USE 6141 3110 HOLDR	3.40
GA1 61130	USE 6123 3100 GRIP	1.32	GA11 61220	USE 6145 3110 WIRE	5.42
GA1 61141 1	USE 6121 3101 COVER	1.58	GA11 61245	USE 6146 3110 CLAMP	.36
GA1 61142	USE 6116 3100 CLAMP	.36	GA2 00464	USE GA11 00464GRIP	7.66
GA1 61143	USE 6119 5000 KNUB	.36	GA2 83100	USE 8202 3110 LAMP	5.58
GA1 61144	USE 6117 3100 CLAMP	.36	GA2 83112	USE 8251 3110 LENS	1.76
GA1 61152	USE 8332 3100 BULB	.42	GA2 83114	USE 0342 0436 SCREW	.18
GA1 61153 1	USE 8331 3101 LENS	.50	GA2 96513	USE 0381 0830 SCREW	.16
GA1 61200	USE 6104 3100 GRIP	10.68	GA3 11613	USE 1381 3110 PIN	.82
GA1 61211 1	USE 6141 3101 HOLDR	3.40	GA3 24150	USE 2554 3110 PLATE	2.22
GA1 61220	USE 6145 3100 WIRE	4.08	GA3 24170	USE 2556 3110 ARM	2.22
GA1 61230	USE 6153 3100 GRIP	1.32	GA3 31450	USE 3433 3100 LOCK	3.30
GA1 61231	USE 6154 3100 PIPE	2.22	GA3 31459	USE 09525 104 NUT	.26
GA1 61232	USE 6155 3100 SHOE	.76	GA3 42441	USE 4435 5010 PLUG	.18
GA1 61233	USE 6156 3100 CABLE	.36	GA3 71110 0	USE 7111 3111 DRUM	20.52
GA1 61241 1	USE 6151 3101 COVER	1.76	GA3 71114	USE 7114 5000 PIPE	.50
GA1 61242	USE 6146 3100 CLAMP	.36	GA3 71117	USE 09590 104 SEAL	.92
GA1 61244	USE 6147 3100 CLAMP	.36	GA3 71134	USE 09590 105 SEAL	1.08
GA1 61260	USE 6152 3100 LEVER	1.98	GA3 71142	USE 7149 3110 CONN	.36
GA1 61261	USE 6124 3100 COLLR	.36	GA3 71150	USE 7140 3110 SHOE	4.02
GA1 61262	USE 0451 0510 WASH	.08	GA3 71161	USE 7145 3110 SPRNG	.30
GA1 61300	USE 8401 3030 METER	17.26	GA3 71171	USE 7151 3110 HUB	2.48
GA1 61313 0	EARTH WIRE	.26	GA3 71182	USE 7226 3110 COLLR	.66
GA1 61530	USE 6176 3100 CABLE	.66	GA3 71185	USE 7228 3110 CAP	.92
GA1 61532	USE 9411 3000 CABLE	1.08	GA3 71300	USE 7108 3110 SPUKE	3.40
GA1 61610	USE 3810 3100 PEDAL	6.18	GA3 71300	USE 7108 3110 EA	.16
GA1 62100	USE 6201 3100 CLEAN	5.12	GA3 72110	USE 7311 3111 HUB	28.80
GA1 62110	USE 6211 3100 ELEMT	3.40	GA3 72114	USE 7314 5000 PIPE	.66
GA1 62112	USE 6222 3100 COVER	2.66	GA3 72117	USE 09590 106 SEAL	.92
GA1 62113	USE 6241 3100 PIPE	1.98	GA3 72118	USE 09566 101 RING	.50
GA1 62115 CCG	AIR CAP GRAY	.50	GA3 72119 1	USE 7319 3111 DAMPR	1.08
GA1 62115 CHW	USE 6235 4100 CHW	.50	GA3 72131	USE 7371 3110 FLANG	7.72
GA1 63111 1	USE 6351 3101 PIPE	4.60	GA3 72132	USE 07 6203 03BEAR	3.22
GA1 63300	USE 6301 3100 MUFFR	14.12	GA3 72133	USE 09590 107 SEAL	1.00
GA1 63327 CFG	USE 3334 3100 CFG	4.08	GA3 72134	USE 09507 101 RING	.32
GA1 63327 CHG	USE 3334 3100 CHG	4.08	GA3 72141	USE 7376 5001 FLANG	3.92
GA1 64100	NOT AVAILABLE	.00	GA3 72142	USE 7377 3110 COLLR	1.36
GA1 64110	USE 6410 3000 SEAT	17.68	GA3 72143	USE 4861 3110 ADJTR	.98
GA1 65100	NUT AVAILABLE	.00	GA3 72144	USE 7379 3111 NUT	.76

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
GA3 72151	USE 7381 3110 SPRKT	5.80	GB1 31416	USE 3319 3200 CAP	.26
GA3 72153	USE 09511 112 BOLT	.18	GB1 31418	NUT USED	.00
GA3 72160	USE 7331 3111 PANEL	11.70	GB1 31419	OUR NOT AVAILABLE	.00
GA3 72171	USE 7351 3110 HUB	5.10	GB1 31433	USE 3315 3200 RACE	1.76
GA3 72181	USE 7421 3110 SHAFT	4.02	GB1 31436	USE 3324 3200 SHAFT	1.82
GA3 72182	USE 7426 3110 COLLR	1.20	GB1 31437	USE 3325 3200 STUP	.26
GA3 72184	USE 7422 3110 NUT	.72	GB1 31438	GUIDE	.26
GA3 72300	USE 7308 3110 SPOKE	4.46	GB1 31439	USE 09546 102 WASH	.42
GA3 72300	USE 7308 3110 EA	.16	GB1 31459	511 USE 3435 3200 511	1.76
GB1 11111	USE 1111 3200 HEAD	7.98	GB1 31459	512 USE 3435 3200 512	1.76
GB1 11211	USE 1121 3230 CYLDR	23.70	GB1 31459	513 USE 3435 3200 513	1.76
GB1 11411	USE 1141 3200 HEAD	.36	GB1 31459	514 USE 3435 3200 514	1.76
GB1 11413	USE 1143 3200 PACK	.26	GB1 31459	515 USE 3435 3200 515	1.76
GB1 13100	USE 1392 3210 CRANK	33.52	GB1 31459	516 USE 3435 3200 516	1.76
GB1 13151	USE 1321 3200 PIN	1.82	GB1 31459	517 USE 3435 3200 517	1.76
GB1 13152	NUT AVAILABLE	.00	GB1 31459	518 USE 3435 3200 518	1.76
GB1 13153	NUT AVAILABLE	.00	GB1 31459	519 USE 3435 3200 519	1.76
GB1 13210	USE 1331 3210 ROD	9.38	GB1 31459	520 USE 3435 3200 520	1.76
GB1 13320	USE 1305 3200 RINGS	3.80	GB1 31459	527 USE 3435 3200 527	1.76
GB1 13320	25 USE 1306 3200 25	3.80	GB1 31459	528 USE 3435 3200 528	1.76
GB1 13320	50 USE 1307 3200 050	3.80	GB1 31459	529 USE 3435 3200 529	1.76
GB1 13332	USE 1382 3200 CLIP	.08	GB1 31459	530 USE 3435 3200 530	1.76
GB1 13421	1 USE 1385 3201 GEAR	8.86	GB1 41000	CBK USE 4100 3200 CBK	82.06
GB1 14112	USE 1412 3210 VALVE	6.90	GB1 41000	OUR USE 4100 3211 OUR	85.70
GB1 14121	USE 1451 3200 COLLR	2.90	GB1 41100	1 USE 4111 3201 TUBE	16.62
GB1 14131	USE 1431 3200 COVER	6.40	GB1 41110	0 USE 4111 3201 TUBE	16.62
GB1 14141	USE 09090 109 SEAL	1.16	GB1 41110	1 USE 4111 3201 TUBE	16.62
GB1 16100	USE 1600 3210 CARB	19.40	GB1 41120	USE 4113 3200 TUBE	23.98
GB1 17111	USE 1791 3210 MAG	26.44	GB1 41171	USE 4121 3200 SPRNG	1.40
GB1 17212	USE 1713 3200 COIL	5.42	GB1 41172	USE 4122 3200 GUIDE	.76
GB1 17230	USE 1752 5000 POINT	4.08	GB1 41173	USE 4126 3200 NUT	1.16
GB1 17251	USE 1755 3200 GRUM	.58	GB1 41173	1 USE 4126 3201 NUT	1.16
GB1 17410	USE 875 NGK PLUG	1.30	GB1 41182	USE 4124 3200 BOLT	.58
GB1 18100	COOLING KIT	26.58	GB1 41183	USE 09546 103 WASH	.26
GB1 21110	USE 2110 3200 CASE	26.00	GB1 41220	USE 4133 3200 TUBE	16.46
GB1 21122	USE 07 6001 01 BEAR	2.98	GB1 41310	USE 4151 3200 BRDGE	13.20
GB1 21127	USE 2121 3200 STUD	.58	GB1 41321	USE 09511 124 BOLT	.76
GB1 21210	USE 2130 3200 CASE	29.20	GB1 41410	CBK USE 4171 3200 CBK	7.72
GB1 21213	USE 2133 3200 BUSH	1.36	GB1 41410	OUR USE 4171 3210 CUR	7.98
GB1 21222	USE 07 6005 01 BEAR	3.72	GB1 41420	CBK USE 4181 3200 CBK	7.72
GB1 21224	USE 2145 3200 HOLDR	.58	GB1 41420	OUR USE 4181 3210 CUR	7.98
GB1 21310	USE 2160 3200 COVER	26.10	GB1 41511	USE 4161 3200 BRDGE	14.40
GB1 21411	USE 242 34302 200	11.32	GB1 41521	USE 4162 3200 HOLDR	2.58
GB1 21412	USE 2152 3200 COVER	2.90	GB1 42221	DISCONTINUED	.00
GB1 21511	USE 2181 3200 PACK	.82	GB1 47110	OMB USE 4810 3200 MB	21.28
GB1 21512	USE 2183 3200 GASKT	.76	GB1 48100	CUR USE 4901 3200 CUR	13.68
GB1 21514	USE 2184 3200 PACK	.46	GB1 48100	OB USE 4901 3200 CBK	11.42
GB1 22111	USE 2221 3201 HUB	6.40	GB1 51110	OB USE 5110 3200 CBK	38.28
GB1 22112	USE 2210 3200 PLATE	3.88	GB1 51110	MB USE 5110 3200 MB	38.38
GB1 22122	USE 09041 110 WASH	.08	GB1 51110	OMB USE 5110 3200 MB	38.38
GB1 23110	USE 2411 3201 GEAR	24.50	GB1 51110	OUR USE 5110 3200 CUR	40.12
GB1 23211	USE 2421 3200 SHAFT	15.38	GB1 51211	USE 5141 3200 GRIP	2.30
GB1 23212	USE 2426 3200 GEAR	15.42	GB1 51212	USE 5142 3200 GRIP	2.30
GB1 23213	USE 2431 3200 GEAR	10.22	GB1 51300	USE 5102 3200 CAP	2.58
GB1 23214	USE 2436 3200 GEAR	6.40	GB1 61300	USE 8401 3210 METER	17.76
GB1 23215	USE 09002 104 RING	.26	GB1 62110	USE 6211 3200 CLEAN	5.42
GB1 23220	USE 2610 3200 GEAR	11.76	GB1 63111	USE 6351 3200 PIPE	6.18
GB1 23231	USE 2418 3200 BUSH	2.30	GB1 63123	1 USE 6361 3201 NUT	2.58
GB1 23232	USE 2419 3200 WASH	.36	GB1 63300	USE 6310 3200 MUFFR	18.96
GB1 23311	USE 2446 3200 SHAFT	11.56	GB1 63308	USE 6310 3200 MUFFR	18.96
GB1 23312	USE 2451 3200 GEAR	11.56	GB1 63313	USE 6320 3200 PIPE	4.22
GB1 23313	USE 2456 3200 GEAR	6.40	GB1 66410	USE 3610 5000 CBK	6.70
GB1 23314	USE 2461 3200 GEAR	18.98	GB1 66421	USE 3621 3200 TUBE	1.40
GB1 23315	USE 2466 3200 GEAR	6.40	GB1 67110	CBK USE 3710 3200 CBK	5.12
GB1 23316	USE 2616 3200 GEAR	6.48	GB1 69100	USE 9201 3201 TOOLS	5.42
GB1 23318	USE 2481 3200 SPACR	.66	GB1 71020	USE 7101 3200 WHEEL	32.84
GB1 23321	USE 2483 3200 COLLR	2.08	GB1 71130	USE 7130 3200 PANEL	13.20
GB1 24110	USE 2510 3201 SHAFT	7.20	GB1 71130	1 USE 7130 3201 PANEL	13.20
GB1 24210	USE 2502 3200 DRUM	9.70	GB1 71141	USE 7148 3201 GEAR	2.58
GB1 24212	USE 2522 3200 PIN	.40	GB1 72020	USE 7301 3200 WHEEL	36.48
GB1 24213	USE 2523 3200 STOP	.52	GB1 72131	USE 7371 3200 FLANG	12.62
GB1 24214	USE 2524 3200 HOLDR	.36	GB1 72151	USE 7381 3200 SPRKT	5.80
GB1 24215	USE 2541 3200 FORK	8.18	GB1 73000	USE 7501 3200 CHAIN	7.72
GB1 24216	USE 2544 3200 PIN	.82	GB1 86100	USE 8601 3200 SWTCH	6.88
GB1 24221	USE 2549 3200 PLATE	1.30	GB1 88300	USE 8802 3200 FUSE	1.00
GB1 24231	USE 2531 3200 STOP	.80	GB1 89510	USE 8702 5000 RECTR	3.56
GB1 25112	USE 2631 3200 GEAR	10.72	GB11 42110	USE 4410 3211 MS	9.58
GB1 25132	USE 2638 3200 SPACR	.82	GB11 42117	USE 4423 3210 MS	2.16
GB1 31100	OB USE 3110 3220 CBK	72.92	GB11 42118	USE 4424 3210 MS	2.30
GB1 31100	OUR USE 3110 3220 CBK	72.92	GB11 47110	OB USE 4810 3200 CBK	22.78
GB1 31320	USE 3331 3200 TUBE	3.88	GB11 47110	OUR USE 4810 3200 CUR	23.98
GB1 31411	USE 3314 3200 RACE	1.76	GB12 10000	ENG 50SP USE SC1324	316.00
GB1 31412	USE 3311 3200 RACE	1.76	GB12 11211	USE 1121 3230 CYLDR	23.70
GB1 31414	USE 3321 3200 NUT	1.40	GB12 13310	USE 1341 3230 PISTN	6.70

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
GB12 13310 25	USE 1342 3230 25	5.88	VM15 31	T USE 1627 5000 SCREW	.82
GB12 13310 50	USE 1343 3230 50	5.88	VM15 41	J USE 1615 3021 JET	1.48
GB12 91200	USE 6531 3220 RACK	11.96	VM15 42	P USE 1631 3010 SCREW	1.32
GB2 11111	USE 1111 3210 HEAD	7.98	VM22 140	USE 1634 3110 JET	1.32
GB2 11211	USE 1121 3220 CYLDR	23.70	BV26 22	USE 1667 3100 PIN	.18
GB2 11411	USE 1141 3210 GASKT	.36	M10 14	USE 1635 5000 110	1.16
GB2 13111	NUT USED	.00	M10 18E	USE 1654 3100 GASKT	.08
GB2 13112	NUT USED	.00	M12F 46A	USE 1632 3010 SPRNG	.26
GB2 13152	USE 1325 3210 BEAR	3.40	M21 14	USE 1622 5000 ADJTR	.58
GB2 13153	USE 09063 103 ROLLR	.08	M21 15	USE 1623 5000 NUT	.18
GB2 13211	USE 1331 3210 ROD	9.38	SML8 F	46A USE 1628 5000 SPRNG	.26
GB2 13212	USE 1333 3210 BEAR	3.88	W4 04	0 USE 0431 0410 WASH	.08
GB2 13320	USE 1305 3210 RINGS	3.80	C2 0414	USE 0311 0414 SCREW	.08
GB2 13320 25	USE 1306 3210 25	3.80	4N 00006	NUT AVAILABLE	.00
GB2 13320 50	USE 1307 3210 50	3.80	6N 00003	USE 0221 0300 NUT	.06
GB2 13413	USE 09063 104 ROLLR	.26	6N 00004	USE 0211 0400 NUT	.08
GB2 14110	USE 1412 3210 VALVE	6.90	6N 00005	USE 0211 0500 NUT	.08
GB2 14112	USE 1412 3210 VALVE	6.90	6N 00006	USE 0231 0600 NUT	.08
GB2 14121	USE 1451 3210 COLLR	2.90	6N 00008	USE 0231 0800 NUT	.08
GB2 41000 08	NUT USED	.00	6N1 00003	USE 0221 0300 NUT	.06
GB2 41000 OUR	USE 4100 3211 OUR	85.70	6N1 00004	USE 0211 0400 NUT	.08
GB2 41110	USE 4111 3210 TUBE	21.66	6N1 00005	USE 0211 0500 NUT	.08
GB2 41110 1	USE 4111 3211 TUBE	21.66	6N1 00006	USE 0222 0600 NUT	.08
GB2 41120	USE 4113 3210 TUBE	17.10	6N1 00008	USE 0211 0800 NUT	.08
GB2 41120 1	USE 4113 3211 TUBE	17.10	6N1 00010	USE 0231 1000 NUT	.08
GB2 41131	USE 4114 3210 TUBE	3.40	6N2 00006	USE 0222 0600 NUT	.08
GB2 41132	USE 09566 103 RING	.42	6N3 3	USE 0221 0300 NUT	.06
GB2 41133	USE 09590 109 SEAL	2.16	6N3 00010	USE 0231 1000 NUT	.08
GB2 41134	USE 4115 3210 SEAT	.26	6N3 00012	USE 0231 1200 NUT	.18
GB2 41161	USE 0111 0508 BOLT	.08	6B 3X10	USE 0121 0312 BOLT	.06
GB2 41162	USE 4118 3210 GASKT	.18	6B 3X12	USE 0121 0312 BOLT	.06
GB2 41171	USE 4121 3210 SPRNG	2.90	6B 4X10	USE 0121 0410 BOLT	.06
GB2 41172	USE 4122 3210 GUIDE	.66	6B 5 X 6	USE 0121 0506 BOLT	.06
GB2 41181	USE 09566 104 RING	.42	6B 5X8	USE 0121 0508 BOLT	.06
GB2 41182	USE 4124 8000 BOLT	.76	6B 5 X10	USE 0121 0510 BOLT	.06
GB2 41183	USE 09541 108 WASH	.08	6B 5 X12	USE 0113 0512 BOLT	.08
GB2 41210 0	USE 4131 3210 TUBE	21.66	6B 5 X16	USE 0111 0516 BOLT	.06
GB2 41210 1	USE 4131 3211 TUBE	21.66	6B 5 X18	USE 0111 0518 BOLT	.08
GB2 41251	USE 09511 125 BOLT	.76	6B 5X38	NUT AVAILABLE	.00
GB2 41310	USE 4151 3210 CBK	13.20	6B 6 X 8	USE 0112 0608 BOLT	.18
GB2 41410 OUR	USE 4171 3210 CUR	7.98	6B 6 X10	USE 0111 0610 BOLT	.08
GB2 41420 OUR	USE 4181 3210 CUR	7.98	6B 6 X14	USE 0112 0614 BOLT	.18
GB2 41511	USE 4161 3210 BRDGE	14.40	6B 6 X16	USE 0111 0616 BOLT	.06
GB2 99118	SPANNER FRONT FOR	3.38	6B 6 X18	USE 0111 0618 BOLT	.06
GB21 10000	ENG 605P USE SC1325	320.00	6B 6 X20	USE 0113 0620 BOLT	.08
GB21 11111	USE 1111 3210 HEAD	7.98	6B 6 X25	USE 0113 0625 BOLT	.08
GB21 13310	USE 1341 3220 PISTN	6.70	6B 6X30	USE 0111 0630 BOLT	.16
GB21 13310 25	USE 1342 3220 PISTN	6.70	6B 6 X65	USE 0111 0665 BOLT	.18
GB21 13310 50	USE 1343 3220 PISTN	6.70	6 8 6X8	0 USE 0311 0678 SCREW	.26
GB21 17100	USE 1790 3210 MAG	38.28	6B 8 X16	USE 0111 0818 BOLT	.16
GB21 17210	USE 1792 3210 FRAME	26.46	6B 8X18	USE 0111 0818 BOLT	.16
GB21 17213	USE 1714 3200 COIL	6.70	6B 8 X22	USE 0112 0822 BOLT	.16
GB21 17410	USE NGK B8S PLUG	1.30	6B 8 X25	USE 0111 0825 BOLT	.16
GB21 31100 08	USE 3110 3220 CBK	72.92	6B 8 X28	USE 0111 0830 BOLT	.18
GB21 31100 OUR	USE 3110 3220 CBK	72.92	6B 8X30	USE 0111 0830 BOLT	.18
GB21 31417	USE 3336 3210 STOP	1.40	6B 8 X32	USE 0111 0832 BOLT	.16
GB21 42111 XCI	USE 4410 3231 XCI	12.16	6B 8 X38	USE 0121 0838 BOLT	.10
GB21 42114	USE 4412 3220 XCI	1.76	6B 8 X50	USE 0122 0850 BOLT	.18
GB21 42117	USE 4423 3220 XCI	2.40	6B 8 X55	USE 0122 0855 BOLT	.18
GB21 42118 XCI	USE 4424 3220 XCI	2.58	6B 8 X62	USE 0113 0862 BOLT	.18
GB21 61300	USE 8401 3210 METER	17.76	6B 8 X65	USE 0121 0865 BOLT	.26
GB21 63111	USE 6351 3210 PIPE	6.18	6B 8 X88	USE 0113 0890 BOLT	.26
GB21 73000	USE 7501 3210 CHAIN	8.66	6B 8X102	USE 09511 115 BOLT	.26
VF14 SC6 19A	USE 1660 5010 VALVE	6.18	6B 8X104	USE 09511 103 BOLT	.26
VF14 T1 39	USE 1652 5010 CONN	1.40	6B 8X106	USE 09511 114 BOLT	.36
VF14 T2 08	USE 1651 5000 BOLT	1.22	6B 8X108	USE 09511 101 BOLT	.68
VM10 31A	USE 1616 3021 CLIP	.36	6B 8X114	USE 09511 113 BOLT	.36
VM13 21	USE 1633 3100 JET	1.58	6B 8X118	USE 09511 110 BOLT	.32
VM14 SC1 80	USE 1613 3020 CLAMP	.36	6B 8X128	USE 09511 110 BOLT	.32
VM14 SC4 16A	USE 1666 3100 FLOAT	2.90	6B 10X30	USE 0123 1030 BOLT	.22
VM14 C1 38A	USE 1617 3021 SEAT	.26	6B 10X40	USE 0123 1040 BOLT	.18
VM15 07A	USE 1665 3100 GASKT	.08	6B 10X10	4 USE 09511 102 BOLT	.32
VM15 12B	USE 1657 3100 PACK	.42	6BA 5 X14	USE 0113 0514 BOLT	.06
VM15 20	USE 0211 0500 NUT	.08	K6B 12X3	8 USE 09511 104 BOLT	.30
VM15 23A	USE 1614 5000 VALVE	3.86	K6N 3 12	USE 09521 103 NUT	.26
VM15 SC10 01	USE 1611 5000 BODY	14.26	KHW 8	USE 0411 0818 WASH	.08
VM15 SC4 85	USE 1645 5000 PLUNG	1.82	HW 00003	USE 0411 0308 WASH	.06
VM15 SC6 88	USE 1647 5000 CAP	1.00	HW 00004	USE 0411 0410 WASH	.08
VM15 SC6 89	USE 1646 5000 SPRNG	.26	HW 00005	USE 0411 0512 WASH	.08
VM15 24	USE 1618 5000 SPRNG	.58	HW 00006	USE 0411 0613 WASH	.08
VM15 25A	USE 1619 5000 TOP	2.30	HW 00008	USE 0411 0818 WASH	.08
VM15 26	USE 1621 5000 CAP	1.58	HW 00010	USE 0411 1022 WASH	.08
VM15 27	USE 1626 5000 ROD	.36	SW 00002	USE 0431 0205 WASH	.08
VM15 28A	USE 1656 5000 BODY	2.30	SW 00003	USE 0431 0307 WASH	.06

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
SW 00004	USE 0431 0410 WASH	.08	WP 2X20	USE 0551 2020 PIN	.08
SW 00005	USE 0431 0513 WASH	.06	WP 25X25	USE 0551 2525 PIN	.08
SW 00006	USE 0431 0615 WASH	.08	WP 3X18	USE 0551 3018 PIN	.08
SW 00008	USE 0431 0820 WASH	.08	WP 3X28	USE 0551 3028 PIN	.06
SW 00010	USE 0431 1025 WASH	.08	0111 0310	USE 0121 0312 BOLT	.06
SW 00012	USE 0431 1230 WASH	.08	0111 0312	USE 0121 0312 BOLT	.06
TW 00065	USE 0441 0611 WASH	.08	0111 0410	USE 0121 0410 BOLT	.06
BS 00006	USE 0451 0611 WASH	.08	0111 0506	USE 0121 0506 BOLT	.06
HW 00016	USE 09546 101 WASH	.10	0111 0508	HEX BOLT A	.08
WK 3X4	USE 0311 0304 SCREW	.06	0111 0512	USE 0111 0516 BOLT	.06
WK 3X6	USE 0311 0306 SCREW	.08	0111 0516	HEX BOLT	.06
PMK 3X4	USE 0311 0304 SCREW	.06	0111 0518	BOLT	.08
PMK 3 X 7	USE 0311 0306 SCREW	.08	0111 0520	USE 0113 0645 BOLT	.18
PMK 3X8	USE 0311 0309 SCREW	.06	0111 0522	USE 0113 0645 BOLT	.18
PMK 3 X 9	USE 0311 0309 SCREW	.06	0111 0530	HEX BOLT	.08
PNK 3 X 4	USE 0311 0304 SCREW	.06	0111 0608	USE 0112 0608 BOLT	.18
PNK 3X6	USE 0311 0306 SCREW	.08	0111 0610	HEXAGON BOLT A	.08
PNK 3 X 9	USE 0311 0309 SCREW	.06	0111 0612	USE 0113 0612 BOLT	.06
PNK 3 X10	USE 0311 0310 SCREW	.06	0111 0614	USE 0112 0614 BOLT	.18
PNK 3 X14	USE 0311 0314 SCREW	.06	0111 0616	HEX BOLT	.06
PNK 3X16	USE 0311 0316 SCREW	.06	0111 0618	BOLT	.06
PNK 4X6	USE 0311 0408 SCREW	.06	0111 0625	USE 0113 0625 BOLT	.08
PNK 4 X 8	USE 0311 0408 SCREW	.06	0111 0630	HEX BOLT	.16
PNK 4 X12	USE 0311 0412 SCREW	.08	0111 0632	HEX BOLT	.08
PNK 4 X14	USE 0311 0414 SCREW	.08	0111 0665	BOLT	.18
PNK 4X16	USE 0311 0416 SCREW	.06	0111 0812	HEXAGON BOLT A	.08
PNK 4X18	USE 0311 0418 SCREW	.06	0111 0816	USE 0111 0818 BOLT	.16
PNK 5X6	USE 0311 0506 SCREW	.06	0111 0818	HEX BOLT	.16
PNK 5 X 8	USE 0311 0508 SCREW	.06	0111 0825	HEX BOLT	.16
PNK 5X10	USE 0311 0510 SCREW	.08	0111 0830	HEX BOLT	.18
PNK 5 X12	USE 0311 0512 SCREW	.08	0111 0832	BOLT	.16
PNK 5 X14	USE 0311 0514 SCREW	.06	0111 0842	HEX BOLT A	.22
PNK 5 X16	USE 0311 0516 SCREW	.08	0111 0862	USE 0113 0862 BOLT	.18
PNK 5 X18	USE 0311 0518 SCREW	.06	0111 0890	USE 0113 0890 BOLT	.26
PNK 5X20	USE 0311 0520 SCREW	.08	0112 0608	HEXAGON BOLT A	.18
PNK 5X22	USE 0311 0522 SCREW	.06	0112 0614	HEXAGON BOLT A	.18
PNK 5 X65	USE 0311 0565 SCREW	.06	0112 0620	USE 0113 0620 BOLT	.08
PNK 6 X 6	USE 0311 0608 SCREW	.08	0112 0812	HEX BOLT	.18
PNK 6 X 8	USE 0311 0608 SCREW	.08	0112 0816	USE 0132 0816 BOLT	.08
PNK 6 X10	USE 0311 0610 SCREW	.08	0112 0818	USE 0111 0818 BOLT	.16
PNK 6 X12	USE 0311 0612 SCREW	.08	0112 0822	HEX BOLT	.16
PNK 6 X14	USE 0311 0614 SCREW	.08	0113 0512	HEXAGON BOLT A	.08
PNK 6 X15	USE 0311 0616 SCREW	.08	0113 0514	HEX BOLT	.06
PNK 6 X16	USE 0311 0616 SCREW	.08	0113 0612	HEXAGON BOLT A	.08
PNK 6 X18	USE 0311 0618 SCREW	.06	0113 0616	HEX BOLT A	.18
PNK 6 X20	USE 0311 0620 SCREW	.08	0113 0620	HEXAGON BOLT A	.06
PNK 6 X25	USE 0311 0625 SCREW	.08	0113 0625	HEXAGON BOLT A	.06
PNK 6 X32	USE 0311 0632 SCREW	.08	0113 0645	HEXAGON BOLT A	.18
PNK 6 X35	USE 0313 0635 SCREW	.08	0113 0662	HEX BOLT A	.18
PNK 6 X45	USE 0313 0645 SCREW	.08	0113 0862	HEXAGON BOLT A	.18
PNK 6 X50	USE 0313 0650 SCREW	.08	0113 0880	HEXAGON BOLT A	.26
PNK 6 X55	USE 0311 0655 SCREW	.16	0113 0890	HEXAGON BOLT A	.26
PNK 6X62	USE 0311 0662 SCREW	.16	0114 0862	USE 0113 0862 BOLT	.18
PNK 6 X65	USE 0311 0662 SCREW	.16	0121 0312	HEX BOLT	.06
PNK 6 X70	USE 0311 0670 SCREW	.26	0121 0410	HEX BOLT	.06
PNK 6 X78	USE 0311 0678 SCREW	.26	0121 0506	BOLT	.06
PNK 6X80	USE 0311 0678 SCREW	.26	0121 0508	HEX BOLT	.06
PNK 6X108	USE 09534 101 SCREW	.26	0121 0510	BOLT	.06
PNK 6X132	NUT USED	.00	0121 0628	HEX BOLT	.26
PRK 3X8	USE 0311 0309 SCREW	.06	0121 0838	BOLT	.10
PRK 3X10	USE 0342 0310 SCREW	.08	0121 0865	HEX BOLT	.26
PRK 3 X30	USE 0341 0330 SCREW	.08	0122 0832	USE 09511 125 BOLT	.76
PRK 3X55	USE 09534 102 SCREW	.08	0122 0845	HEXAGON BOLT B	.26
PRK 4X6	USE 0342 0406 SCREW	.06	0122 0850	HEX BOLT	.18
PRK 4X8	USE 0342 0408 SCREW	.06	0122 0855	HEX BOLT	.18
PRK 5 X10	USE 0342 0510 SCREW	.18	0122 0856	HEXAGON BOLT B	.26
PRK 5X12	USE 0342 0510 SCREW	.18	0122 1032	HEXAGON BOLT B	.26
PRK 5 X15	USE 0342 0515 SCREW	.06	0122 1065	HEXAGON BOLT B	.08
PRK 6X20	USE 0342 0620 SCREW	.06	0123 0640	USE 0311 0640	.08
PRK 6 X25	USE 0342 0625 SCREW	.08	0123 0641	NUT AVAILABLE	.00
PRK 6X108	USE 09534 101 SCREW	.26	0123 0816	HEX BOLT	.18
PSK 3X6	USE 0331 0305 SCREW	.06	0123 1030	HEX BOLT	.22
PSK 6 X14	USE 0331 0614 SCREW	.08	0123 1040	BOLT	.18
HK 5 X38	USE 0371 0535 SCREW	.16	0124 0838	USE 0121 0838 BOLT	.10
NK 2 X 6	USE 0361 0206 SCREW	.08	0124 0862	USE 0113 0862 BOLT	.18
NK 4 X 7	USE 0361 0407 SCREW	.06	0124 1032	USE 0122 1032 BOLT	.26
NK 4 X10	USE 0361 0410 SCREW	.06	0126 0838	USE 0121 0838 BOLT	.10
NK 4X12	USE 0361 0412 SCREW	.06	0126 0862	USE 0113 0862 BOLT	.18
NK 4X24	USE 0361 0424 SCREW	.06	0131 1028	HEX BOLT	.82
NK 5X10	USE 0361 0510 SCREW	.06	0131 1032	HEXAGON BOLT C	.82
SK 6X10	USE 0381 0610 SCREW	.06	0132 0816	HEXAGON BOLT C	.08
SK 8X30	USE 0381 0830 SCREW	.18	0133 0836	HEXAGON BOLT C	.82
WP 1X10	USE 0551 1010 PIN	.08	0134 0836	USE 0133 0836 BOLT	.82
WP 16X12	USE 0551 1612 PIN	.08	0141 0822	HEX BOLT U	.26

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
0142	0836	USE 0133 0836 BOLT	0342	0406	SCREW	.06
0142	0845	USE 0122 0845 BOLT	0342	0408	SCREW	.06
0142	1220	USE 09511 154 BOLT	0342	0436	OVAL HD SCREW	.18
0143	0816	USE 0123 0816 BOLT	0342	0510	SCREW	.18
0211	0300	USE 0221 0300 NUT	0342	0512	USE 0342 0510 SCREW	.18
0211	0400	HEXAGON NUT A	0342	0515	SCREW	.06
0211	0500	HEXAGON NUT A	0342	0620	SCREW	.06
0211	0600	USE 0222 0600 NUT	0342	0625	SCREW	.08
0211	0600	HEXAGON NUT A	0361	0206	SCREW	.08
0212	0800	USE 0211 0800 NUT	0361	0406	PAN HEAD SCREW	.06
0212	1000	HEXAGON NUT A	0361	0407	SCREW	.06
0221	0300	HEX NUT	0361	0408	SCREW	.08
0221	0500	USE 0211 0500 NUT	0361	0410	SCREW	.06
0221	0600	USE 0222 0600 NUT	0361	0412	SCREW	.06
0221	1000	USE 0231 1000 NUT	0361	0424	SCREW	.06
0222	0600	HEXAGON NUT B	0361	0510	SCREW	.06
0231	0500	USE 0211 0500 NUT	0371	0535	SCREW	.16
0231	0600	HEXAGON NUT C	0372	0330	SCREW	.08
0231	0800	HEXAGON NUT C	0381	0610	SCREW	.06
0231	1000	HEXAGON NUT C	0381	0830	CARRIER SCREW	.18
0231	1200	HEX NUT C	0411	0308	FLAT WASHER	.06
0231	1400	14MM HALF NUT	0411	0410	PLAIN WASHER A	.08
0232	0500	HEXAGON NUT C	0411	0512	PLAIN WASHER A	.08
0232	1200	HEX NUT C	0411	0613	PLAIN WASHER A	.08
0241	1000	USE 0231 1000 NUT	0411	0818	PLAIN WASHER A	.08
0241	1200	HEX NUT	0411	1022	PLAIN WASHER A	.08
0252	1200	USE 0232 1200 NUT	0411	1836	PLAIN WASHER A	.18
0252	1400	HEXAGON NUT E	0421	0408	PLAIN WASHER B	.08
0261	1000	10 HEX NUT	0421	0612	USE 0411 0613 WASH	.08
0311	0304	SCREW	0421	0816	PLAIN WASHER B	.08
0311	0306	3X6MM SCREW	0431	0205	SPRING WASHER	.08
0311	0309	SCREW	0431	0307	LOCK WASHER	.06
0311	0310	SCREW	0431	0410	SPRING WASHER	.08
0311	0314	SCREW	0431	0513	LOCK WASHER	.06
0311	0316	SCREW	0431	0615	SPRING WASHER	.08
0311	0408	SCREW	0431	0820	SPRING WASHER	.08
0311	0412	SCREW	0431	1025	SPRING WASHER	.08
0311	0414	SCREW	0431	1230	SPRING WASHER	.08
0311	0416	SCREW	0432	0510	USE 0342 0510 SCREW	.18
0311	0418	SCREW	0432	0513	USE 0431 0513 WASH	.06
0311	0506	SCREW	0432	0615	USE 0431 0615 WASH	.08
0311	0508	SCREW	0432	0820	USE 0431 0820 WASH	.08
0311	0510	SCREW	0432	1230	USE 0431 1230 WASH	.08
0311	0512	SCREW	0433	0615	USE 0431 0615 WASH	.08
0311	0514	SCREW	0441	0330	USE 0341 0330 SCREW	.08
0311	0516	SCREW	0441	0611	STAR WASHER	.08
0311	0518	SCREW	0441	1018	TOOTH WASHER	.08
0311	0520	SCREW	0441	1221	TOOTHED WASHER	.08
0311	0522	SCREW	0451	0510	EXT TOOTHED WASHE	.08
0311	0525	SCREW	0451	0611	TOOTH WASHER	.08
0311	0565	SCREW	0451	0815	EXT TOOTH WASHER	.08
0311	0606	USE 0311 0608 SCREW	0551	1010	SPLIT PIN	.08
0311	0608	SCREW	0551	1612	SPLIT PIN	.08
0311	0610	SCREW	0551	2018	SPLIT PIN	.08
0311	0612	SCREW	0551	2020	SPLIT PIN	.08
0311	0614	SCREW	0551	2025	SPLIT PIN	.08
0311	0615	USE 0311 0616 SCREW	0551	2525	SPLIT PIN	.08
0311	0616	SCREW	0551	3018	SPLIT PIN	.08
0311	0618	SCREW	0551	3025	SPLIT PIN	.08
0311	0620	SCREW	0551	3028	SPLIT PIN	.06
0311	0622	USE 0311 0625 SCREW	0552	1612	USE 0551 1612 PIN	.08
0311	0625	SCREW	0552	2535	USE 0552 2540 PIN	.08
0311	0630	SCREW	0552	2540	SPLIT PIN	.08
0311	0632	SCREW	0552	3018	USE 0551 3018 PIN	.08
0311	0635	USE 0313 0635 SCREW	0611	0104	BALL 1/4 IN	.08
0311	0640	SCREW	0611	0108	BALL	.08
0311	0645	USE 0313 0645 SCREW	0611	0316	3 16 BALL	.08
0311	0650	USE 0313 0650 SCREW	0611	0516	BALL 5 16	.08
0311	0655	SCREW	0611	0532	BALL	.08
0311	0662	SCREW	0611	0732	7-32 BALL	.08
0311	0665	USE 0311 0662 SCREW	0671	2510	WOODRUFF KEY	.26
0311	0670	SCREW	0671	3010	KEY ROTOR	.36
0311	0678	SCREW	0671	3013	3MM WOODRUFF KEY	.18
0313	0635	SCREW	1000	5001	USE SC 1355 ENGINE	390.00
0313	0645	SCREW	1000	5011	USE SC 1356 ENGINE	400.00
0313	0650	SCREW	1000	5400	NUT AVAILABLE	.00
0331	0305	SCREW	1000	8000	USE ESC1420 175 ENG	668.00
0331	0512	FLAT HEAD SCREW	1000	9000	USE SC 1518 ENGINE	894.00
0331	0612	SCREW	1111	3001	CYLINDER HEAD	6.38
0331	0614	SCREW	1111	3100	CYLINDER HEAD	7.98
0331	0616	NUT AVAILABLE	1111	3200	CYLINDER HEAD	7.98
0341	0330	SCREW	1111	3210	CYLINDER HEAD	7.98
0341	0355	USE 09534 102 SCREW	1111	5000	CYLINDER HEAD	17.10
0342	0310	SCREW	1111	5400	CYLINDER HEAD	24.90

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
1111	5410	CYLINDER HEAD	24.90	1307	3200	PISTON RING SET 5	3.80
1112	8000	LEFT CYLINDER HEA	25.08	1307	3210	PISTON RING SET 5	3.80
1112	8010	L CYLINDER HEAD	25.08	1307	5000	PISTON RING SET 5	3.72
1112	8200	L CYLINDER HEAD	25.08	1311	5000	NOT USED	.00
1112	9000	L CYLINDER HEAD	28.90	1311	5010	NOT USED	.00
1113	8000	RIGHT CYLINDER HE	25.08	1312	5000	NOT AVAILABLE	.00
1113	8010	R CYLINDER HEAD	25.08	1312	5010	NOT USED	.00
1113	8200	R CYLINDER HEAD	25.08	1313	8000	NOT USED	.00
1113	9000	R CYLINDER HEAD	28.90	1313	9000	L CRANKSHAFT A	22.22
1115	3000	USE 09021 104 NUT	.18	1314	8000	NOT USED	.00
1115	5000	NUT CYL HEAD	.50	1314	9000	L CRANKSHAFT B	24.92
1115	5400	CYL HEAD NUT	.42	1315	8000	NOT USED	.00
1115	8000	CYLINDER HEAD NUT	.58	1315	9000	NOT AVAILABLE	.00
1120	3000	CYLINDER BS7	18.88	1316	8000	NOT USED	.00
1120	3100	CYLINDER COMP	23.70	1316	9000	R CRANKSHAFT B	22.70
1121	3220	CYLINDER 60 SP	23.70	1317	8000	CRANKSHAFT SPACER	1.58
1121	3230	CYLINDER	23.70	1321	3200	CRANK PIN	1.82
1121	5010	USE 1121 5030 CYLDR	25.08	1321	5000	CRANK PIN	2.30
1121	5020	ALUM CYLINDER	53.22	1321	8000	CRANK PIN	2.88
1121	5030	CYLINDER C I	25.08	1321	9000	CRANK PIN	3.40
1121	5400	USE 1121 5410 CYLDR	65.76	1325	3210	NEEDLE BEARING	3.40
1121	5410	CYLINDER 100CC	65.76	1325	5010	NEEDLE BEARING	3.40
1122	8000	LEFT CYLINDER	49.32	1325	9000	NEEDLE BEARING	3.82
1122	8020	NOT AVAILABLE	.00	1326	5000	RETAINER	3.86
1122	8200	LEFT CYLINDER	49.32	1330	3200	USE 1331 3210 ROD	9.38
1122	9000	LEFT CYLINDER	68.04	1331	3210	CONNECTING ROD	9.38
1123	8000	RIGHT CYLINDER	49.32	1331	5010	CONNECTING ROD	10.98
1123	8020	RIGHT CYLINDER	49.32	1331	9000	CONNECTING ROD	13.60
1123	8200	RIGHT CYLINDER	49.32	1333	3210	NEEDLE BEARING	3.88
1123	9000	RIGHT CYLINDER	68.04	1333	5010	NEEDLE BEARING	3.88
1125	3000	EXH PIPE STUD	.18	1333	9000	NEEDLE BEARING	3.82
1126	5000	STUD CYL HEAD	.36	1334	3001	CON ROD BUSHING	.92
1126	5010	USE 09016 106 STUD	.42	1334	5000	BUSHING CONN ROD	1.00
1131	3020	CARB ADAPTOR	1.08	1336	3100	WASHER CON ROD	1.00
1131	3100	CARBURETOR ADAPTO	1.76	1337	9000	LABYRINTH PACKING	4.06
1141	3001	CYL HEAD GASKET	.50	1341	3003	PISTON STD	5.20
1141	3200	GASKET CYL HEAD	.36	1341	3220	PISTON STD	6.70
1141	3210	CYL HEAD GASKET	.36	1341	3230	PISTON STD	6.70
1141	5000	GASKET CYL HEAD	.42	1341	5000	PISTON STD	6.70
1141	5010	GASKET CYL HEAD	.42	1341	5010	PISTON 90SP & 175	6.70
1141	5400	CYLINDER HEAD GAS	.42	1341	5400	USE 1341 5410 PISTN	8.22
1141	5410	USE 1141 5400 GASKT	.42	1341	5410	PISTON 100CC	8.22
1141	8000	CYLINDER HEAD GAS	.58	1341	8000	USE 1341 5010 PISTN	6.70
1141	8010	HEAD GASKET AFT 1	.58	1341	8010	PISTON	6.70
1141	8200	HEAD GASKET	.58	1341	9000	PISTON	7.72
1141	9000	CYL HEAD GASKET	.86	1342	3001	PISTON 25 OS	5.20
1142	3000	EXH PIPE GASKET	.26	1342	3220	PISTON 025 OS	6.70
1142	5000	GASKET	.58	1342	3230	PISTON 025MM OS	5.88
1142	5400	EXH PIPE GASKET	1.12	1342	5000	PISTON 025MM OS	6.70
1142	9000	EXH PIPE GASKET	1.10	1343	3001	PISTON 50 OS	5.20
1143	3001	CYLINDER PACKING	.18	1343	3220	PISTON 050 OS	6.70
1143	3100	CYL BASE GASKET	.18	1343	3230	PISTON 050MM OS	5.88
1143	3200	CYL PACKING	.26	1343	5000	PISTON 050MM OS	6.70
1143	5000	PACKING CYLINDER	.26	1381	3000	PISTON PIN	1.08
1143	5400	CYL BASE GASKET	.26	1381	3110	PISTON PIN	.82
1143	8000	CYL BASE GASKET	.26	1381	5000	PISTON PIN	.82
1143	8200	CYL BASE GASKET	.36	1381	5400	PISTON PIN	2.02
1143	9000	CYL BASE GASKET	.42	1381	9000	PISTON PIN	1.36
1144	3001	CARB ADAPT PACKIN	.08	1382	3000	PISTON PIN CIRCLI	.08
1144	3100	CARB ADAPTOR GASK	.18	1382	3200	CIRCLIP PISTON PI	.08
1273	8000	USE 2173 8000 GROM	.18	1382	5000	PIN CIRCLIP	.08
1301	3001	CRANKSHAFT BS7D	28.90	1382	9000	CIRCLIP-PISTON PI	.08
1301	3011	CRANKSHAFT BS7S	28.90	1385	3000	PINION GEAR	3.72
1301	3100	CRANKSHAFT HMS	31.00	1385	3201	DRIVE PINION	8.86
1301	5010	CRANKSHAFT 90	47.94	1385	5000	PINION GEAR	6.72
1301	5410	NOT AVAILABLE	.00	1385	8000	DRIVE PINION	22.78
1301	8000	USE 1301 8002 CRANK	77.90	1385	9000	DRIVE PINION	9.06
1301	8001	USE 1301 8002 CRANK	77.90	1392	3210	CRANKSHAFT COMP	33.52
1301	8002	CRANKSHAFT-PINNED	77.90	1403	8000	USE 1430 8000 COVER	6.88
1301	8010	NOT AVAILABLE	.00	1404	8000	USE 1440 8000 COVER	15.92
1301	9000	CRANKSHAFT ASSY	107.02	1412	3210	ROTARY VALVE	6.90
1305	3000	PISTON RING SET S	3.40	1412	5010	ROTARY VALVE	6.90
1305	3200	PISTON RING SET S	3.80	1412	5600	USE 1412 5010 VALVE	6.90
1305	3210	PISTON RING SET S	3.80	1412	8000	ROTARY VALVE	5.42
1305	5000	PISTON RING SET S	3.72	1412	9000	ROTARY VALVE	5.58
1305	5010	PISTON RING	3.40	1413	8000	VALVE GUIDE	2.90
1305	5400	PISTON RINGS 100	3.80	1413	9000	VALVE GUIDE	1.92
1305	8010	PISTON RING	5.10	1415	8000	USE 1451 8000 COLLR	2.76
1305	9000	PISTON RING SET	4.10	1423	9000	L VALVE GUIDE	1.82
1306	3000	PISTON RING SET 2	3.80	1430	5010	ROTARY VALVE COVE	7.98
1306	3200	PISTON RING SET 2	3.80	1430	5020	VALVE COVER	7.98
1306	3210	PISTON RING SET 2	3.80	1430	5400	VALVE COVER	15.40
1306	5000	PISTON RING SET 2	3.72	1430	8000	ROTARY VALVE COVE	6.88
1307	3000	PISTON RING SET 5	3.80	1430	9000	R VALVE COVER	11.12

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
1431	3200	ROTARY VALVE COVE	6.40	1614	8000	THRUTTLE VALVE	4.60
1431	5000	ROTARY VALVE COVE	6.40	1614	9000	THRUTTLE VALVE	7.02
1431	5010	ROTARY VALVE COVE	10.70	1615	3021	JET NEEDLE	1.48
1431	5040	ROTARY VALVE COVE	7.72	1615	3102	JET NEEDLE	1.32
1431	8020	R VALVE COVER	6.88	1615	5010	JET NEEDLE	1.40
1440	8000	LEFT VALVE COVER	15.92	1615	9000	JET NEEDLE	1.98
1440	8001	LEFT COVER AFT 16	15.92	1616	3021	NEEDLE CLIP	.36
1441	8020	L VALVE COVER	15.92	1616	5010	NEEDLE CLIP	.36
1441	9000	L VALVE COVER	9.06	1616	9000	NEEDLE CLIP	.36
1451	3200	COLLAR CRANKSHAFT	2.90	1617	3021	SPRING SEAT	.26
1451	3210	COLLAR CRANKSHAFT	2.90	1617	5010	SPRING SEAT	.76
1451	5000	COLLAR CRANKSHAFT	3.72	1617	9000	SPRING SEAT	.76
1451	8000	CRANKSHAFT COLLAR	2.76	1618	3020	VALVE SPRING	.58
1501	5020	OIL PUMP ASSY	27.34	1618	5000	VALVE SPRING	.58
1501	5030	OIL PUMP ASSY	27.34	1618	5010	THROTTLE VLV SPRI	.58
1501	8000	OIL PUMP ASSY	33.74	1618	8000	THROTTLE VLV SPRI	.58
1501	8200	OIL PUMP 200CC	28.74	1618	9000	SPRING THROTTLE	.58
1501	9000	OIL PUMP ASSY	33.74	1619	3020	MIXING CHAMBER TO	.82
1502	8000	CHECK VALVE ASSY	2.90	1619	3100	MIXING CHAMBER TO	1.32
1502	9000	CHECK VALVE ASSY	3.72	1619	5000	MIXING CHAMBER TO	2.30
1513	5010	WORM SHAFT BUSH B	4.60	1619	5010	MIXING CHAMBER TO	1.40
1513	9000	WORM SHAFT BUSH	2.76	1619	9000	MIXING CHAMBER TO	1.76
1551	8000	PUMP GEAR A	2.90	1621	5000	MIXING CHAMBER CA	1.58
1552	5010	PUMP GEAR B	3.72	1621	5010	MIXING CHAMBER CA	1.40
1552	8000	PUMP GEAR B	5.12	1621	9000	MIXING CHAMBER CA	1.92
1552	9000	PUMP GEAR	4.10	1622	3020	CABLE ADJUSTER	.58
1555	5010	WORM SHAFT	9.06	1622	3100	CABLE ADJUSTER	.50
1555	9000	WORM SHAFT	4.10	1622	5000	CABLE ADJ	.58
1561	8000	USE 1561 8001 CASE	3.72	1623	3020	ADJ LOCK NUT	.08
1561	8001	GEAR CASE AFT 16R	3.72	1623	5000	LOCK NUT	.18
1562	8000	GEAR CASE GASKET	.18	1624	3100	CABLE GUIDE	.82
1563	5010	PUMP GASKET	.08	1625	3100	CABLE ADJ CAP	.82
1563	8000	PUMP GASKET	.08	1626	5000	THROTTLE STOP ROD	.36
1564	5010	UNION BOLT	.66	1626	5010	THROTTLE STOP ROD	.42
1564	8000	UNION BOLT	.68	1626	9000	THROTTLE STOP ROD	.36
1565	8000	UNION CONNECTOR	.58	1627	3021	THROTTLE STOP SCR	.66
1566	5010	OIL TUBE A	2.16	1627	5000	STOP SCREW	.82
1566	5011	OIL TUBE A	2.16	1627	5010	THROTTLE STOP SCR	.76
1566	8000	OIL TUBE A	.76	1628	3010	STOP SCREW SPRING	.36
1566	9000	OIL TUBE A	1.68	1628	5000	STOP SCREW SPRING	.26
1567	8000	OIL TUBE B	.76	1628	5010	STOP SCREW SPRING	.26
1567	9000	OIL TUBE B	1.68	1631	3010	PILOT AIR SCREW	1.32
1568	5010	CHECK BALL SPRING	.18	1631	5000	PILOT AIR SCREW	1.32
1569	5010	CHECK BALL SPRING	.18	1631	9000	PILOT AIR SCREW	1.36
1571	5010	UNION CONNECTOR B	1.00	1632	3010	SPRING AIR SCREW	.26
1571	5011	UNION CONNECTOR B	1.00	1632	9000	SPRING AIR SCREW	.26
1571	8000	USE 1571 5010 CONN	1.00	1633	3021	NEEDLE JET	1.90
1572	5010	UNION BOLT B	1.00	1633	3100	NEEDLE JET	1.58
1573	9000	OIL TUBE GROMMET	.26	1633	5010	NEEDLE JET	1.76
1574	8000	OIL TUBE D	.76	1633	5030	NEEDLE JET	1.76
1575	9000	UNION CONNECTION	.58	1633	5410	NEEDLE JET	1.76
1582	5011	USE 1582 5012 BRCKT	.82	1633	8000	NEEDLE JET	2.16
1582	5012	THREADED BRACKET	.82	1633	9000	NEEDLE JET	3.02
1582	9000	WIRE BRACKET	1.10	1634	3101	PILOT JET	1.16
1587	5010	ADJUST SCREW CAP	.36	1634	3110	PILOT JET	1.32
1591	8000	CAM COVER	1.40	1634	5000	USE 1634 3110 JET	1.32
1595	8000	USE 1591 8000 COVER	1.40	1634	5010	PILOT JET	1.76
1600	3005	CARBURETOR BS7	14.58	1634	8000	USE 1634 5010 JET	1.76
1600	3102	CARBURETOR	17.56	1634	9000	PILOT JET	1.26
1600	3210	CARBURETOR	19.40	1635	3000	70 NOT AVAILABLE	.00
1600	5000	15M CARB 100J 90S	19.40	1635	3000	80 MAIN JET NO 80	1.08
1600	5030	15M CARB 130J 90T	19.40	1635	3010	65 MAIN JET 65	1.08
1600	5070	USE 1600 5030 CARB	19.40	1635	3010	80 USE 1635 3000 80	1.08
1600	5080	17M CARB 110J 90S	29.92	1635	3010	85 MAIN JET 85	1.08
1600	5100	22M CARB 210J SPE	31.90	1635	5000	95 MAIN JET 95	1.16
1600	5110	18M CARB 130J 90S	29.92	1635	5000	100 MAIN JET 100	1.16
1600	5400	18M CARB 110J 100	29.92	1635	5000	110 MAIN JET 110	1.16
1600	5410	22M CARB 180J 100	31.90	1635	5000	120 MAIN JET 120	1.16
1600	8000	17M CARB 90J 175	27.32	1635	5000	130 MAIN JET 130	1.16
1600	8030	18M CARB 95J 175	27.32	1635	5000	140 MAIN JET 140	1.16
1600	8040	22M CARB 250J 175	31.90	1635	5000	150 MAIN JET 150	1.16
1600	8200	18M CARB 200CC	27.60	1635	5010	75 MAIN JET NO 75	1.16
1600	9000	26M CARB 150J 350	33.74	1635	5010	80 MAIN JET NO 80	1.16
1611	3021	CARB BODY	7.06	1635	5010	85 MAIN JET NO 85	1.16
1611	3102	CARBURETOR BODY	12.72	1635	5010	90 MAIN JET 90	1.16
1611	5000	CARB BODY 15MM	14.26	1635	5010	95 MAIN JET 95	1.16
1611	5010	CARB BODY	20.52	1635	5010	100 MAIN JET 100	1.16
1611	8010	USE 1600 8030 CARB	27.32	1635	5010	110 MAIN JET 110	1.16
1613	3020	CLAMP SCREW	.36	1635	5010	120 MAIN JET 120	1.16
1613	5010	CLAMP SCREW	.36	1635	5010	130 MAIN JET 130	1.16
1614	3021	THROTTLE VALVE	2.66	1635	5010	140 MAIN JET 140	1.16
1614	3100	THROTTLE VALVE	3.72	1635	5010	150 MAIN JET 150	1.16
1614	5000	THROTTLE VALVE	3.86	1635	5010	160 MAIN JET 160	1.16
1614	5010	THROTTLE VALVE	6.18	1635	5010	170 MAIN JET 170	1.16

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
1635	5010	180	MAIN JET 180		1.16
1635	5010	190	MAIN JET 190		1.16
1635	5010	200	MAIN JET 200		1.16
1635	5010	210	MAIN JET 210		1.16
1635	5010	220	MAIN JET 220		1.16
1635	5010	230	MAIN JET 230		1.16
1635	5010	240	MAIN JET 240		1.16
1635	5010	250	MAIN JET 250		1.16
1635	5010	260	MAIN JET 260		1.16
1635	5010	270	MAIN JET 270		1.16
1635	5010	280	MAIN JET 280		1.16
1635	5010	290	MAIN JET 290		1.16
1635	5010	300	MAIN JET 300		1.16
1636	9000		WASHER-JET		.18
1640	3012		STARTER LEVER COM		1.98
1640	3100		STARTER LEVER		2.22
1645	3010		STARTER PLUNGER		1.90
1645	5000		STARTER PLUNGER		1.82
1646	3010		PLUNGER SPRING		.36
1646	5000		PLUNGER SPRING		.26
1647	3010		PLUNGER CAP		.92
1647	5000		PLUNGER CAP		1.00
1647	5010		PLUNGER CAP		.92
1647	9000		PLUNGER CAP		1.00
1648	3010		PLUNGER CLIP		.36
1651	3200		USE 1651 5000 BOLT		1.22
1651	5000		CONNECTING BOLT		1.22
1651	5010		UNION BOLT		1.22
1652	3100		USE 1652 5010 UNION		1.40
1652	5010		UNION CONN		1.40
1654	3100		UNION GASKET		.08
1656	3021		FLOAT CHAMBER BOD		4.68
1656	3100		FLOAT CHAMBER		6.18
1656	5000		FLOAT CHAMBER BOD		2.30
1656	5010		FLOAT CHAMBER BOD		5.88
1656	8000		USE 1656 5010 BODY		5.88
1656	9000		FLOAT CHAMBER BOD		7.26
1657	3020		FLOAT CHAMBER GAS		.50
1657	3100		PACKING		.42
1657	5010		FLT CHAMBER GASKE		.58
1657	9000		GASKET FLOAT CHAM		.58
1658	3010		SET SPRING		1.26
1659	9000		SET SCREW		.08
1660	3010		FLOAT VALVE ASSY		6.18
1660	3100		USE 1660 5010 VALVE		6.18
1660	5010		FLOAT VALVE ASSY		6.18
1660	9000		FLOAT VALVE ASSY		7.02
1660	9010		FLOAT VALVE		7.02
1665	3100		VALVE GASKET		.08
1665	9000		VALVE SEAT GASKET		.08
1666	3020		FLOAT ASSY		2.40
1666	3100		FLOAT		2.90
1666	5010		FLOAT		3.16
1666	9000		FLOAT		3.62
1667	3020		FLOAT PIN		.26
1667	3100		FLOAT PIN		.18
1667	9000		FLOAT PIN		.18
1690	3210		JET SET 160 TO 20		3.90
1690	5010		JET SET 110 TO 15		3.90
1690	5020		USE 1690 3210 JET		3.90
1690	5025		USE 1690 8010 JET		3.16
1690	5030		JET SET 220 TO 26		4.10
1690	5410		JET SET 170-190-2		3.16
1690	8010		JET SET 240-60-70		3.16
1701	3014		FLYWHEEL MAGNETO		34.74
1701	3101		FLYWHEEL MAG ASSY		33.74
1701	5000		FLYWHEEL MAG ASSY		43.18
1702	3002		STARTER DYNAMO AS		67.20
1703	8000		A C DYNAMO ASSY		120.00
1703	8001		USE 1703 8002 DYNAMO		120.00
1703	8002		A C DYNAMO AFT 16		120.00
1703	8010		USE 1703 8002 DYNAMO		120.00
1703	9000		A C DYNAMO ASSY		120.00
1710	3011		MAGNETO PLATE		25.98
1710	3100		MAGNETO PLATE		26.46
1710	5000		MAGNETO FRAME		26.46
1712	3100		IGNITION COIL		9.38
1713	3200		IGNITION COIL		5.42
1713	5000		IGNITION COIL		5.66
1714	3010		LIGHTING COIL		6.08
1714	3200		LIGHTING COIL		6.70
1714	5000		LIGHTING COIL		6.70
1718	3013		MAGNETO FLYWHEEL		24.60
1718	5000		FLYWHEEL		25.44
1720	3001		STARTER ASSEMBLY		34.20
1721	3000		USE 1720 3001 STATR		34.20
1722	3001		CARBON BRUSH		1.48
1723	3001		BRUSH SPRING		.50
1725	3001		ROTOR		26.64
1726	3001		STARTER BOLT		1.16
1736	8000		CONTACT BREAKER C		6.40
1736	8001		CONTACT BREAKER C		6.40
1736	8010		BREAKER CAM AFT 1		6.40
1736	9000		CONTACT BREAKER C		6.40
1737	8000		O RING		1.98
1738	8000		GASKET		.42
1739	8000		CONT BREAKER COVE		.58
1739	8001		BREAKER COVER		.58
1739	8010		USE 1739 8001 COVER		.58
1741	8000		TIMING GEAR		21.66
1741	8010		TIMING GEAR AFT 1		6.90
1741	9000		TIMING GEAR		16.36
1742	8010		IDLE GEAR AFT 16G		11.42
1751	3001		BREAKER BASE		3.62
1751	8000		CONT BREAKER BASE		.76
1751	8001		BREAKER BASE		.76
1752	3001		CONTACT BREAKER		3.52
1752	5000		CONTACT BREAKER		4.08
1752	8000		L BREAKER BEF 16G		5.26
1752	8001		L CONTACT BREAKER		5.26
1753	3001		CONDENSER		2.30
1753	3010		CONDENSER		1.86
1753	5000		CONDENSER		2.90
1753	8000		CONDENSER BEF 16G		5.26
1754	3001		OIL FELT		.50
1754	3020		OIL FELT		.36
1755	3001		WIRE GROMMET		.36
1755	3200		WIRE GROMMET		.58
1755	5000		WIRE GROMMET		.58
1756	8010		L CONDENSER AFT 1		3.08
1757	8000		R BREAKER BEF 16G		5.26
1757	8001		R CONTACT BREAKER		5.26
1758	8010		USE 1756 8010 COND		3.08
1760	3002		NEUTRAL SWITCH		1.16
1761	5000		NEUTRAL SWITCH CA		.66
1761	8000		NUT AVAILABLE		.00
1761	8001		SWITCH CASE AFT 1		1.76
1761	9000		NEUTRAL SWITCH CA		1.78
1762	5000		CONTACT PLATE		.26
1762	8000		SWITCH PLATE BEF		.26
1762	8001		SWITCH PLATE AFT		.26
1763	5000		PACKING		.08
1763	8000		GASKET		.08
1764	5000		WIRE GROMMET		.58
1764	9000		GROMMET NEUTRAL W		.18
1767	8000		USE 1767 8001 CASE		1.76
1767	8001		NEUTRAL CHANGE CA		1.76
1768	8000		NEUT CHANGE PLATE		.26
1781	3002		USE NGK B6 PLUG		1.30
1781	3210		USE NGK B7S PLUG		1.30
1781	3221		USE NGK B8S PLUG		1.30
1781	5010		USE NGK B7HS PLUG		1.30
1781	5030		USE NGK B7HZ PLUG		1.30
1781	8000		USE NGK B8HS PLUG		1.30
1781	9000		USE NGK B9H PLUG		1.30
1785	3000		GROUND WIRE		.50
1785	3010		EARTH WIRE		.26
1790	3200		USE 1790 3210 MAG		38.28
1790	3210		FLYWHEEL MAG ASSY		38.28
1791	3200		USE 1791 3210 FLYWL		26.44
1791	3210		FLYWHEEL MAGNETO		26.44
1792	3200		USE 1792 3210 FRAME		26.46
1792	3210		FRAME ASSY		26.46
1794	8000		OIL FELT		.18
1795	8010		OIL FELT BRACKET		.32
1811	3003		FAN		10.30
1811	3010		FAN		3.62
1812	3002		FAN CAP		.36
1820	3011		FAN COVER		8.06
1821	3100		FAN COVER		7.98
1822	3000		FAN COVER CAP		1.48
1823	3000		STAY FAN COVER		.50
1831	3100		CYLINDER COVER A		3.40
1832	3100		COVER RUBBER A		.26
1841	3002		CYLINDER COVER		3.40
1841	3100		CYLINDER COVER B		2.50
1842	3100		COVER RUBBER B		.18
1843	3000		CYL COVER SPACER		.08

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
2101 8000	CRANK CASE ASSY	82.04	2160 5010	R CRANKCASE COVER	27.26
2101 8010	USE 2101 8011 CASE	117.02	2161 3002	TRANS CASE COVER	11.80
2101 8011	CRANKCASE AFT 16G	117.02	2161 5410	R CRANKCASE COVER	28.42
2101 8200	CRANK CASE 200CC	93.00	2161 8000	R CRANKCASE COVER	27.32
2101 9000	CRANKCASE ASSY	136.06	2161 8020	R CRANKCASE COVER	29.04
2110 3000	L CRANKCASE A BS7	22.92	2161 9000	USE 2161 9001 CASE	28.42
2110 3010	L CRANKCASE A BS7	23.06	2161 9001	R CASE COVER AFT	28.42
2110 3100	LEFT CRANK CASE	29.82	2162 5001	USE 2162 5002 PIPE	.82
2110 3200	LEFT CRANKCASE	26.00	2162 5002	DRAIN PIPE	.82
2110 5010	LEFT CRANKCASE CO	27.32	2162 9000	USE 2163 5010	.82
2110 5400	LEFT CRANKCASE	35.22	2163 5001	USE 2162 5002 PIPE	.82
2112 3000	SHAFT BUSHING	1.98	2163 5010	DRAIN FILTER	.82
2113 8000	FORK GUIDE PIN	.82	2163 9000	USE 2163 5010	.82
2113 9000	FORK GUIDE PIN	.82	2164 3001	OIL GAUGE	1.32
2114 8000	UPPER CASE PLUG	.66	2165 5000	OIL COCK	1.16
2115 9000	BUSHING START SHA	1.78	2165 8000	OIL FILLER PLUG	1.16
2116 8000	DYNAMO SPACER	.26	2166 9000	OIL GAUGE	1.10
2116 9000	DYNAMO SPACER	.58	2167 9000	OIL BAFFLE B	.58
2117 8000	DYNAMO SET BAND	1.40	2168 5000	12 RUBBER PLUG	.18
2117 9000	SET BAND DYNAMO	1.36	2171 8000	LEFT CARB COVER	4.38
2118 8000	DYNAMO SET PIN	.42	2171 8010	LEFT CARB COVER	15.28
2119 3001	BEARING HOUSING	2.66	2171 9000	L CARBURETOR COVE	5.82
2121 3100	CYL MOUNT STUD	.58	2172 8000	LEFT CARB CAP	4.38
2121 3200	CYLINDER STUD	.58	2172 9000	L CARBURETOR CAP	1.92
2121 5000	6X27 CYL STUD	.26	2173 8000	OIL TUBE GROMMET	.18
2121 5400	CYL MOUNTING STUD	.82	2174 8000	CARB CAP GUIDE	1.40
2121 8000	CYL MOUNTING STUD	.82	2175 5410	NOT AVAILABLE	.00
2121 9000	BEARING RETAINER	1.00	2175 9000	CARB ADJUSTER CAP	1.00
2122 8000	BEARING RETAINER	.82	2176 5000	CARBURETOR COVER	5.42
2122 9000	BEARING RETAINER	1.10	2176 5010	CARBURETOR COVER	14.80
2123 8000	BEARING RETAINER	1.58	2176 5020	CARBURETOR COVER	8.26
2123 9000	BEARING RETAINER	.82	2176 5410	CARBURETOR COVER	21.00
2124 8000	OIL SEAL RETAINER	.82	2176 8000	CARB COVER	3.88
2125 3001	OIL SEAL HOUSING	1.16	2176 8010	RIGHT CARB COVER	14.78
2125 9000	USE 2121 9000 RETAN	1.00	2176 9000	R CARBURETOR COVE	9.52
2126 3003	OIL SEAL HOLDER	.50	2177 5000	CARB RUBBER CAP	3.78
2128 8000	OIL BAFFLE PLATE	.82	2177 5010	CARB RUBBER CAP	3.40
2128 9000	OIL BAFFLE PLATE	1.00	2177 5020	CARBURETOR CAP	4.60
2129 3000	WIRE CLAMP	.08	2177 5410	CARB CAP	29.46
2129 3100	WIRE CLAMP	.26	2177 8000	CARB CAP	4.60
2130 3000	RIGHT CRANKCASE B	18.02	2177 9000	R CARBURETOR CAP	1.68
2130 3100	R CRANKCASE	28.26	2178 5000	SET RING	.36
2130 3200	CRANKCASE B	29.20	2178 5010	CARB CAP RING	.42
2130 5000	USE 2130 5001 CASE	27.78	2179 5000	RELEASE CAP	.36
2130 5001	R CRANKCASE B	27.78	2179 9000	RELEASE SCREW CAP	.36
2130 5010	RIGHT CRANKCASE C	27.78	2180 9000	COVER GROMMET	.66
2130 5400	RIGHT CRANKCASE	35.48	2181 3001	PACKING CRANKCASE	.26
2133 3100	DRIVE SHAFT BUSH	2.22	2181 3100	CRANKCASE GASKET	.26
2133 3200	BUSHING DRIVE SHA	1.36	2181 3200	CRANKCASE PACKING	.82
2133 5000	METAL DRIVING SHA	2.22	2181 5000	PACKING CRANKCASE	1.00
2133 8000	DRIVE SHAFT BUSH	.18	2181 5010	CRANKCASE GASKET	1.32
2133 8010	DRIVE SHAFT BUSH	3.62	2182 9000	L CARBURETOR GASK	.36
2133 9000	DRIVE SHAFT BUSH	3.88	2183 3001	CASE COVER GASKET	.18
2135 5000	BREATHER VINYL TU	.18	2183 3100	COVER GASKET	.26
2137 9000	8MM RUBBER PLUG	.36	2183 3200	CASE COVER GASKET	.76
2138 3001	BEARING CASE	2.16	2183 5000	PACKING TRANS CAS	1.00
2139 9000	8MM PLUG	.26	2183 5010	CRANKCAS COVR GAS	1.16
2141 3001	CYL STUD CRANKCAS	.50	2183 8000	GASKET	1.76
2142 3100	BEARING HOLDER	.66	2183 9000	CASE COVER GASKET	1.68
2145 3002	BEARING HOLDER	.36	2184 3200	PACKING MAG COVER	.46
2145 3200	BEARING HOLDER	.58	2184 5000	PACKING MAG COVER	.58
2145 5000	BEARING HOLDER	.66	2185 5000	PACKING CARB COVE	.50
2145 8000	USE 2145 8002 HOLDR	.76	2185 5010	CARB COVER GASKET	.50
2145 8001	USE 2145 8002 HOLDR	.76	2185 5410	CARB COVER GASKET	.50
2145 8002	BEARING HOLDER	.76	2185 8000	GASKET	.58
2149 8000	SET BAND WASHER	.36	2185 9000	CARB COVER GASKET	.58
2151 3003	FAN CASE	7.12	2186 3000	RELEASE GASKET	.08
2151 3100	LEFT CASE COVER	7.08	2186 5000	RELEASE GASKET	.08
2151 3200	USE 242 34302 200 CS	11.32	2186 9000	USE 2182 9000 GASKT	.36
2151 5020	LEFT CRANKCASE CO	16.38	2187 3100	BEARING GASKET	.08
2151 5030	USE 2151 5020 COVER	16.38	2188 3000	OIL GAUGE GASKET	.18
2151 8000	L CRANK CASE COVE	10.98	2189 5410	CARB CAP GASKET	.18
2151 9000	LEFT CASE COVER	9.52	2195 9010	USE 2180 9000 GROM	.66
2152 3200	MAGNETO COVER	2.90	2200 3000	CLUTCH ASSY	20.52
2152 5001	MAGNETO COVER	3.12	2210 3200	PRESSURE PLATE	3.88
2153 3001	DUST COVER	.58	2210 5000	PRESSURE PLATE	4.60
2153 5001	DUST COVER METAL	2.08	2210 8000	PRESSURE PLATE CO	4.60
2153 8000	DUST COVER A	7.98	2211 3001	PRESSURE PLATE	3.96
2153 9000	DUST COVER A	7.02	2211 9000	NOT AVAILABLE	.00
2154 3100	DUST COVER B	.58	2211 9001	PRESS PLATE AFT 2	9.52
2156 5000	RUBBER GEAR SHAFT	.36	2213 9000	SPRNG WASHER BEF	.42
2160 3100	CRANKCASE COVER	14.12	2214 3002	FRICTION PLATE	2.72
2160 3200	CRANKCASE COVER	26.10	2214 5000	CLUTCH FACING	2.16
2160 5000	TRANS CASE COMP	22.30	2214 8000	FRICTION PLATE	2.90

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
2214	8010	FRICITION PLATE	2.90	2386	3100	COVER GASKET	.36
2214	9000	FRICITION PLATE	5.88	2410	3100	DRIVEN GEAR	13.68
2214	9001	USE 2214 9000 PLATE	5.88	2410	5000	USE 2410 5001 GEAR	26.38
2215	3001	INNER PLATE	.66	2410	5001	GEAR AFT 12V	26.38
2215	5000	CLUTCH INNER PLAT	1.00	2410	8000	DRIVEN GEAR COMP	41.92
2215	8000	INNER PLATE	1.32	2410	8010	DRIVEN GEAR	41.92
2215	9000	INNER PLATE	1.36	2411	3002	DRIVEN GEAR	13.86
2216	3001	OUTER PLATE	.92	2411	3201	DRIVEN GEAR	24.50
2216	5000	CLUTCH OUTER PLAT	1.08	2411	5001	USE 2410 5001 GEAR	26.38
2216	9000	USE 2216 9001 PLATE	2.20	2411	9000	DRIVEN GEAR	36.26
2216	9001	OUTER PLATE	2.20	2412	9000	CLUTCH HOUSING	14.98
2216	9010	USE 2216 9001 PLATE	2.20	2418	3200	THRUST BUSHING	2.30
2218	3001	CLUTCH SPRING	.36	2419	3200	16 THRUST WASHER	.36
2218	5000	CLUTCH SPRING	.36	2421	3001	COUNTER SHAFT	7.28
2218	5010	CLUTCH SPRING	.36	2421	3100	COUNTER SHAFT	9.80
2218	9000	USE 2218 9001 SPRNG	.36	2421	3200	COUNTERSHAFT	15.38
2218	9001	CLUTCH SPRNG AFT	.36	2421	5000	COUNTER SHAFT	11.88
2219	9000	NOT AVAILABLE	.00	2421	5001	SHAFT AFT 12T	18.98
2220	3003	CLUTCH HUB	8.58	2421	8000	COUNTER SHAFT	17.08
2221	3201	CLUTCH HUB	6.40	2421	8010	COUNTER SHAFT	17.08
2221	5000	CLUTCH BRACKET	14.12	2421	9000	COUNTER SHAFT	22.70
2221	8000	CLUTCH HUB	6.88	2423	9000	SET SPACER SHAFT	.82
2221	9000	NOT AVAILABLE	.00	2424	5000	SPRING DRIVEN GEAR	.42
2221	9001	USE 2221 9002 HUB	12.20	2424	8000	DRIVEN GEAR SPRIN	.42
2221	9002	CLUTCH HUB AFT 21	12.20	2426	3002	SECOND GEAR A	4.56
2224	3000	SET RING	1.08	2426	3100	2ND GEAR A	4.52
2225	3000	WASHER SET RING	.66	2426	3200	SECOND GEAR A	15.42
2227	5000	SET PLATE COMP	.76	2426	5000	SECOND GEAR A	7.72
2227	8000	SET PLATE COMP	.82	2426	8000	2ND GEAR A	9.12
2231	3000	BALL RACE CLUTCH	.82	2426	9000	USE 2426 9001	15.18
2260	3003	RELEASE ARM	3.96	2426	9001	2ND GEAR A 25T	15.18
2260	5000	RELEASE ARM	1.82	2431	3004	3RD GEAR A	5.12
2260	9000	RELEASE ARM	4.10	2431	3200	THIRD GEAR A	10.22
2261	5010	RELEASE ARM	1.16	2431	5000	THIRD GEAR A	11.56
2261	9000	USE 2260 9000 ARM	4.10	2431	8000	3RD GEAR A	7.98
2264	5000	RELEASE SCREW	1.08	2431	9000	3RD GEAR A	14.28
2264	8000	RELEASE SCREW MET	1.42	2436	3200	4TH GEAR A	6.40
2264	9000	RELEASE SCREW	2.78	2436	5000	HIGH GEAR A	9.10
2265	3001	RELEASE SCREW	1.48	2436	8000	4TH GEAR A	9.12
2265	5000	PUSH SCREW	2.26	2441	8000	5TH GEAR A	7.98
2267	5000	USE 2267 8000 SCREW	.36	2441	8001	5TH GEAR A AFT 16	7.98
2267	8000	RELEASE ADJ SCREW	.36	2441	9000	5TH GEAR A	13.18
2268	5000	WASHER	.30	2443	9000	6TH GEAR A	13.38
2269	3000	SPRING HANGER	.36	2446	3005	DRIVING SHAFT	5.20
2271	3000	RELEASE ARM SPRIN	.36	2446	3100	DRIVE SHAFT	6.90
2271	5000	RELEASE SPRING	.36	2446	3200	DRIVE SHAFT	11.56
2271	5010	RELEASE ARM SPRIN	.36	2446	5000	DRIVE SHAFT BEF 1	7.06
2272	5000	GUIDE WASHER	.08	2446	5001	DRIVE SHAFT AFT 1	14.28
2273	9000	PUSH ROD A	3.28	2446	8000	DRIVE SHAFT	11.42
2274	9000	PUSH ROD B	1.00	2446	8001	DRIVE SHAFT AFT 1	11.42
2275	5010	RELEASE ARM PIN	.36	2446	8010	DRIVE SHAFT	11.42
2276	9000	CLUTCH WPKR HOLDE	.82	2446	9000	DRIVE SHAFT	14.50
2300	3101	CLUTCH ASSY	31.00	2451	3002	LOW GEAR B	4.30
2310	3100	CLUTCH HUB	12.28	2451	3100	1ST GEAR B	6.18
2315	3100	PINION BUSHING	3.72	2451	3200	LOW GEAR B	11.56
2317	3100	FREE WHEEL BASS	2.22	2451	5000	LOW GEAR B	11.56
2318	3100	FREE WHEEL WASHER	.26	2451	8000	1ST GEAR B	12.56
2319	3100	5 FREE WHEEL WASH	.18	2451	8010	1ST GEAR B	12.56
2320	3100	CLUTCH BASS	6.18	2451	9000	1ST GEAR B	12.50
2325	3101	CLUTCH RETURN SPR	.18	2452	3001	LOW GEAR BUSHING	1.76
2326	3100	INNER PLATE	.66	2456	3002	2ND GEAR B	4.30
2327	3100	OUTER PLATE	1.16	2456	3200	SECOND GEAR B	6.40
2328	3100	FRICITION PLATE	1.32	2456	5000	SECOND GEAR B	9.06
2331	3101	CLUTCH SPRING	.36	2456	8000	2ND GEAR B	9.98
2332	3100	PUSH PLATE SPRING	.50	2456	9000	2ND GEAR B	12.50
2333	3100	1 6 THRUST WASHER	2.16	2457	9000	BUSHING 2ND GEAR	1.36
2335	3100	SPRING HOLDER	.26	2461	3004	3RD GEAR B	6.18
2336	3100	PLATE SPRING	.58	2461	3200	THIRD GEAR B	18.98
2338	3100	FREE WEIGHT COLLA	.26	2461	5000	THIRD GEAR B	18.60
2340	3101	CLUTCH HOUSING	6.18	2461	8000	3RD GEAR B	10.22
2345	3100	CLUTCH SET RING	.36	2461	8001	3RD GEAR B AFT 16	10.22
2351	3100	PUSH ROD	.92	2461	9000	3RD GEAR B	19.52
2352	3100	BALL RACE	1.32	2466	3200	4TH GEAR B	6.40
2353	3100	PUSH ROD CLIP	.18	2466	5000	HIGH GEAR B	8.68
2356	3100	PINION SPACER	.50	2466	5001	USE 2466 5000 GEAR	8.68
2357	3100	CLUTCH NUT	.36	2466	8000	4TH GEAR B	6.88
2371	3102	RELEASE CAM	2.66	2466	8001	4TH GEAR B AFT 16	6.88
2373	3100	RELEASE ARM	3.12	2466	9000	USE 2466 9001	12.98
2374	3100	RELEASE ARM SHAFT	.58	2466	9001	4TH GEAR B 25T	12.98
2375	3100	RELEASE ROLLER	.42	2471	8000	5TH GEAR B BEF 16	7.98
2376	3100	RELEASE ARM CLIP	.08	2471	8001	5TH GEAR B AFT 16	7.98
2378	3100	ARM ADJ SCREW	.42	2471	8002	5TH GEAR B AFT 16	7.98
2379	3100	RELEASE ARM SPRIN	.18	2471	9000	5TH GEAR B	18.86
2385	3100	RELEASE COVER	1.00	2473	9000	6TH GEAR B	15.40

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
2476	3001	SHAFT SPACER	.50	2541	8000	SHIFT FORK A	6.40
2477	8000	RUBBER PLUG	.18	2541	9000	SHIFT FORK	7.66
2478	3001	DRIVEN GEAR BUSHI	1.58	2542	8000	SHIFT FORK B BEF	6.40
2478	5000	GEAR BUSH BEF 12T	2.40	2542	8001	SHIFT FORK B AFT	6.40
2479	3002	SHAFT SET BOLT	.66	2542	8010	SHIFT FORK B	6.40
2481	3002	SHAFT SPACER	.66	2544	3001	FORK GUIDE	.66
2481	3100	SHAFT SPACER	.50	2544	3200	GUIDE PIN AFT 12S	.82
2481	3200	DRIVE SHAFT SPACE	.66	2544	5000	GUIDE PIN BEF 12S	.36
2481	5000	COLLAR	.66	2544	8000	FORK GUIDE A	.82
2481	8000	DRIVE SHAFT SPACE	.76	2544	9000	FORK GUIDE	.82
2481	8001	SHAFT SPACER AFT	.76	2545	8000	FORK GUIDE ROLLER	1.16
2483	3003	SPROCKET SPACER	.66	2546	8000	FORK GUIDE B	.82
2483	3200	OIL SEAL COLLAR	2.08	2547	8000	FORK GUIDE SPRING	.26
2483	5000	OIL SEAL COLLAR	1.08	2548	8000	SPRING HOLDER	.08
2484	3001	DRIVE SPROCKET 13	4.90	2549	3003	THRUST RECEIVER	1.16
2484	3010	DRIVE SPROCKET	3.56	2549	3100	DRUM GUIDE PLATE	1.58
2484	5000	DRIVING SPROCKET	5.42	2549	3200	THRUST RECEIVER	1.30
2484	5010	DRIVE SPROCKET 12	4.42	2549	5000	THRUST REC BE 12	.92
2484	5400	DRIVE SPROCKET	8.68	2549	5001	THRUST RCVR	1.48
2484	5410	DRIVE SPROCKET 13	6.02	2549	9000	DRUM GUIDE PLATE	.42
2484	8000	DRIVE SPROCKET	5.42	2551	3001	SPRING OLD STYLE	.58
2484	8010	DRIVE SPROCKET 15	5.42	2551	3002	RETURN SPRING	.50
2484	8020	FT SPROCKET 14T	7.42	2551	5000	RET SPRING	.76
2484	8030	NOT AVAILABLE	.00	2552	3001	USE 2552 3002 WASH	.26
2484	8040	USE 2484 8000 SPRKT	5.42	2552	3002	WASHER 12MM	.26
2484	9000	DRIVE SPROCKET	10.42	2553	5000	STOPPER PIN	.92
2485	8000	SPROCKET SET PLAT	1.40	2554	3002	SHIFT PLATE	1.82
2485	8010	SET PLATE SPROCKE	1.40	2554	3100	SHIFT PLATE BEF 7	2.22
2485	9000	SPROCKET SET PLAT	.58	2554	3110	SHIFT PLATE AFT 7	2.22
2486	3000	PUSH RING	1.76	2555	3002	SHIFT PLATE STOPP	1.82
2486	3100	PUSH RING	1.66	2555	3101	STOPPER PLATE	2.22
2487	3000	END WASHER	.36	2556	3100	USE 2556 3110 ARM	2.22
2494	9000	NEEDLE BEARNG SPA	.82	2556	3110	SHIFT ARM AFT 7I	2.22
2502	3200	SHIFT DRUM	9.70	2557	8000	CHANGE SHAFT SPAC	.58
2502	5000	SHIFT DRUM BEF 12	8.90	2558	9000	FORK GUIDE STOPPE	.08
2502	5001	SHIFT DRUM AFT 12	22.78	2561	9000	DRUM STOPPER GASK	.08
2502	8000	SHIFT DRUM BEF 16	13.68	2571	8000	SHAFT	2.30
2502	8001	SHIFT DRUM AFI 16	13.68	2571	8001	5TH SHAFT AFT 16G	2.30
2502	8002	SHIFT DRUM AFT 16	13.68	2574	8000	LEVER	1.40
2510	3002	CHANGE ARM	4.46	2574	8010	SPORT SHIFT LEVER	1.76
2510	3100	CHANGE ARM	3.40	2575	8000	LEVER SHAFT	2.30
2510	3201	CHANGE SHAFT COMP	7.20	2576	8000	SHAFT RUBBER	1.76
2510	5000	CHANGE SHAFT BEF	7.20	2577	8010	NOT USED	.00
2510	5002	CHANGE SHAFT AFT	8.70	2580	9010	R CHANGE PEDAL	10.62
2510	8000	USE 2510 8001 ARM	7.20	2581	3012	GEAR CHANGE PEDAL	3.72
2510	8001	CHANGE ARM COMP	7.20	2581	5000	GEAR CHANGE PEDAL	5.12
2510	9000	CHANGE ARM COMP	8.82	2581	5010	SHIFT LEVER	5.78
2511	3001	CHANGE SHAFT	3.78	2581	5030	GEAR CHANGE PEDAL	5.12
2511	3100	CHANGE SHAFT	5.12	2581	8001	GEAR CHANGE PEDAL	5.12
2513	9000	DRUM SHIFTER	7.28	2581	8010	GEAR CHANGE PEDAL	8.16
2517	3001	DRUM SHIFTER SPRI	.18	2581	9000	GEAR CHANGE PEDAL	4.52
2517	5000	SHIFTER SPRING	.36	2582	5000	PEDAL RUBBER	.76
2520	3001	SHIFT DRUM	7.12	2582	9000	CHANGE PEDAL RUBB	1.00
2520	3100	SHIFT DRUM	7.08	2610	3200	KICK GEAR A	11.76
2520	9000	SHIFT DRUM	15.40	2610	5000	KICK IDLE GEAR A	14.02
2521	9000	USE 2520 9000 DRUM	15.40	2611	8000	KICK STARTER GEAR	7.98
2522	3001	SHIFT PIN	.18	2611	8010	STARTER GEAR A	7.98
2522	3200	SHIFT PIN AFT 16G	.40	2611	9000	STARTER GEAR A	5.28
2522	5000	SHIFT PIN	.18	2616	3200	KICK STARTER GEAR	6.48
2523	3200	SHIFT PIN STOPPER	.52	2616	5000	KICK GEAR B	3.86
2523	5000	SHIFT PIN STOPPER	.18	2616	8000	KICK STARTER GEAR	7.98
2524	3200	SHIFT PIN HOLDER	.36	2616	8010	STARTER GEAR B	7.98
2524	5000	SHIFT PIN HOLDER	.36	2616	9000	STARTER GEAR B	7.66
2524	8000	SHIFT PIN HOLDER	.26	2620	3000	KICK STARTER SHAF	3.78
2527	9000	USE 2520 9000 DRUM	15.40	2620	3100	KICK SHAFT	7.08
2528	9000	DRUM GUIDE BOLT	1.36	2621	3201	USE 2621 5002 SHAFT	6.40
2530	3000	DRUM STOPPER	1.16	2621	5002	KICK SHAFT AFT 12	6.40
2530	3100	DRUM STOPPER	1.26	2621	8000	KICK STARTER SHAF	7.20
2531	3200	DRUM STOPPER	.80	2621	9000	KICK STARTER SHAF	11.80
2531	5001	DRUM STOPPER	2.16	2630	9000	KICK STARTER GEAR	12.70
2531	8000	DRUM STOPPER ARM	1.00	2631	3001	STARTER GEAR C	4.00
2531	9000	DRUM STOPPER ARM	1.68	2631	3200	KICK STARTER GEAR	10.72
2532	9000	DRUM STOPPER ROLL	1.68	2631	5000	KICK GEAR C	15.68
2534	9000	DRUM STOPPER BOSS	3.88	2631	8000	KICK STARTER GEAR	10.22
2535	9000	STOPPER PLATE	1.52	2632	3004	STARTER RATCHET A	4.00
2536	5000	DRUM STOPPER BOLT	.78	2632	5000	RATCHET ARM	4.76
2536	8000	DRUM STOPPER BOLT	.42	2632	8000	RATCHET ARM	5.66
2537	5000	6MM COLLAR	.22	2633	3001	STARTER RATCHET	1.58
2538	3001	STOPPER SPRING	.26	2633	5000	RATCHET	1.58
2538	5000	STOPPER SPRING	.18	2633	8000	RATCHET	.26
2538	9000	SPRING DRUM STOPP	.18	2634	3000	RATCHET SPRING	.36
2541	3003	SHIFT FORK	6.40	2634	5000	RATCHET SPRING	.36
2541	3200	SHIFT FORK	8.18	2634	8000	RATCHET, SPRING	.26
2541	5001	SHIFT FORK	8.22	2635	3000	RATCHET STOPPER	.26

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
2635	5000	STOPPER RATCHET A	2.30	3315	3200	LOWER INNER RACE	1.76
2635	8000	RATCHET STOPPER	.82	3318	5000	BALL CAGE COMP	1.00
2635	9000	RATCHET STOPPER	.42	3319	3200	RACE CAP	.26
2636	3000	RETURN SPRING	.92	3319	5000	RACE CAP	.26
2636	5001	KICK RETURN SPRIN	1.16	3319	8000	RACE CAP	.26
2636	8000	RETURN SPRING	1.40	3321	3000	RACE LOCK NUT	.58
2636	9000	STARTER RETURN SP	1.36	3321	3200	RACE LOCK NUT	1.40
2637	3001	SPRING HOOK	1.58	3321	5000	LOCK NUT	.82
2638	3200	SPACER	.82	3322	3001	RACE ADJUSTER	1.32
2638	5000	USE 2638 3200 SPACR	.82	3322	5000	ADJ NUT	1.32
2638	9000	RETURN SPRING SPA	1.00	3323	3000	HEAD LOCK NUT	1.08
2642	8000	RATCHET POLE	.08	3324	3200	STEER SHAFT BEF 1	1.82
2643	8000	SPRING HOLDER	.36	3324	3201	STEER SHAFT AFT 1	1.82
2680	3010	USE 2680 3100 ARM	7.08	3325	3200	SHAFT STOPPER	.26
2680	3100	STARTER ARM ASSY	7.08	3331	3200	DOWN TUBE	3.88
2680	5000	KICK PEDAL ASSY	9.88	3331	5000	DOWN TUBE	5.42
2680	5610	USE 2680 5000	9.88	3331	5010	DOWN TUBE	5.42
2680	8000	KICK STARTER ARM	7.72	3334	3003	BLE MUFFLER BRACKET B	4.00
2680	9000	KICK STARTER ARM	13.38	3334	3003	CBK MUFFLER BRACKET B	4.00
2680	9010	R STARTER ARM	20.42	3334	3003	CUR MUFFLER BRACKET R	4.00
2680	9020	USE 2680 9000 ARM	13.38	3334	3100	CHG MUFFLER BRACKET G	4.08
2681	3010	KICK STARTER ARM	7.12	3334	3100	CFG MUFFLER BRACKET G	4.08
2681	3100	STARTER ARM	6.90	3334	5000	BRACKET MUFFLER	2.16
2681	5610	KICK STARTER ARM	6.90	3335	3000	RUBBER STOPPER	.18
2683	3010	USE 2683 3011 RUBBR	.36	3335	8000	RUBBER STOPPER	.26
2683	3011	PEDAL RUBBER	.36	3335	9000	STAND STOPPER	1.68
2683	9000	STARTER PEDAL RUB	.58	3336	3210	STAND STOPPER	1.40
2684	3010	USE 2684 5000 WASH	.26	3336	5010	STOPPER BRACKET	1.40
2684	5000	PEDAL WASHER	.26	3336	8010	STOPPER BRACKET	1.98
2685	9000	STARTER ARM BOSS	6.80	3336	9010	STAND STOPPER BRA	2.36
2686	9000	STARTER SET SPRIN	.18	3337	8000	BATTERY BAND SPAC	.18
2687	9000	STARTER SHAFT BOL	.68	3338	8010	OIL TANK BRACKET	.42
2688	9000	CHAIN GUIDE	1.00	3339	8010	OIL TANK PAD	.36
2690	3010	KICK PEDAL W RUBB	3.06	3339	9000	OIL TANK PAD	.42
2812	9000	TACHOMETER GEAR B	4.06	3341	3100	CHG BATTERY PLATE COM	3.72
2813	9000	BUSHING TACH GEAR	3.62	3342	5010	BATTERY CASE	13.80
2815	9000	BOLT TACH BUSHING	.18	3342	8000	BATTERY BRACKET	3.40
3110	3002	BLE FRAME BLUE	62.04	3342	8010	BATTERY BRACKET	1.98
3110	3002	CBK FRAME BLACK	62.04	3343	8000	BATTERY BRACKET P	.26
3110	3002	CUR FRAME RED	62.04	3344	8000	BATTERY BAND PIN	.42
3110	3040	CBK USE 3110 3040 CUR	62.04	3345	8000	BATTERY PAD	.42
3110	3040	CUR FRAME RED	62.04	3345	9000	BATTERY PAD	.82
3110	3101	CCG FRAME COMP GRAY	42.14	3346	8000	BATTERY SEAT	3.40
3110	3101	CHG FRAME COMP GREEN	42.14	3346	8010	BATTERY SEAT	.66
3110	3220	CBK FRAME BLACK	72.92	3346	9000	BATTERY SEAT	1.10
3110	3220	CUR USE 3110 3220 CBK	72.92	3347	8000	CBK TOOL BOX CAP BLK	1.40
3110	3270	CBK FRAME	72.92	3347	8000	FAR TOOL BOX CAP RED	1.40
3110	5000	CUR USE 3110 5070 FAR	87.50	3347	8010	TOOL BOX CAP	1.98
3110	5011	CBK FRAME BLACK	73.82	3348	8000	TOOL BOX BUTTON	.82
3110	5011	MB FRAME BLUE	73.82	3349	8000	TOOL BOX SPRING	.18
3110	5031	CBK FRAME COMP BLACK	82.04	3352	5600	TOOL BOX 100T	7.92
3110	5060	CBK FRAME 90D BLACK	73.80	3352	8000	FAR USE 3301 8000 FAR	5.26
3110	5060	MB FRAME 90T BLUE	73.80	3352	8000	OB USE 3301 8000 FAR	5.26
3110	5070	FAR FRAME 90SP RED	87.50	3353	3001	BATTERY BAND	.50
3110	5600	CBK FRAME 100T	106.10	3353	3011	BATTERY BAND	.50
3110	8000	FRAME COMP BLACK	96.62	3353	8000	BATTERY BAND	1.98
3110	8010	CBK FRAME COMP BLACK	96.62	3353	8010	NOT USED	.00
3110	9000	CBK FRAME COMP	145.12	3353	8020	BATTERY BAND	1.16
3130	5400	USE 2130 5400 CASE	35.48	3354	3001	TOOL BAND	.36
3137	3210	COVER GUIDE	.82	3354	5001	TOOL BAND	.50
3166	5010	SWITCH BRACKET	2.10	3358	9000	ENGINE CUSHION A	1.36
3166	9000	CBK MAIN SWITCH BRACK	1.00	3365	5600	CBK L ENGINE BRACKET	1.36
3259	9000	CBK FOOTREST BRACKET	2.52	3365	8000	L ENGINE BRACKET	.82
3260	3130	CHG REAR FENDER GREEN	18.48	3365	9000	CBK L ENGINE BRACKET	4.10
3260	3130	CFG REAR FENDER GRAY	18.48	3366	5600	CBK R ENGINE BRACKET	1.36
3260	5600	XCI REAR FENDER 100T	18.48	3366	8000	R ENGINE BRACKET	.82
3260	8000	REAR FENDER COMP	14.80	3366	9000	CBK R-ENGINE BRACKET	4.10
3260	8040	XCI REAR FENDER AFT 1	27.32	3367	3000	CUSHION RUBBER B	.66
3260	8050	MS REAR FENDER	22.70	3367	9000	ENGINE CUSHION B	1.68
3260	9000	REAR FENDER	29.46	3368	3001	SPACER A	.36
3266	5000	CUR DISCONTINUED	.00	3371	3001	ENGINE HANGER L	.50
3301	8000	CBK TOOL BOX BLACK	5.26	3371	9000	CBK L ENGINE HANGER	4.10
3301	8000	FAR TOOL BOX ASSY RED	5.26	3372	3001	ENGINE HANGER R	.50
3301	8010	XCI TOOL BOX ASSY	10.68	3372	9000	CBK R ENGINE HANGER	4.10
3301	9010	TOOL BOX ASSY	12.00	3373	9000	ENGINE MOUNT BOLT	1.00
3311	3200	OUTER RACE	1.76	3374	3101	CYL HEAD BRACKET	.66
3311	5000	OUTER RACE	1.32	3375	3101	CYL HEAD HANGER	1.90
3311	8000	OUTER RACE	1.76	3376	3102	CUSHION RUBBER D	.36
3312	3001	UPPER OUTER RACE	1.32	3378	3101	CUSHION RUBBER	.26
3313	5000	INNER RACE	1.40	3382	3010	BUSH B	.50
3313	8000	INNER RACE	1.76	3382	3100	USE 3382 3010 BUSH	.50
3314	3000	UPPER INNER RACE	1.58	3384	3000	COIL HOLDER	.26
3314	3200	UPPER INNER RACE	1.76	3386	9000	SPACER A	.58
3315	3000	LOWER INNER RACE	1.08	3387	3010	SEAT COLLAR B	.28

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
3388	5600	REAR FENDER CLAMP	3435	5010 913	ENGINE KEY NO 913	.66
3388	8000	REAR FENDER CLAMP	3435	5010 914	ENGINE KEY NU 914	.66
3388	9000	CLAMP REAR FENDEK	3435	5010 915	ENGINE KEY NO 915	.66
3389	5010	SPACE COLLAR	3435	5010 921	ENGINE KEY NO 921	.66
3411	3000	DISTANCE PIECE	3435	5010 922	ENGINE KEY NO 922	.66
3412	3000	GROMMET	3435	5010 923	ENGINE KEY NO 923	.66
3414	3003	PIVOT SHAFT	3435	5010 924	ENGINE KEY NU 924	.66
3414	5000	10X245MM BOLT	3435	5010 925	ENGINE KEY NO 925	.66
3414	5600	PIVOT SHAFT	3435	5010 926	ENGINE KEY NO 926	.66
3414	8000	PIVOT SHAFT	3435	5010 927	ENGINE KEY NO 927	.66
3414	8010	PIVOT SHAFT	3435	5010 928	ENGINE KEY NU 928	.66
3414	9000	PIVOT SHAFT	3435	5010 929	ENGINE KEY NO 929	.66
3415	3004	REAR CUSHION SHAF	3435	5010 930	ENGINE KEY NO 930	.66
3415	5000	10X200MM BOLT	3435	5010 949	ENGINE KEY NO 949	.66
3415	5010	10 X 230 BOLT	3435	5010 950	ENGINE KEY NO 950	.66
3416	5000	SET RUBBER TANK	3435	5010 951	ENGINE KEY NO 951	.66
3416	8000	TANK CUSHION RUBB	3435	5010 952	ENGINE KEY NO 952	.66
3417	5000	SET RUBBER	3435	5010 953	ENGINE KEY NO 953	.66
3417	9000	REAR TANK CUSHION	3435	5010 954	ENGINE KEY NO 954	.66
3418	5000	CBK USE 3418 5000 BRCKT	3435	5600	KEY 311	1.26
3418	5000	FAR USE 3418 5000 BRCKT	3435	5600	KEY 312	1.26
3418	5000	MB USE 3418 5000 BRCKT	3435	5600	KEY 313	1.26
3418	5000		3435	5600	KEY 314	1.26
3419	5000	FRONT SEAT BRACKE	3435	8010	KEY 101	1.26
3419	5000	TANK SET BOLT	3435	8010	KEY 102	1.26
3419	9000	TANK MOUNTING BOL	3435	8010	KEY 103	1.26
3421	3110	SEAT PIVOT BOLT	3435	8010	KEY 104	1.26
3422	5000	MS MUD FLAP METAL	3438	8010	NOT AVAILABLE	.00
3423	3001	SHAFT LOCK WASHER	3439	3200	NOT USED	.00
3424	3010	WIRE HARNESS STRA	3441	3001	CLAMP STIFFENER	.50
3425	3000	GROMMET STOP LIGH	3442	9000	FENDER MOUNT RUBB	.42
3426	8000	FENDER PROTECTOR	3443	3210	NUMBER PLATE SUPP	5.26
3427	5010	TOOL SET PAD	3444	8000	COVER BOLT	.42
3427	8000	TOOL SET PAD	3445	8000	LEFT COVER SPACER	.26
3428	5010	FRAME HANDLE	3445	8010	L COVER SPACER AF	.26
3428	8000	FRAME HANDLE	3446	8000	RIGHT COVER SPACE	.26
3428	8010	FRAME HANDLE	3447	8000	COVER PAD	.58
3428	9000	FRAME HANDLE	3447	9000	COVER PAD	.42
3429	3200	NOT USED	3448	8012	LEFT SEAT BOLT	.66
3433	3011	STEERING LOCK	3449	8012	RIGHT SEAT BOLT	.66
3433	3100	HANDLE LOCK	3451	5010	OIL TANK CUSHION	.82
3433	5000	STEERING LOCK	3451	9000	OIL TANK CUSHION	1.40
3433	5010	STEERING LOCK COM	3452	3210	SUPPORT PAD	.18
3433	8000	HANDLE LOCK	3471	9000	LEFT METER HOLDER	2.20
3434	3012	611 ENGINE KEY NO 611	3472	9000	RIGHT METER HOLDE	2.20
3434	3012	612 ENGINE KEY NO 612	3473	8200	MS SPEEDOMETER HOLDE	5.50
3434	3012	613 ENGINE KEY NO 613	3474	8200	SPEEDOMETER COVER	7.42
3434	3012	614 ENGINE KEY NO 614	3549	3200	USE 2549 3200 RECVR	1.30
3434	8000	721 ENGINE KEY NO 721	3610	3001	CBK MAIN STAND BLACK	5.66
3434	8000	722 ENGINE KEY NO 722	3610	3001	CUR MAIN STAND RED	5.66
3434	8000	723 ENGINE KEY NU 723	3610	3100	CFG MAIN STAND GRAY	6.18
3434	8000	724 ENGINE KEY NO 724	3610	3100	CHG MAIN STAND GREEN	6.18
3434	8000	725 ENGINE KEY NO 725	3610	5000	CBK STAND COMP BLACK	6.70
3434	8000	726 ENGINE KEY NO 726	3610	8000	MAIN STAND COMP	9.12
3434	8000	727 ENGINE KEY NO 727	3610	8010	CBK MAIN STAND COMP	9.10
3434	8000	728 ENGINE KEY NO 728	3610	9000	CBK MAIN STAND COMP	14.76
3434	8000	729 ENGINE KEY NO 729	3621	3002	MAIN STAND SHAFT	.66
3434	8000	730 ENGINE KEY NO 730	3621	3200	STAND TUBE	1.40
3434	8000	731 ENGINE KEY NO 731	3622	5000	SPRING GUIDE	.26
3434	8000	732 ENGINE KEY NO 732	3623	5000	PIN SPRING GUIDE	.08
3434	8000	733 ENGINE KEY NO 733	3624	3000	MAIN STAND SPRING	.66
3435	3101	621 ENGINE KEY NO 621	3624	5000	SPRING STAND	.26
3435	3101	622 ENGINE KEY NO 622	3624	8000	MAIN STAND SPRING	1.16
3435	3101	623 ENGINE KEY NO 623	3624	9000	SPRING MAIN STAND	1.36
3435	3101	624 ENGINE KEY NO 624	3625	8000	LEFT STAND BOLT	.42
3435	3101	625 ENGINE KEY NO 625	3625	9000	BOLT LEFT STAND	.82
3435	3101	626 ENGINE KEY NO 626	3626	8000	RIGHT STAND BOLT	.82
3435	3101	627 ENGINE KEY NO 627	3627	8000	MAIN STAND SPACER	.18
3435	3101	628 ENGINE KEY NO 628	3650	5000	SIDE STAND COMP	4.00
3435	3200	511 ENGINE KEY NO 511	3650	5600	SIDE STAND LOOT	6.06
3435	3200	512 ENGINE KEY NO 512	3650	8000	SIDE STAND COMP	5.66
3435	3200	513 ENGINE KEY NO 513	3650	9000	SIDE STAND COMP	5.82
3435	3200	514 ENGINE KEY NO 514	3662	5000	BOLT SIDE STAND	.50
3435	3200	515 ENGINE KEY NO 515	3662	8000	SIDE STAND BOLT	.58
3435	3200	516 ENGINE KEY NO 516	3663	5000	SPRING SIDE STAND	.58
3435	3200	517 ENGINE KEY NO 517	3663	8000	SIDE STAND SPRING	.58
3435	3200	518 ENGINE KEY NO 518	3663	9000	SPRING SIDE STAND	.58
3435	3200	519 ENGINE KEY NO 519	3664	9000	RUBBER SIDE STAND	.58
3435	3200	520 ENGINE KEY NO 520	3701	3001	CBK NOT AVAILABLE	.00
3435	3200	527 ENGINE KEY NO 527	3701	3001	CUR NOT AVAILABLE	.00
3435	3200	528 ENGINE KEY NO 528	3702	3020	REAR FOOTREST	1.48
3435	3200	529 ENGINE KEY NO 529	3702	5000	FOOT REST	1.82
3435	3200	530 ENGINE KEY NO 530	3702	8010	TANDEM FOOT REST	3.72
3435	5010	911 ENGINE KEY NO 911	3710	3001	CBK FOOTREST SHAFT BL	4.06
3435	5010	912 ENGINE KEY NO 912				

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
3710 3001	CUR FOOTREST SHAFT RE	4.06	4111 3210	OUTER TUBE L BEF	21.66
3710 3100	CHG FOOTREST COMP GRE	5.12	4111 3211	OUTER TUBE A	21.66
3710 3100	CFG USE 3710 3100CHG	5.12	4111 5001	MS OUTER TUBE L COMP	21.66
3710 3200	CBK FOOTREST SHAFT	5.12	4111 5011	MS OUTER TUBE A	21.66
3710 5000	CBK FOOT REST SHAFT C	5.80	4111 8000	MS OUTER TUBE A	29.62
3710 5020	CBK FOOT REST SHAFT	6.88	4111 9000	MS OUTER TUBE A	29.46
3711 5010	RUBBER SHAFT	1.82	4113 3200	INNER TUBE A	23.98
3715 5600	LEFT FOOTREST	5.28	4113 3201	INNER TUBE A	17.06
3715 8000	LEFT FOOT REST	5.12	4113 3210	INNER TUBE BEF 15	17.10
3715 9000	LEFT FOOT REST	5.06	4113 3211	INNER TUBE A	17.10
3716 5600	RIGHT FOOTREST	5.28	4113 5001	INNER TUBE COMP	15.98
3716 8000	RIGHT FOOT REST	5.66	4113 5010	INNER TUBE A	17.10
3716 9000	RIGHT FOOT REST	5.50	4113 8000	INNER TUBE A	19.40
3721 3002	FOOT REST RUBBER	1.30	4113 9000	INNER TUBE A	29.46
3722 5010	SPACE WASHER	.76	4114 3200	OUTER TUBE NUT	5.12
3723 5010	BOLT	.82	4114 3210	OUTER TUBE NUT	3.40
3725 3001	RUBBER STOPPER	.08	4114 5000	OUTER TUBE NUT	7.72
3726 5410	L FOOTREST SPRING	.58	4114 8000	OUTER TUBE NUT	7.08
3726 8010	L FOOT REST SPRIN	.58	4114 9000	OUTER TUBE NUT	11.60
3727 5410	R FOOTREST SPRING	.58	4115 3210	SPRING SEAT	.26
3727 8010	R FOOT REST SPRIN	.58	4115 5000	SPRING SEAT	.26
3728 9010	R FOOT REST SPACE	3.40	4115 9000	MAIN SPRING SEAT	.26
3762 5000	WASHER	.08	4116 3200	CUSHION BUSHING	1.32
3763 5000	PIN	.18	4116 5000	SLIDE BUSH METAL	1.00
3764 8010	FOOTREST SPACER	.76	4116 8000	CUSHION SLIDE MET	2.90
3765 5610	FOOTREST STOPPER	1.10	4116 9000	CUSH SLIDE BUSHIN	2.78
3765 9010	TANDEM FOOTREST S	3.36	4118 3210	DRAIN PLUG GASKET	.18
3810 3005	XCI BRAKE PEDAL	3.96	4118 5000	DRAIN PACKING	.08
3810 3100	BRAKE PEDAL	6.18	4121 3200	SPRING	1.40
3810 5001	USE 3810 5030 XCI	6.18	4121 3201	MAIN SPRING	2.58
3810 5021	BRAKE PEDAL	6.18	4121 3210	MAIN SPRING	2.90
3810 5030	XCI BRAKE PEDAL COMP	6.18	4121 5000	MAIN SPRING	3.40
3810 5410	BRAKE PEDAL COMP	5.66	4121 5010	SPRING FRONT FORK	3.78
3810 5600	BRAKE PEDAL 100T	6.06	4121 5600	MAIN SPRING 100T	2.78
3810 5610	BRAKE PEDAL COMP	7.42	4121 8000	FRONT CUSHION MAI	6.92
3810 8000	BRAKE PEDAL COMP	15.98	4121 9000	SPRING FRONT FORK	4.30
3810 8010	BRAKE PEDAL	15.98	4122 3200	SPRING GUIDE	.76
3810 9000	R BRAKE PEDAL	11.30	4122 3201	SPRING GUIDE	.76
3810 9010	L BRAKE PEDAL	28.46	4122 3210	MAIN SPRING GUIDE	.66
3811 8000	BRAKE PEDAL ARM	4.32	4122 5000	COVER GUIDE	.66
3821 3001	BRAKE PEDAL SPRIN	.18	4122 8000	MAIN SPRING GUIDE	1.00
3821 5000	RETURN SPRING	.26	4123 3200	INNER TUBE PACKIN	.58
3821 5600	BRAKE PEDAL SPRIN	.52	4123 5000	INNER TUBE PACKIN	.26
3821 8000	BRAKE PEDAL SPRIN	.58	4123 8000	INNER TUBE PACKIN	.58
3821 9000	SPRING BRAKE PEDA	.58	4124 3200	UPPER BRIDGE BOLT	.58
3821 9010	BRAKE PEDAL SPRIN	.66	4124 3201	USE 4124 8000 BOLT	.76
3822 8000	BRAKE PEDAL PIN	.58	4124 3210	UPPER BRIDGE BOLT	.76
3822 9000	PIN BRAKE PEDAL	.18	4124 5000	USE 4124 8000 BOLT	.76
3823 5410	RUBBER BRAKE PEDA	1.00	4124 8000	UPPER BRIDGE BOLT	.76
3831 3001	BRAKE ROD	1.08	4124 9000	UPPER BRIDGE BOLT	1.52
3831 5600	REAR BRAKE ROD	1.08	4125 8000	UPPER BRIDGE WASH	1.00
3832 3000	ADJ NUT	.26	4125 9000	UPPER BRIDGE WASH	.26
3833 3000	SPRING BRAKE ROD	.18	4126 3200	TUBE NUT BEF 13N	1.16
3833 8000	BRAKE ROD SPRING	.26	4126 3201	TUBE TOP NUT	1.16
3841 8000	REAR BRAKE WIRE	6.40	4127 3200	DUST SEAL	2.58
3841 9000	REAR BRAKE CABLE	5.06	4127 9000	DUST SEAL	1.36
3841 9010	L BRAKE CABLE	8.12	4128 3200	USE 09590 101 SEAL	.42
4100 3010	BLE FRONT FORK BLUE	43.40	4131 3200	OUTER TUBE B	16.02
4100 3010	CHG FRONT FORK GREEN	43.40	4131 3201	OUTER TUBE B	16.90
4100 3010	CFG FRONT FORK GRAY	43.40	4131 3210	OUTER TUBE BEF 15	21.66
4100 3010	CBK USE 4100 3010 CUR	43.40	4131 3211	OUTER TUBE B	21.66
4100 3010	CUR FRONT FORK RED	43.40	4131 5001	MS OUTER TUBE R COMP	21.66
4100 3200	CBK FRONT FORK BLACK	82.06	4131 5011	MS OUTER TUBE B	21.66
4100 3201	CBK FRONT FORK BLACK	85.70	4131 8000	MS OUTER TUBE B	28.50
4100 3201	CUR RED NOT AVAILABLE	.00	4131 9000	MS OUTER TUBE B	29.46
4100 3210	CBK NOT USED BLACK	.00	4133 3200	INNER TUBE B	16.46
4100 3211	CBK NOT USED	.00	4133 3201	INNER TUBE B	17.06
4100 3211	OUR FRONT FORK ASSY	85.70	4151 3200	LOWER BRIDGE	13.20
4100 5000	OMB FORK BLUE	100.26	4151 3201	LOWER BRIDGE	19.40
4100 5000	CBK FORK BLACK	100.26	4151 3210	CBK LOWER BRACKET	13.20
4100 5000	FAR USE 4100 5020 FAR	101.36	4151 3220	CBK LOWER BRIDGE	13.20
4100 5000	CUR USE 4100 5020 FAR	101.36	4151 5000	CBK LOWER BRACKET	3.62
4100 5020	FAR FRONT FORK C A RE	101.36	4151 8000	CBK LOWER BRIDGE	32.84
4100 5020	MB FRONT FORK M BLUE	100.28	4151 9000	CBK LOWER BRIDGE	30.62
4100 5600	MB FRONT FORK 100T	116.08	4153 8000	WIRE CLAMP	.26
4100 5600	MS F FORK 100TMX BEF	116.08	4161 3200	UPPER BRIDGE	14.40
4100 5610	MS F FORK TMX AFT22P	116.08	4161 3201	UPPER BRIDGE	7.98
4100 8000	CBK FRONT FORK ASSY B	136.76	4161 3210	UPPER BRIDGE	14.40
4100 8000	FAR FRONT FORK ASSY R	136.76	4161 3220	UPPER BRIDGE AFT 22 P	14.40
4100 8000	MS FRONT FORK ASSY	136.76	4161 5000	UPPER BRACKET	13.68
4100 9000	FRONT FORK ASSY	159.64	4161 5010	UPPER BRIDGE 7/8	14.36
4111 3200	USE 4111 3201 TUBE	16.62	4161 8000	UPPER BRIDGE	17.06
4111 3201	OUTER TUBE	16.62	4161 9000	UPPER BRIDGE	21.52
4111 3202	OUTER TUBE A	16.90	4162 3200	HANDLE HOLDER	2.58

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST				
4162	3201	HANDLE HOLDER	2.58	4316	8000	RETAINING PLATE	.58		
4162	3210	H HOLDER AFT 22P	2.58	4318	8000	PRESSURE PLATE	.42		
4162	5000	HANDLE HOLDER	4.22	4319	8000	DAMPER SPRING	.82		
4162	5010	HANDLE HOLDER 7/8	8.12	4321	8000	DAMPER SPRING GUI	.82		
4162	8000	HANDLE HOLDER	1.40	4322	9000	DAMPER GUIDE PLAT	.42		
4164	5000	STEERING HEAD NUT	4.00	4410	3211	MS	FRONT FENDER	9.58	
4164	8000	STEERING HEAD NUT	2.90	4410	3231	XCI	FRONT FENDER CHRO	12.16	
4164	9000	STEERING HEAD NUT	4.52	4410	5002	CBK	MUDGUARD BLACK	15.90	
4165	5000	CAP NUT WASHER	.50	4410	5010	MS	NOT AVAILABLE	.00	
4166	3201	LWER HOLDER	2.58	4410	5011	XCI	USE 4410 5012 XCI	15.98	
4171	3200	CBK	LEFT FORK COVER	7.72	4410	5012	XCI	FRONT FENDER	15.98
4171	3201	CBK	LEFT FORK COVER	9.12	4411	3000	CBK	FRONT FENDER BLAC	10.90
4171	3201	CUR	LEFT FORK COVER	9.12	4411	3000	CUR	FRONT FENDER RED	10.90
4171	3201	OUR	NUT AVAILABLE	.00	4411	3100	CHG	FRONT FENDER GREE	7.08
4171	3201	MS	USE 4171 5600 MS	9.02	4411	3100	CFG	FRONT FENDER GRAY	7.08
4171	3210	CBK	L FORK COVER	9.12	4411	5011	XCI	FRONT FENDER	15.98
4171	3210	CUR	LEFT FORK COVER R	7.98	4411	5501	XCI	USE 4411 5011 XCI	15.98
4171	5000	OMB	LEFT FORK COVER B	7.98	4411	5501	MS	FRONT FENDER PAIN	15.98
4171	5000	CBK	LEFT FORK COVER B	7.98	4411	5600	XCI	FRONT FENDER 100T	9.52
4171	5000	FAR	L FORK COVER C A	14.80	4411	8000		FRONT FENDER	14.80
4171	5000	CUR	USE 4171 5000 FAR	14.80	4411	8010		USE 4411 8011 FENDR	11.42
4171	5600		L FORK COVER	6.96	4411	8011		FRONT FENDER AFT	11.42
4171	5600	MS	LEFT FORK COVER	9.02	4411	8030		FRONT FENDER	14.80
4171	8000	FAR	LEFT FORK COVER R	6.26	4411	8040	MS	FRONT FENDER	12.50
4171	8000	OB	USE 4171 8000 MS	6.26	4411	9000	XCI	FRONT FENDER	13.60
4171	8000	MS	LEFT FORK COVER	6.26	4411	9010		FRONT FENDER	12.90
4171	9000	XCI	LEFT FORK COVER	8.16	4412	3220	XCI	FENDER STAY A	1.76
4174	5600		FORK COVER GUIDE	1.92	4412	8010		FENDER BRACKET	4.66
4174	8000		FORK COVER GUIDE	3.40	4412	8020		FENDER BRACKET AF	4.66
4174	9000		FORK COVER GUIDE	2.78	4412	9000		FENDER BRACKET A	5.82
4176	5600		FORK BOOT BAND	2.36	4412	9010		FRONT FENDER BRAC	6.98
4177	5600		FRONT FORK BOOT	6.28	4421	5000	CBK	STAY L COMP BLACK	2.40
4177	8000		FRONT FORK BOOT	5.12	4421	5010		STAY LEFT COMP	2.30
4177	9000		BOOT FRONT FORK	4.30	4421	5610		L FENDER STAY	2.78
4178	5600		BOOT HOLDER UPPER	1.36	4422	5000	CBK	STAY R COMP BLACK	2.40
4178	8000		BOOT HOLDER UPPER	1.16	4422	5010		STAY RIGHT	2.40
4178	9000		UPPER BOOT HOLDER	.58	4422	5610		R FENDER STAY	2.96
4179	8000		BOOT HOLDER LOWER	.82	4423	3210	MS	FENDER STAY A	2.16
4181	3200	CBK	RIGHT FORK COVER	7.72	4423	3211	MS	FENDER STAY A	2.16
4181	3201	CUR	RIGHT FORK COVER	9.12	4423	3211		USE 4423 3211 MS	2.16
4181	3201	CBK	RIGHT FORK COVER	9.12	4423	3220	XCI	FENDER STAY B	2.40
4181	3201	OUR	NUT AVAILABLE	.00	4423	3221	XCI	FENDER STAY A	2.40
4181	3201	MS	USE 4181 5600 MS	9.02	4423	5010		FENDER STAY A	2.22
4181	3210	CBK	R FORK COVER	9.12	4423	8010		FENDER STAY A	2.30
4181	3210	CUR	RIGHT FORK COVER	7.98	4423	8020		FENDER STAY A AFT	2.40
4181	5000	OMB	RIGHT FORK COVER	7.98	4423	9000	XCI	FENDER STAY A	2.10
4181	5000	CBK	RIGHT FORK COVER	7.98	4423	9010		FENDER STAY A	9.38
4181	5000	CUR	USE 4181 5000 FAR	14.80	4424	3210	MS	FENDER STAY B	2.30
4181	5000	FAR	R FORK COVER C A	14.80	4424	3211	MS	STAY B	2.16
4181	5600	MB	USE 4181 5600 MS	9.02	4424	3220	XCI	FENDER STAY C	2.58
4181	5600	MS	RIGHT FORK COVER	9.02	4424	3221	XCI	FENDER STAY B	2.58
4181	8000	FAR	R FORK COVER RED	6.40	4424	5010		FENDER STAY B	2.22
4181	8000	OB	USE 4181 8000 MS	6.40	4424	8010		FENDER STAY B	2.40
4181	8000	MS	RIGHT FORK COVER	6.40	4424	8020		FENDER STAY B AFT	2.58
4181	9000	XCI	RIGHT FORK COVER	8.16	4424	8030		NOT AVAILABLE	.00
4182	5000		CABLE CLIP	.18	4424	9000	XCI	FENDER STAY B	2.60
4182	9000		CABLE CLIP	.76	4424	9010		FENDER STAY B	8.36
4187	8010		USE 4153 8000 CLAMP	.26	4425	5011	XCI	FRONT FENDER STAY	5.66
4220	3001		LEFT FRONT ARM	6.60	4425	5600	XCI	FT FENDER STAY	3.02
4224	3000		GREASE NIPPLE	.26	4425	7000	XCI	USE 4425 8000	10.22
4224	3110		GREASE NIPPLE	.26	4425	8000		FRONT FENDER STAY	10.22
4230	3001		RIGHT FRONT ARM	7.12	4425	8010		STAY FRONT FENDER	11.42
4241	3001		RUBBER RING A	.92	4427	5620		FRONT FORK STABLI	14.48
4242	3001		RUBBER RING B	1.08	4428	5010		BAND STAY CLAMP	1.32
4243	3001		RUBBER RING C	1.16	4428	8010		CLAMP FRONT FENDE	.42
4251	3000		RUBBER BUSHING	.82	4431	3000		CABLE CLIP	.08
4252	3000		ARM COLLAR A	.36	4432	5000		FENDER PROTECTOR	.50
4253	3000		ARM COLLAR B	.26	4433	3100		FENDER WASHER	.08
4254	3003		CUSHION STOPPER	1.08	4435	5010		FRONT FENDER PLUG	.18
4255	3000		STOPPER A	.36	4451	5010		FRONT FENDER FLAP	1.16
4281	3000	CBK	HANDLE BRACKET BL	1.66	4452	5010		SET BAND	.26
4281	3000	CUR	HANDLE BRACKET RE	1.66	4511	3010		HANDLE BAR	6.90
4281	3010		HANDLE BRACKET	1.72	4511	3101		HANDLE BAR	6.90
4282	3012		HOLDER BASE	6.18	4511	5000		HANDLE BAR	6.90
4283	3012		HANDLE HOLDER	3.40	4511	5040		UP HANDLE BAR	9.12
4286	3000		BRIDGE CAP	.18	4511	8000		UP HANDLE BAR	7.72
4311	8000		STEER DAMPER KNOB	4.08	4511	8020		HANDLE BAR	9.38
4311	9000		STEERING DAMPER K	2.20	4511	9000		UP HANDLE BAR	7.72
4312	8000		DAMPER KNOB GUIDE	.82	4511	9010		UP HANDLE BAR	20.62
4313	8000		DAMPER LOCK SPRIN	.58	4601	3101		REAR VIEW MIRROR	3.72
4314	8000		DAMPER FACING	1.16	4601	8000		BACK MIRROR ASSY	5.12
4314	9000		DAMPER FACING	1.00	4610	3100		MIRROR COMP	1.76
4315	8000		FRICTION PLATE	.58	4610	8000		BACK MIRROR COMP	3.88
4315	9000		FRICTION PLATE	.58	4611	8000		NOT USED	.00

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
4615	5000	USE 4165 5000 WASH	4901	5600 MB USE 4901 5600 MS	17.96
4621	3101	STAY MIRROR	4901	5600 MB USE 4901 5600 MS	17.96
4621	8000	BACK MIRROR STAY	4901	5600 MS REAR CUSHION ASSY	17.96
4622	3102	MIRROR CLAMP	4901	8000 FAR REAR CUSHION RED	25.62
4622	8000	BACK MIRROR CLAMP	4901	8000 MS REAR CUSHION ASSY	25.62
4624	8000	NOT USED	4901	8000 OB USE 4901 8000 FAR	25.62
4701	3001	BLE CHAIN CASE BLUE	4901	9000 XCI REAR CUSHION	29.46
4701	3001	CBK CHAIN CASE BLACK	5101	3001 CBN FUEL TANK ASSY BR	36.92
4701	3001	CUR USE 4701 3001 CUR	5101	3001 CUR FUEL TANK RED ASS	36.92
4701	3001	CUR CHAIN CASE RED	5102	3200 TANK CAP	2.58
4701	3100	CHG CHAIN CASE GREEN	5102	8000 TANK CAP ASSY	4.08
4701	3100	CFG CHAIN CASE GRAY	5103	3000 FUEL COCK ASSY	3.06
4701	5000	MS CHAIN CASE ASSY	5103	5000 FUEL COCK	3.40
4711	3000	CHG UPPER CHAIN CASE	5103	8000 FUEL COCK ASSY	6.18
4711	3000	CBK UPPER CHAIN CASE	5103	8010 FUEL COCK ASSY	4.10
4711	3000	CUR UPPER CHAIN CASE	5103	9000 FUEL COCK	7.46
4721	3000	BLE NOT AVAILABLE	5103	9010 FUEL COCK ASSY	12.56
4721	3000	CHG LOWER CHAIN CASE	5110	3001 USE 5101 3001 CUR	36.92
4721	3000	CBK LOWER CHAIN CASE	5110	3101 CFG FUEL TANK GRAY	17.50
4721	3000	CUR LOWER CHAIN CASE	5110	3101 CHG FUEL TANK GREEN	17.50
4731	3000	CAP CHAIN CASE	5110	3200 MB FUEL TANK BLUE	38.38
4751	5010	CHAIN CASE	5110	3200 CBK FUEL TANK BLACK	38.28
4751	5020	HALF CHAIN CASE	5110	3200 CUR FUEL TANK 60 SP R	40.12
4751	5030	HALF CHAIN CASE	5110	5001 MB FUEL TANK BLUE	41.02
4751	5303	USE 4751 5030 CASE	5110	5001 CBK FUEL TANK BLACK	41.02
4751	5600	MS HALF CHAIN CASE	5110	5011 MB FUEL TANK 100T	48.32
4751	5610	MS CHAIN GUARD	5110	5011 FAB FUEL TANK 100GP/T	60.14
4751	8000	HALF CHAIN CASE	5110	5011 CBK USE 5110 5011 FAR	60.14
4751	9000	XCI HALF CHAIN CASE	5110	5011 FAR FUEL TANK C A RED	60.14
4810	3003	CHG REAR FORK GREEN	5110	5620 FBG FUEL TANK GOLD	46.80
4810	3003	CFG REAR FORK GRAY	5110	5620 FDG FUEL TANK GREEN	46.80
4810	3003	CBK REAR FRAME BLACK	5110	5621 FOG FUEL TANK	46.80
4810	3003	CUR REAR FRAME RED	5110	5621 FO FUEL TANK	46.80
4810	3200	CBK REAR FORK BLACK	5110	5011 CUR USE 5110 5011 FAR	60.14
4810	3200	CUR REAR FORK RED	5110	8000 CBK FUEL TANK BLACK	60.14
4810	3200	MB REAR FORK BLUE	5110	8000 FAR FUEL TANK COMP RE	60.14
4810	5000	CBK REAR FRAME BLACK	5110	8010 FAR FUEL TANK RED	60.14
4810	5000	CUR USE 4810 5021 FAR	5110	8010 FAB FUEL TANK BLUE	60.14
4810	5000	MB REAR FRAME BLUE	5110	8010 FBG FUEL TANK GOLD	46.82
4810	5021	CBK REAR FORK 90 SP B	5110	8010 FDG FUEL TANK GREEN	46.82
4810	5021	FAR REAR FORK ASSY RE	5110	8020 CUR FUEL TANK	52.60
4810	5410	CBK USE 4810 3200 CBK	5110	8010 FOG FUEL TANK GOLD	46.82
4810	5600	CBK REAR FORK 100T	5110	8010 PSW FUEL TANK WHITE	46.82
4810	8000	CBK REAR FORK COMP	5110	9000 FAR FUEL TANK RED	90.70
4810	8020	CBK REAR FORK AFT 16M	5110	9000 FBG FUEL TANK COMPL	69.62
4810	9000	CBK REAR FORK	5110	9000 FOG FUEL TANK	70.98
4851	3000	USE 4851 8000 BUSH	5110	9000 PSW FUEL TANK COMP	70.98
4851	3002	REAR FORK BUSH	5141	3000 KNEE GRIP L	1.16
4851	5000	TURSION RUBBER	5141	3200 KNEE GRIP LEFT	2.30
4851	8000	REAR FORK BUSH	5141	5000 KNEE GRIP LEFT	1.40
4851	8010	REAR FORK BUSHING	5141	5010 KNEE GRIP LEFT	2.90
4851	9000	BUSHING-REAR FORK	5141	8000 LEFT KNEE GRIP	3.40
4852	3001	REAR FORK CAP	5141	9000 LEFT KNEE GRIP	2.78
4852	5000	REAR FORK CAP	5142	3000 KNEE GRIP R	1.16
4853	3001	PACKING REAR FRAM	5142	3200 KNEE GRIP RIGHT	2.30
4853	3011	CHAIN PROTECTOR	5142	5000 KNEE GRIP RIGHT	1.40
4854	5000	TORQUE ROD SPRING	5142	5010 KNEE GRIP RIGHT	2.90
4855	5010	TENSION BAR BOLT	5142	8000 RIGHT KNEE GRIP	3.40
4855	8000	TORQUE ROD BOLT	5142	9000 RIGHT KNEE GRIP	2.78
4855	9000	BOLT TORQUE ROD	5143	3000 TANK SIDE MARK	1.48
4856	8000	REAR FORK COLLAR	5143	5000 SIDE MARK TANK	1.40
4856	9000	COLLAR REAR FORK	5144	5020 BRIDGESTONE LABEL	.86
4857	8000	REAR FORK SPACER	5145	8000 FUEL TANK FILTER	1.16
4857	8010	REAR FORK SPACER	5148	3000 RUBBER WASHER	.18
4858	8000	FORK PIVOT CAP	5149	3000 RUBBER GROMMET	.18
4858	9000	FORK PIVOT CAP	5149	9000 TANK CUSHION RUBB	.26
4861	3002	CHAIN ADJUSTER	5150	8200 TANK EMBLEM BASE	3.02
4861	3110	CHAIN ADJUSTER	5151	8200 TANK EMBLEM LABEL	.58
4861	9000	CHAIN ADJUSTER	5160	3002 TANK CAP	2.66
4862	8000	LEFT CHAIN ADJUST	5160	3100 TANK CAP	2.22
4863	8000	R CHAIN ADJUSTER	5166	5610 RIGHT TANK STRIPE	5.36
4864	8000	CHAIN ADJUSTER BO	5166	8200 RIGHT TANK STRIPE	9.10
4901	3005	BLE SUSPENSION BLUE	5166	9000 RIGHT TANK LABEL	6.18
4901	3005	CHG REAR CUSHION GREE	5167	5610 LEFT TANK STRIPE	5.36
4901	3005	CFG REAR CUSHION GRAY	5167	8200 LEFT TANK STRIPE	9.10
4901	3005	CBK SUSPENSION BLACK	5170	5610 TANK CAP LABEL	.68
4901	3005	CUR SUSPENSION RED	5170	8200 TANK CAP LABEL	1.08
4901	3200	CBK REAR CUSHN ASSY B	5167	9000 LEFT TANK LABEL	6.18
4901	3200	CUR REAR CUSHN ASSY R	5171	3001 TANK CAP GASKET	.66
4901	5000	CBK REAR SUSPENSION C	5171	3100 TANK CAP GASKET	.50
4901	5000	MB REAR SUSPENSION B	5171	8000 TANK CAP GASKET	.58
4901	5010	FAR USE 4901 5030 FAR	5172	3001 FUEL PIPE	.26
4901	5010	MB REAR SUSPENSION B	5172	3100 FUEL TUBE	.58
4901	5030	FAR REAR CUSHION C A	5172	5000 FUEL PIPE	.58

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
5173	8000	LEFT FUEL TUBE	6111	3101	LEFT SWITCH CASE	1.90
5174	8000	RIGHT FUEL TUBE	6111	5000	LEVER HOLDER LEFT	3.12
5174	9000	RIGHT FUEL TUBE	6111	5600	L SWITCH CASE	3.12
5181	3000	FUEL COCK BODY	6111	8000	LEFT SWITCH CASE	2.90
5182	5000	FUEL BOWL	6112	3100	CONTACT PLATE	.42
5182	8000	FUEL STRAINER CUP	6113	3100	HORN BUTTON	.18
5183	3000	PACKING BOWL	6114	3100	HORN SPRING	.18
5183	8000	STRAINER CUP GASK	6115	3100	LEFT HANDLE WIRE	4.38
5184	3000	PACKING FUEL COCK	6115	3110	WIRE ASSY	3.96
5184	8000	FUEL COCK GASKET	6115	5000	WIRE L ASSY	4.38
5186	5000	CONNECTING TUBE	6115	8000	LEFT HANDLE WIRE	5.12
5186	8000	TANK CONN TUBE	6116	3100	WIRE CLAMP L H	.36
5187	3004	CLIP FUEL PIPE	6116	8000	LEFT WIRE CLAMP	.42
5189	9000	WIRE GUARD SPRING	6117	3100	SWITCH CLAMP	.36
5191	3210	TANK CAP WITH KEY	6117	8000	DIPPER SWITCH CLA	.26
5191	8010	TANK CAP WITH KEY	6119	3100	USE 6119 5000 KNOB	.36
5510	5010	MB OIL TANK BLUE	6119	5000	SWITCH KNOB	.36
5510	5010	CBK OIL TANK COMP BLA	6119	8000	HANDLE SWITCH KNO	.58
5510	5010	FAR OIL TANK COMP RED	6121	3101	LEFT SWITCH COVER	1.58
5510	8000	CBK OIL TANK COMP	6121	5000	HOLDER COVER LEFT	3.12
5510	8010	FAR OIL TANK RED	6121	8000	L SWITCH CASE COV	2.90
5510	8010	MB OIL TANK 100T	6122	3011	CLUTCH LEVER	2.40
5510	8010	FAB OIL TANK 100GP/TM	6122	8000	CLUTCH LEVER	2.90
5510	8010	FBG OIL TANK GOLD	6123	3100	GRIP LEFT	1.32
5510	8010	FDG USE 5510 8010 FO	6123	5010	LEFT GRIP RUBBER	1.76
5510	8010	FO OIL TANK COMP	6123	5600	L HANDLE GRIP	1.82
5510	8010	FOG OIL TANK GOLD	6123	8000	LEFT HANDLE GRIP	1.82
5510	8010	PSW OIL TANK WHITE	6124	3100	LEVER COLLAR	.36
5510	9000	FAR OIL TANK COMP	6125	8000	LEFT LEVER HOLDER	2.30
5510	9000	FAB USE 5510 9000 FAR	6126	5600	WIRE ADJUSTER	1.78
5510	9000	FOG OIL TANK COMP	6126	8000	ADJUSTER SCREW	1.76
5510	9010	OIL TANK COMPL	6126	8200	WIRE ADJUSTER	1.78
5511	8000	OIL TANK PAD	6127	5600	ADJUSTER LOCK NUT	.86
5512	8000	OIL TANK CONN TUB	6127	8000	USE 6127 9000 NUT	.58
5512	9010	OIL TANK CONN TUB	6127	8000	USE 6127 9000	.58
5513	8000	OIL CONN TUBE CLI	6127	9000	WIRE ADJ LOCK NUT	.58
5513	9010	OIL CONN CLIP	6134	5610	FT STOP SWITCH	4.48
5514	8000	BREATHER TUBE	6134	8200	FT STOP SWITCH NH	4.48
5515	8000	DISCONTINUED	6140	8000	R SWITCH CASE	4.08
5530	8000	SUB OIL TANK	6141	3101	LEVER HOLDER R H	3.40
5531	5010	OIL GAUGE	6141	3110	LEVER HOLDER R H	3.40
5531	8000	USE 5531 5010 GAGE	6141	5600	R SWITCH CASE	2.52
5532	5010	OIL TANK FILTER	6141	5610	R SWITCH CASE	3.28
5532	8000	OIL TANK FILTER	6141	8000	USE 6141 8010 CASE	3.40
5532	9010	OIL TANK FILTER	6141	8010	R SWITCH CASE AFT	3.40
5533	5010	OIL TUBE C	6145	3100	R HANDLE WIRE	4.08
5533	8000	OIL TUBE C	6145	3110	WIRE ASSY R H	5.42
5533	8010	OIL TUBE C	6145	5000	NUT USED	.00
5533	9000	OIL TUBE C	6146	3100	WIRE CLAMP R	.36
5534	5010	UNION CONNECTOR	6146	3110	RIGHT WIRE CLAMP	.36
5536	8000	OIL TANK BRACKET	6147	3100	SWITCH CLAMP L	.36
5537	8000	OIL TANK PAD	6149	8000	RIGHT LEVER HOLDE	2.90
5540	9010	LEFT OIL TANK U B	6149	8200	R LEVER HOLDER NH	3.28
5541	9010	RIGHT OIL TANK U	6151	3101	R CASE COVER	1.76
5542	9010	OIL TANK UPPER BR	6151	5000	USE 6151 5020 COVER	3.12
5543	9010	OIL TANK LOWER BR	6151	5020	HOLDER COVER R	3.12
5544	9010	OIL TANK SET BAND	6151	8000	USE 6151 8010 COVER	2.90
5545	9010	OIL TANK SPACER A	6151	8010	R SWITCH CASE COV	2.90
5546	9010	OIL TANK SPACER B	6152	3100	LEVER RIGHT	1.98
5547	9010	OIL TANK SET BOLT	6152	5610	FT BRAKE LEVER	2.96
5560	5010	OIL TANK CAP	6152	8000	FRONT BRAKE LEVER	2.90
5560	9010	OIL TANK CAP COMP	6153	3100	GRIP RIGHT	1.32
5560	8000	USE 5560 5010 CAP	6153	5010	RIGHT GRIP RUBBER	1.66
6101	3010	CLUTCH GRIP ASSY	6153	5600	R HANDLE GRIP	1.68
6101	3021	CLUTCH GRIP 6V	6153	8000	RIGHT HANDLE GRIP	1.76
6101	5000	CLUTCH GRIP ASSY	6154	3100	GRIP PIPE RH	2.22
6101	5600	CLUTCH GRIP ASSY1	6154	8000	THROTTLE GRIP PIP	2.30
6101	9000	CLUTCH GRIP ASSY	6155	3100	SLIDING SHOE	.76
6102	3100	LEFT GRIP ASSY	6156	3100	STOPPER CABLE	.36
6102	3130	LEFT GRIP ASSY	6158	8000	ADJUST SCREW	1.16
6103	5000	STARTER LEVER ASS	6161	8000	RETAINING SPRING	.60
6103	8000	STARTER LEVER ASS	6165	8000	SCREW SPRING	.18
6104	3100	THROTTLE GRIP	6171	3001	SPEEDOMETER CABLE	2.66
6104	3120	THROTTLE GRIP 12V	6171	5000	SPEEDOMETER CABLE	3.40
6104	5000	NUT USED	6171	8000	USE 6171 8001 CABLE	2.90
6104	5020	THROTTLE GRIP ASS	6171	8001	SPEEDOMETER CABLE	2.90
6104	5600	THROTTLE GRIP 100	6171	8200	SPEEDOMETER CABLE	3.28
6104	5610	THROTTLE GRIP ASS	6171	9000	SPEEDOMETER CABLE	3.28
6104	8200	THROTTLE GRIP NHS	6172	9000	TACHOMETER CABLE	3.28
6104	9000	THROTTLE GRIP ASS	6176	3001	THROTTLE CABLE	.82
6105	8000	LEFT CASE ASSY	6176	3100	THROTTLE CABLE	.66
6107	8000	USE 6107 8030 CASE	6176	5000	THROTTLE CABLE	1.48
6107	8030	RIGHT CASE ASSY	6176	5030	THROTTLE CABLE	3.40
6111	3011	LEVER HOLDER L H	6176	5040	THROTTLE CABLE	2.58

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
6176	5070	USE 6176 5071 CABLE	6.90	6291	8010	CLEANER ELEMENT	.66
6176	5071	THRATTLE CABLE	6.90	6301	3002	MUFFLER ASSY	12.16
6176	5080	USE 6176 5081 CABLE	6.90	6301	3100	MUFFLER ASSY	14.12
6176	5081	THRATTLE CABLE 90	6.90	6301	5000	MUFFLER ASSY	20.52
6176	5610	THROT CABLE AFT22	7.42	6301	5010	UP MUFFLER RIGHT	22.78
6176	8000	USE 6176 8001 CABLE	5.12	6301	5020	MUFFLER ASSY	22.78
6176	8001	THRATTLE CABLE	5.12	6301	5030	MUFFLER ASSY	20.50
6176	8020	THRATTLE CABLE	7.52	6301	5040	MUFFLER ASSY	22.78
6176	8030	THRATTLE CABLE	2.36	6301	5041	MUFFLER ASSY	22.78
6176	9000	THRATTLE WIRE	6.80	6301	5600	MUFFLER 100T	25.40
6178	5000	STARTER CABLE	2.90	6301	5600	GBK MUFFLER ASSY TMX	25.38
6178	5030	STARTER CABLE COM	2.66	6301	5610	MUFFLER ASSY	26.08
6178	5060	USE 6178 5030 CABLE	2.66	6302	8000	USE 6302 8001 MUFFR	22.78
6178	8000	CARB STARTER WIRE	3.96	6302	8001	LEFT MUFFLER ASSY	22.78
6178	8010	STARTER CABLE	4.38	6302	8010	LEFT MUFFLER ASSY	27.32
6178	9000	STARTER CABLE	3.88	6302	8010	GBK MUFFLER ASSY	27.18
6181	3000	FRONT BRAKE CABLE	1.98	6302	9000	L MUFFLER ASSY	32.06
6181	5000	BRAKE CABLE	3.30	6302	9010	GBK LEFT MUFFLER ASSY	52.86
6181	5020	BRAKE CABLE	2.36	6303	8000	USE 6303 8001 MUFFR	22.78
6181	5600	FRONT BRAKE CABLE	5.38	6303	8001	R MUFFLER ASSY	22.78
6181	8000	FRONT BRAKE WIRE	4.94	6303	8010	RIGHT MUFFLER ASS	27.32
6181	8010	FRONT BRAKE CABLE	4.94	6303	8010	GBK MUFFLER ASSY	27.18
6181	8020	BRAKE CABLE	4.94	6303	9000	R MUFFLER ASSY	32.06
6181	9000	FRONT BRAKE CABLE	4.38	6303	9010	GBK RIGHT MUFFLER ASS	52.86
6182	5000	RETURN SPRING	.18	6310	3200	MUFFLER	18.96
6183	5000	BOOT BRAKE CABLE	.76	6310	3220	UP MUFFLER	20.50
6186	3001	CLUTCH CABLE	2.58	6310	5020	TUNED MUFFLER 90	32.00
6186	5000	CLUTCH WIRE	3.12	6310	5410	TUNED MUFFLER 100	32.00
6186	5020	CLUTCH CABLE	3.62	6310	8010	NOT AVAILABLE	.00
6186	5040	CLUTCH CABLE	3.40	6320	3000	MUFFLER INNER PIP	2.22
6186	5410	CLUTCH CABLE	3.40	6320	3200	DIFFUSER PIPE	4.22
6186	5600	CLUTCH CABLE	2.78	6320	5000	INNER PIPE	4.76
6186	8000	CLUTCH WIRE	3.72	6320	5010	INNER PIPE	4.90
6186	8020	CLUTCH WIRE	3.72	6320	5020	DIFFUSER PIPE	5.66
6186	9000	USE 6186 9001 CABLE	3.62	6320	5030	DIFFUSER PIPE	4.76
6186	9001	CLUTCH CABLE	3.62	6320	5600	DIFFUSER PIPE 100	4.68
6187	9000	WIRE CLAMP C	.58	6320	8000	USE 6320 8001 PIPE	3.72
6189	5000	CABLE CLAMP B	.42	6320	8001	DIFFUSER PIPE	3.72
6201	3003	AIR CLEANER ASSY	5.28	6320	8010	DIFFUSER PIPE	4.38
6201	3100	AIR CLEANER	5.12	6320	9000	DIFFUSER PIPE	5.06
6201	5010	AIR CLEANER ASSY	44.54	6320	9010	DIFFUSER PIPE	9.92
6201	5600	AIR CLEANER ASSY	29.92	6321	8000	DIFUSER PIPE NUT	1.00
6201	8000	AIR CLEANER ASSY	14.80	6321	9010	DIFFUSER PIPE NUT	.32
6201	8010	MS AIR CLEANER	14.80	6322	8010	SEAL DIFFUSER PIP	1.98
6211	3000	AIR CLEANER ELEME	3.72	6322	9010	DIFFUSER PIPE SEA	3.82
6211	3100	AIR CLEANER ELEME	3.40	6323	8010	SCREW GASKET A	.16
6211	3200	AIR CLEANER	5.42	6324	8010	SCREW GASKET B	.16
6211	5000	USE 6211 5001 CLEAN	6.88	6332	3210	FR MUFFLER PROTEC	4.42
6211	5001	AIR CLEANER COMP	6.88	6332	5010	MUFFLER PROTECTOR	3.96
6211	5010	AIR CLEANER ELEME	7.98	6333	5010	R MUFFLER PROTECT	3.16
6211	5020	CLEANER ELEMENT	4.12	6334	5010	PROTECTOR BRACKET	.82
6211	5030	AIR CLEANER ELEME	7.98	6335	3210	MUFFLER STAY	1.40
6211	5600	AIR CLEANER ELEME	14.80	6335	5010	MUFFLER STAY RIGH	1.40
6211	8000	AIR CLEANER ELEME	6.88	6335	5020	MUFFLER STAY	1.40
6211	8010	AIR CLEANER ELEME	6.88	6335	5021	MUFFLER STAY	1.40
6211	8020	AIR CLEANER SCREE	5.86	6335	5600	MUFFLER STAY 100T	2.20
6212	9000	USE 6214 9000 ELEM	12.20	6335	8010	MUFFLER STAY	2.16
6213	9000	USE 6214 9000 ELEM	12.20	6336	8010	L MUFFLER PROTECT	2.16
6214	9000	ELEMENT AIR CLEAN	12.20	6337	8010	R MUFFLER PROTECT	2.16
6221	5600	AIR CLEANER CASE	14.76	6338	8010	SCREW COVER	.18
6221	8000	AIR CLEANER CASE	6.88	6340	8010	NOT AVAILABLE	.00
6221	8010	AIR CLEANER CASE	6.18	6341	9010	LEFT MUFFLER STAY	3.92
6221	9000	AIR CLEANER CASE	12.20	6342	9010	RIGHT MUFFLER STA	3.92
6222	3100	AIR CLEANER COVER	2.66	6343	9010	LEFT FRONT MUF PR	8.48
6222	8000	AIR CLEANER COVER	2.30	6344	9010	LEFT FRONT MUF PR	7.50
6223	8000	AIR CLEANER BOLT	.36	6351	3001	EXHAUST PIPE	3.96
6224	8000	LATCH CLIP	.18	6351	3101	EXHAUST PIPE	4.60
6225	9000	GASKET-CLEANER CO	.58	6351	3200	EXHAUST PIPE	6.18
6232	5010	COVER ELEMENT	5.66	6351	3210	EXHAUST PIPE	6.18
6233	5010	CLEANER CASE COVE	5.66	6351	3220	EXHAUST PIPE	6.88
6235	4100	CHW AIR INTAKE CAP	.50	6351	5000	USE 6351 5030 PIPE	6.18
6241	3010	AIR PIPE STR TYPE	.66	6351	5010	EXHAUST PIPE	6.18
6241	3100	AIR PIPE	1.98	6351	5030	EXHAUST PIPE	6.18
6241	5000	AIR PIPE	1.58	6351	5040	EXHAUST PIPE	6.18
6241	5010	AIR PIPE 90SP	1.58	6351	5050	EXHAUST PIPE	7.08
6241	5020	AIR PIPE	1.58	6351	5400	EXHAUST PIPE 100	6.18
6241	5600	AIR PIPE 100T	1.68	6351	5600	EXHAUST PIPE	7.92
6241	8000	AIR PIPE	1.58	6351	5610	EXHAUST PIPE P100	8.08
6241	8010	AIR PIPE AFT 16K	1.26	6352	8000	LEFT EXHAUST PIPE	6.18
6242	5000	JOINT RUBBER	1.26	6352	8020	LEFT EXHAUST PIPE	6.88
6242	5010	AIR PIPE JOINT	1.40	6352	9000	LEFT EXHAUST PIPE	7.58
6242	5020	AIR PIPE JOINT	1.40	6352	9010	LEFT EXHAUST PIPE	14.96
6242	8000	AIR PIPE JOINT	3.96	6353	8000	RIGHT EXHAUST PIP	6.18
6243	5000	SET RING AIR PIPE	.36	6353	8020	RIGHT EXHAUST PIP	6.88

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST			
6353	9000	RIGHT EXHAUST PIP	7.58	6811	3131	CFG	SIDE COVER GRAY	6.62
6353	9010	RIGHT EXHAUST PIP	14.96	6811	3131	CHG	SIDE COVER GREEN	6.62
6361	3000	EXH PIPE CLAMP	1.16	6811	3211	OMB	SIDE COVER L BLUE	6.70
6361	3201	EXH PIPE CLAMP NU	2.58	6811	3211	OUR	SIDE COVER L RED	6.70
6361	5000	CLAMP NUT EXH PIP	2.30	6811	3211	CBK	L SIDE COVER BLK	6.62
6361	5400	EXHAUST PIPE CLAM	2.58	6811	5020	CBK	USE 6811 5030 CBK	6.70
6361	8000	EXHAUST PIPE CLAM	2.40	6811	5030	CBK	SIDE COVER L BLAC	6.70
6361	9000	EXHAUST PIPE CLAM	4.10	6811	5030	OUR	SIDE COVER RED	9.12
6362	3002	MUFFLER JOINT	1.32	6811	5030	FAR	SIDE COVER L RED	6.88
6362	5000	RUBBER JOINT	1.98	6811	5030	MB	SIDE COVER L BLUE	6.70
6362	9000	MUFFLER JOINT RUB	2.20	6811	5600	MB	LEFT COVER 100T	7.72
6363	3001	JOINT STOPPER	.26	6811	5600	FAB	USE 6811 5600 FOG	7.72
6363	5000	STOPPER	.18	6811	5600	FAR	L SIDE COVER RED	7.72
6363	9000	MUFFLER JOINT STO	.68	6811	5600	FBG	LEFT SIDE COVER G	7.72
6364	3000	JOINT RING	.18	6811	5600	FDG	LEFT SIDE COVER G	7.72
6364	5000	RING	.26	6811	5600	FOG	LEFT SIDE COVER	7.72
6365	8010	LEFT BAND A	1.16	6811	5600	FO	LEFT SIDE COVER	7.72
6366	8010	RIGHT BAND A	1.16	6811	8000	OB	SIDE COVER LEFT B	6.68
6367	8010	BAND B	1.16	6811	8000	FAR	LEFT COVER RED	6.68
6367	9010	BAND A	3.26	6811	8010	FAR	USE 6811 8020 FAR	6.68
6368	8010	BAND CUSHION RUBB	.26	6811	8020	FAR	LEFT COVER	6.68
6368	9010	BAND CUSHION RUBB	1.00	6811	8200	FAR	LEFT COVER RED	7.42
6369	9010	BAND B	2.86	6811	8200	FAB	LEFT COVER BLUE	7.42
6391	9000	NUT AVAILABLE	.00	6811	8200	FBG	LEFT COVER GOLD	7.72
6402	8000	DUAL SEAT ASSY	45.56	6811	8200	FDG	LEFT COVER GREEN	7.72
6402	8020	DUAL SEAT ASSY	53.04	6811	8200	FOG	LEFT COVER GOLD	7.72
6402	8200	DUAL SEAT 200DT	59.76	6811	8200	PSW	USE 6811 8200 FAR	7.42
6402	8210	DUAL SEAT 200HS	59.76	6811	9000	FAR	USE 6811 9001 FAR	7.46
6410	3000	SINGLE SEAT HMS	17.68	6811	9001	FAR	LEFT COVER	7.46
6410	4020	USE 6410 5020 SEAT	19.40	6811	9001	FOG	LEFT SIDE COVER G	7.46
6410	5020	SINGLE SEAT ASSY	19.40	6811	9010	FBG	LEFT COVER	8.90
6426	3110	SEAT PIVOT BRACKE	1.32	6811	9010	PSW	LEFT COVER WHITE	8.90
6430	5020	RACER SEAT	45.56	6812	8000		MAIN SWITCH GROMM	.26
6430	5030	DUAL SEAT	27.34	6813	8000		CHRG SWITCH LABE	.18
6430	5600	SPORT SEAT 100T	27.34	6815	3120		COVER ORNAMENT	1.16
6430	8010	NOT AVAILABLE	.00	6815	3210		COVER ORNAMENT 50	1.16
6460	3012	DUAL SEAT	30.52	6815	3220		COVER ORNAMENT 60	1.16
6460	3110	DUAL SEAT	38.28	6815	5010		COVER ORNAMENT 90	1.16
6460	3220	DUAL SEAT	41.74	6815	5030		COVER ORNAMENT 90	1.16
6460	5010	USE 6460 5030 SEAT	44.66	6815	5040		COVER ORNAMENT 90	1.16
6460	5030	TANDEM SEAT	44.66	6815	5050		COVER ORNAMENT 90	1.16
6460	5040	DUAL SEAT	44.66	6815	5400		COVER ORNAMENT 10	1.16
6460	5400	DUAL SEAT 100 SP	44.66	6815	5600		COVER ORNAMENT 10	1.68
6460	5610	DUAL SEAT P100SP	44.66	6815	5610		COVER ORNAMENT P1	1.42
6460	9000	DUAL SEAT COMP	59.84	6815	5620		COVER ORNAMENT P10	1.42
6510	5000	OMB	8.46	6815	8000		175 COVER ORNAMEN	1.16
6510	5610	LUGGAGE CARRIER 1	22.20	6815	8020		175 HS ORNAMENT	1.16
6531	3220	LUGGAGE CARRIER	11.96	6815	8200		COVER ORNAMENT 20	1.42
6531	5020	USE 6531 3220 RACK	11.96	6815	8210		COVER ORNAMENT 20	1.42
6531	5021	SPORT CARRIER	11.96	6815	9000		COVER ORNAMENT	1.16
6541	5030	HEAVY DUTY CARRIE	21.52	6815	9010		COVER ORNAMENT	4.10
6548	5010	HD CARRIER PLATE	1.76	6815	9011		71 COVER ORNAMENT	4.10
6581	3110	DUAL SEAT RACK	15.78	6818	5610		COVER ORNAMENT 10	1.08
6610	3120	LEGSHIELD WHITE	19.40	6818	8200		COVER ORNAMENT 20	1.16
6610	3120	LEGSHIELD GRAY	19.40	6818	9000		COVER ORNAMENT 35	1.16
6615	3110	BRIDGESTONE MARK	1.00	6821	3210	CBK	SIDE COVER R BLAC	6.70
6615	3120	SURFRIDER MARK	1.00	6821	3210	CUR	SIDE COVER R RED	9.10
6621	3100	L LEGSHIELD STAY	.66	6821	3220	OMB	SIDE COVER R BLUE	9.10
6622	3100	R LEGSHIELD STAY	.66	6821	3220	BSR	USE 6821 3210 CUR	9.10
6623	3100	LEGSHIELD BOLT	.28	6821	3220	CUR	USE 6821 3210 CUR	9.10
6624	3100	LEGSHIELD NUT	.26	6821	5040	CBK	SIDE COVER R BLAC	9.10
6660	8200	PASS TOURING BAR	20.28	6821	5050	CBK	SIDE COVER R BLAC	6.70
6660	9000	PASS TOURING BAR	21.92	6821	5050	FAR	SIDE COVER R RED	6.90
6711	3100	L ENGINE COVER	8.90	6821	5050	MB	SIDE COVER R BLUE	6.70
6721	3100	R ENGINE COVER	9.78	6821	5070	CUR	USE 6821 5070 FAR	6.90
6731	3100	COVER STOPPER	.08	6821	5070	FAR	SIDE COVER R RED	6.90
6732	3100	COVER SPACER	.08	6821	8000	FAR	USE 6821 8001 FAR	6.90
6733	3100	COVER GROMMET	.08	6821	8000	OB	USE 6821 8001 FAR	6.90
6751	3101	CHG	1.58	6821	8001	FAR	SIDE COVER R RED	6.90
6751	3101	CFG	1.58	6821	9010	FBG	RIGHT COVER GOLD	10.28
6761	5010	ENGINE GUARD	5.42	6821	9010	PSW	RIGHT COVER WHITE	10.28
6761	5600	ENGINE GUARD 100T	7.28	6823	8000		EYELET	.08
6761	8010	ENGINE PROTECTOR	9.10	6831	3002	CBK	COVER KNOB	.82
6761	9010	ENGINE PROTECTOR	15.92	6831	3100		COVER KNOB	.76
6762	8010	UPPER BOLT	.76	6831	5000		KNOB COVER	.92
6762	9010	ENGINE PROT U BOL	1.00	6831	5010		COVER KNOB	1.00
6763	5000	ENG GUARD BRACKET	1.42	6831	9000		COVER KNOB	.68
6801	3001	CBK	5.06	6832	3001		USE 09504 101 RING	.08
6801	3001	CFG	5.06	6833	9000		COVER STOPPER	.18
6801	3012	CBK	5.06	7100	3000		USE 7101 3000 WHEEL	57.36
6801	3030	CFG	5.06	7100	3200		USE 7101 3200 WHEEL	32.84
6802	3001	CFG	5.06	7101	3000		FRONT WHEEL	57.36
6802	3001	CBK	5.06	7101	3200		FRONT WHEEL	32.84
6803	8000	CHRG CONTROL SWIT	2.88	7100	5000		USE 7101 5000 WHEEL	36.48

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
7101	5000	FRONT WHEEL ASSY	7159	9000	SPRING BRAKE ARM	1.26
7101	5600	FRONT WHEEL LOOT	7161	8000	BRAKE ARM PIN	.08
7101	8000	FRONT WHEEL ASSY	7161	9000	PIN BRAKE ARM	.08
7102	3003	FRONT HUB ASSY	7166	5000	TENSION BAR	1.76
7105	3003	BRAKE SHOE SET	7166	8000	FRONT TORQUE LINK	2.22
7108	3000	SET FRONT SPOKE SET	7166	9000	FRONT TORQUE LINK	2.20
7108	3000	EA FRONT SPOKE EACH	7167	5000	TENSION BAR BOLT	.36
7108	3110	SET FRONT SPOKE SET	7167	8000	FRONT LINK BOLT	1.76
7108	3110	EA FRONT SPOKE EACH	7173	3001	NOT AVAILABLE	.00
7108	5000	SET FRONT SPOKE SET	7191	3110	SPEEDO HUB GEAR S	3.40
7108	5000	EA FRONT SPOKE EACH	7191	5000	SPEEDO HUB GEAR S	3.40
7108	5020	SPOKE SET F & R	7193	9000	FRONT WHEEL ASSY	67.02
7108	8000	SET FRONT SPOKE ASSY	7221	3002	FRONT WHEEL AXLE	2.22
7108	8000	EA FRONT SPOKE EACH	7221	5000	FRONT HUB SHAFT	3.16
7108	9000	SET FRONT-REAR SPOKE	7221	8000	FRONT WHEEL AXLE	6.18
7108	9000	EA SPOKE EACH	7221	9000	FRONT WHEEL AXLE	7.02
7111	3003	USE 7111 3004 DRUM	7226	3110	OIL SEAL COLLAR	.66
7111	3004	FRONT BRAKE DRUM	7226	8000	FRONT AXLE COLLAR	1.76
7111	3111	FRONT BRAKE DRUM	7228	3110	DUST SEAL CAP	.92
7111	3210	BRAKE DRUM	7241	3000	USE 7441 3000 RIM	11.36
7111	5002	DRUM FRONT AFT 12	7241	5000	FRONT OR REAR RIM	11.60
7111	8000	FRONT BRAKE DRUM	7241	5020	FRONT & REAR RIM	15.88
7114	3002	FT DRUM COLLAR	7241	8000	WHEEL RIM	15.98
7114	3110	USE 7114 5000 PIPE	7241	8010	WHEEL RIM 300X18	19.26
7114	5000	CENTER PIPE	7241	9000	FRONT-REAR RIM	18.16
7114	8000	FRONT DRUM COLLAR	7245	9000	BALANCE WEIGHT A	.68
7115	3000	CENTER PIPE SUPPD	7246	9000	BALANCE WEIGHT B	.82
7115	8000	COLLAR SUPPORTER	7251	3000	USE 225 X 17 FS	
7115	8010	COL SUPPORT AFT 1	7251	5000	USE 250 X 17 FS TIRE	
7116	3000	SPEEDOMETER GEAR	7251	5020	USE 250 X 17 HK TIRE	
7118	3000	OIL SEAL COLLAR	7251	8000	USE 250 X 18 FS TIRE	
7121	3000	DUST SEAL A	7251	8010	USE 300 X 18 FL TIRE	
7130	3200	FRONT PANEL OLD S	7251	9000	USE 325 X 19 FL TIRE	
7130	3201	FRONT PANEL	7252	3000	USE 225 X 17 TUBE	
7130	3202	PANEL 50 SP	7252	5000	USE 250 X 17 TUBE	
7130	5002	PANEL FRONT BEF 1	7252	8000	USE 250 X 18 TUBE	
7130	5003	PANEL FRONT AFT 1	7252	8010	USE 300 X 18 TUBE	
7130	5600	FRONT PANEL	7252	9000	USE 325 X 19 TUBE	
7130	8000	FRONT PANEL COMP	7253	3000	RIM BAND	.42
7130	9000	FRONT BRAKE PANEL	7253	8000	USE 7453 8000 BAND	1.22
7131	3004	USE 7131 3005 PANEL	7253	9000	19 IN TIRE FLAP	1.26
7131	3005	FRONT BRAKE PANEL	7261	3003	SPEED GEAR BOX	9.96
7131	3202	USE 7130 3202 PANEL	7300	3000	USE 7402 3000 WHEEL	57.36
7134	3002	GREASE NIPPLE	7300	3200	USE 7301 3200 WHEEL	36.48
7135	5000	SPEEDO PINION	7300	5000	USE 7301 5000 WHEEL	43.76
7136	3110	THRUST WASHER	7301	3200	REAR WHEEL	36.48
7137	3110	BUSHING	7301	5000	REAR WHEEL ASSY	43.76
7138	3110	SPEEDO PIN PLUG	7301	5600	REAR WHEEL LOOT	39.92
7139	3110	SET SCREW	7301	8000	REAR WHEEL ASSY	78.70
7140	3110	BRAKE SHOE	7301	8010	USE 7301 8011 WHEEL	83.88
7140	5000	BRAKE SHOE	7301	8011	REAR WHEEL AFT 16	83.88
7140	8000	USE 7140 9000 SHOE	7302	3003	REAR HUB ASSY	28.66
7140	9000	BRAKE SHOE	7308	3000	REAR SPOKE SET	3.80
7141	3004	USE 7105 3003 SHOE	7308	3000	EA REAR SPOKE EACH	.16
7145	3001	BRAKE SHOE SPRING	7308	3110	SET REAR SPOKE SET	4.46
7145	3110	RETURN SPRING	7308	3110	EA REAR SPOKE EACH	.16
7145	8000	BRAKE SHOE SPRING	7308	5000	SET REAR SPOKE SET	4.46
7148	3201	SPEEDOMETER GEAR	7308	5000	EA REAR SPOKE EACH	.16
7148	5001	SPEEDOMETER GEAR	7308	5600	SET F & R SPOKE SET	6.50
7148	8000	SPEEDOMETER GEAR	7308	5600	EA F & R SPOKE EACH	.26
7148	9000	SPEEDOMETER GEAR	7308	8000	SET REAR SPOKE ASSY	6.18
7149	3110	GEAR CONNECTOR	7308	8000	EA REAR SPOKE EACH	.26
7149	5000	USE 7149 3110 GEAR	7311	3002	REAR BRAKE DRUM	17.16
7149	8000	GEAR CONNECTOR	7311	3111	DRUM REAR HUB	28.80
7151	3001	USE 7151 3003 CAM	7311	5000	USE 7311 5001 DRUM	23.22
7151	3003	FRONT BRAKE CAM	7311	5001	DRUM REAR AFT 12Q	23.22
7151	3110	CAM FRONT HUB	7311	8000	REAR BRAKE DRUM	41.92
7151	8000	FRONT BRAKE CAM	7311	8010	REAR DRUM AFT 16M	38.08
7151	9000	FRONT BRAKE CAM	7311	9000	REAR BRAKE DRUM	43.54
7152	3001	PACKING BRAKE LEV	7314	3001	REAR DRUM COLLAR	.32
7152	8000	CAM DUST SEAL	7314	3110	USE 7314 5000 PIPE	.66
7153	3004	BRAKE LEVER FRONT	7314	5000	CENTER PIPE	.66
7153	8000	BRAKE ARM A	7314	8000	REAR DRUM COLLAR	1.16
7153	9000	BRAKE ARM A	7314	8010	DRUM COLLAR AFT 1	1.98
7154	8000	BRAKE ARM B	7314	9000	COLLAR REAR DRUM	2.20
7154	9000	BRAKE ARM B	7315	8010	CUL SUPPORT B AFT	.26
7155	8000	WIRE CONNECTOR	7315	9000	COLLAR SUPPORT B	.42
7156	8000	ROD END A	7318	9000	USE 7381 9000 SPRKT	12.20
7156	9000	ROD END A	7319	3111	DAMPER RUBBER	1.08
7157	8000	ROD END B	7319	8000	REAR WHEEL DAMPER	1.16
7157	9000	ROD END B	7319	8010	REAR DAMPER AFT 1	1.32
7158	8000	BRAKE ARM ROD	7319	9000	DAMPER REAR WHEEL	1.42
7158	9000	BRAKE ARM ROD	7330	3201	USE 7331 3111 PANEL	11.70
7159	8000	ARM RETURN SPRING	7330	8000	REAR PANEL COMP	22.78

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
7330	9000	REAR PANEL COMP	26.08	7501 5030	ROLLER CHAIN 100T	9.78
7331	3002	REAR BRAKE PANEL	6.40	7501 5410	USE 7501 5030 CHAIN	9.78
7331	3111	REAR PANEL	11.70	7501 8000	ROLLER CHAIN ASSY	14.58
7331	5000	USE 7331 5001 PANEL	18.20	7501 8010	RULLER CHAIN ASSY	12.90
7331	5001	PANEL AFT 12Q	18.20	7501 8200	USE 7501 8000 CHAIN	14.58
7351	3003	REAR BRAKE CAM	1.32	7501 9000	ROLLER CHAIN	16.56
7351	3110	CAM REAR HUB	5.10	7502 5010	CHAIN EXT KIT 47T	2.26
7351	8000	REAR BRAKE CAM	3.16	7502 5020	CHAIN EXT KIT 64T	2.26
7351	9000	REAR BRAKE CAM	3.02	7502 5050	USE 7502 5010 EXT	2.26
7353	3004	BRAKE LEVER REAR	1.40	7502 8010	SUB CHAIN ASSY	1.36
7353	8000	BRAKE ARM C	5.88	7502 8020	SUB CHAIN ASSY	1.68
7359	8000	ARM RETURN SPRING	1.58	7520 3000	CHAIN CONNECTOR 4	.68
7361	3003	ANCHOR PIN	.26	7520 5000	CHAIN CONNECTOR	.68
7366	3000	REAR TORQUE LINK	.66	7520 8000	CHAIN JOINT CLAMP	.76
7366	5000	TENSION BAR	1.76	7520 9000	CHAIN CONNECTOR	.98
7366	5010	TENSION BAR	1.98	8102 3004	HEAD LAMP ASSY	7.98
7366	8000	REAR TORQUE LINK	3.72	8102 3012	HEAD LAMP ASSY	7.98
7366	9000	REAR TORQUE LINK	4.10	8102 3020	HEAD LAMP ASSY	14.46
7367	3001	REAR LINK BOLT	.36	8102 5000	HEADLIGHT ASSY	7.98
7367	8000	REAR LINK BOLT	1.76	8102 5020	HEAD LAMP ASSY	14.62
7367	9000	REAR LINK BOLT	1.68	8102 8000	USE 8102 8200 LAMP	14.10
7369	8000	USE 6224 8000 CLIP	.18	8102 8010	USE 8102 8200 LAMP	14.10
7371	3110	DRIVING FLANGE	7.72	8102 8200	HEAD LAMP ASSY	14.10
7371	3200	DRIVE FLANGE	12.62	8102 9000	HEAD LAMP ASSY	12.52
7371	8000	DRIVE FLANGE	14.80	8111 3004	BLE NOT AVAILABLE	.00
7376	3111	USE 7376 5001 COLLR	3.92	8111 3004	CBK HEAD COVER BLACK	8.20
7376	5001	COLLAR DRIVE FLAN	3.92	8111 3004	CUR HEAD COVER RED	8.20
7376	8000	DRIVE FLANGE COLL	4.90	8111 3012	CBK HEAD COVER BLACK	8.20
7377	3110	OIL SEAL COLLAR	1.36	8111 3012	CUR HEAD COVER RED	8.20
7377	5000	OIL SEAL COLLAR	.26	8111 3100	CHG HEAD COVER GREEN	6.70
7377	8000	OIL SEAL COLLAR	1.58	8111 3120	CFG HEAD COVER GRAY	8.52
7377	8010	SEAL COLLAR AFT 1	2.18	8111 3120	CHG HEAD COVER GREEN	8.96
7377	9000	OIL SEAL COLLAR	1.68	8111 5000	CBK HEAD COVER BLACK	5.88
7379	3111	FLANGE COLLAR NUT	.76	8111 5000	MB USE 8111 5020 MB	14.80
7379	8000	FLANGE COLLAR NUT	2.72	8111 5000	OUR USE 8111 5020 OUR	14.80
7381	3000	REAR SPROCKET	5.20	8111 5020	CBK HEAD COVER BLACK	14.80
7381	3110	DRIVE SPROCKET 33	5.80	8111 5020	MB HEAD COVER BLUE	14.80
7381	3200	SPROCKET 36T	5.80	8111 5020	FAR HEAD COVER C A RE	17.10
7381	5000	REAR SPROCKET 36T	5.80	8111 5020	OUR HEAD COVER 60 RED	14.80
7381	5010	48 NOT AVAILABLE	.00	8111 5020	MS HEAD LAMP BODY	14.80
7381	5020	46 46T SPROCKET	8.92	8111 8000	FAR HEAD LAMP BODY RE	12.56
7381	5030	44 44T SPROCKET	8.92	8111 8000	OB HEAD LAMP BODY BL	12.56
7381	5040	42 42T SPROCKET	8.92	8111 8200	HEAD LAMP BODY	14.86
7381	5050	40 40T SPROCKET	8.92	8111 9000	XCI HEAD LAMP BODY	17.78
7381	5060	38 38T SPROCKET	8.92	8121 3010	HEAD ORNAMENT	1.08
7381	5400	DRIVEN SPROCKET	6.82	8121 3020	SURF ORNAMENT	1.08
7381	8000	DRIVEN SPROCKET	7.20	8122 3006	ORNAMENT	.08
7381	8010	R SPROCKET AFT 16	7.26	8124 3011	CABLE PROTECTOR	.08
7381	8020	REAR SPROCKET 42T	15.88	8125 5020	GROMMET HEAD COVE	.18
7381	8030	REAR SPROCKET 46T	22.70	8125 8000	HEAD LAMP GROMMET	.58
7381	8040	REAR SPROCKET 50T	22.70	8126 3210	USE 8126 5000 NUT	.82
7381	8200	REAR SPROCKET	17.38	8126 5000	HEAD COVER SET NU	.82
7381	9000	DRIVEN SPROCKET	12.20	8140 5000	HEADLIGHT RIM	4.38
7386	3110	USE 09511 112 BOLT	.18	8140 5010	XCI HEADLITE RIM	5.62
7387	8010	LOCK WASHER	.18	8140 8000	USE 8140 8200 RIM	4.42
7393	9000	REAR WHEEL COMP	85.90	8140 8200	HEAD LAMP RIM COM	4.42
7402	3000	REAR WHEEL 225 X	57.36	8140 9000	HEAD LAMP RIM	7.28
7411	5010	SPROCKET 47T	35.00	8141 3002	HEAD LAMP RIM	4.00
7411	5020	DUAL SPROCKET 64T	41.80	8141 3010	HEAD LAMP RIM	9.30
7416	5010	SPROCKET 34T	5.80	8150 3002	HEAD LAMP LENS	5.20
7421	3002	USE 290 34501 200	4.02	8150 5000	LENS HEADLIGHT	5.42
7421	3110	REAR HUB SHAFT	4.02	8150 5020	HEAD LAMP LENS	5.62
7421	8000	REAR WHEEL AXLE	6.40	8150 8000	USE 8150 8200 LAMP	8.92
7421	8010	REAR AXLE AFT 16M	6.40	8150 8010	USE 8150 8200 LENS	8.92
7421	9000	REAR WHEEL AXLE	7.58	8150 8200	HEAD LAMP LENS	8.92
7422	3110	NUT REAR HUB SHAF	.72	8150 9000	HEAD LAMP LENS	10.40
7426	3001	REAR AXLE COLLAR	.26	8154 3000	SOCKET CLAMP	.26
7426	3110	REAR SHAFT COLLAR	1.20	8160 3004	SOCKET ASSY	1.40
7426	8000	REAR AXLE COLLAR	2.90	8160 3010	SOCKET ASSY	4.52
7426	9000	COLLAR-REAR AXLE	2.78	8160 5000	SOCKET HEADLIGHT	1.40
7427	3001	OIL SEAL COLLAR	.66	8160 5020	SOCKET COMP	3.90
7441	3000	WHEEL RIM	11.36	8160 8010	SOCKET COMP	2.20
7451	3000	USE 225 X 17 FSH TIR		8160 9000	USE 8160 8010 SOCKT	2.20
7451	5000	USE 250 X 17 RS TIRE		8171 3000	USE 8171 8010 BULB	1.52
7451	8000	USE 275 X 18 RA TIRE		8171 3010	HEAD LAMP BULB	1.16
7451	8010	USE 300 X 18 RA TIRE		8171 3020	USE 8171 5000 BULB	1.16
7451	9000	USE 325X19 RS10 TIRE		8171 3030	LIGHT BULB	1.16
7452	8000	USE 275 X 18 TUBE		8171 5000	BULB HEADLIGHT 6V	1.16
7453	5020	USE 7253 3000 BAND	.42	8171 8010	BULB-HEAD LAMP	1.52
7453	8000	TIRE FLAP	1.22	8172 5000	STOPPER LENS	.18
7501	3000	CHAIN ASSY	7.78	8173 3001	ADJUST NUT	.18
7501	3200	ROLLER CHAIN ASSY	7.72	8173 3010	USE 8173 9000 NUT	.18
7501	3210	ROLLER CHAIN 6OSP	8.66	8173 8000	USE 8173 9000 NUT	.18
7501	5000	ROLLER CHAIN ASSY	9.70	8173 9000	QUICK ACTING NUT	.18

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
8174	3000	ADJUSTING SPRING	.18	8401	8000	SPEEDOMETER	25.08
8174	3010	ADJUSTING SPRING	.26	8401	8200	SPEEDOMETER ASSY	25.08
8174	8000	USE 8174 3010 SPRNG	.26	8401	9000	SPEEDOMETER	24.90
8174	9000	ADJUSTER SPRING	.26	8402	3000	HORN ASSY	4.68
8175	3000	USE 8175 3010 NUT	.18	8402	3012	USE 8402 3600 HORN	4.52
8175	3010	SQUARE NUT	.18	8402	5000	USE 8402 3600 HORN	4.52
8175	8000	USE 8175 3010 NUT	.18	8402	5600	HORN ASSY 100T	4.52
8175	9000	SQUARE NUT	.18	8402	8000	HORN ASSY	7.98
8176	3000	ADJUSTING SCREW	.18	8402	8001	USE 8402 8000 HORN	7.98
8176	3010	ADJUSTING SCREW	.22	8402	9000	HORN ASSY	7.92
8176	8000	USE 8176 3010 SCREW	.22	8403	9000	TACHOMETER ASSY	24.90
8176	9000	ADJUSTER SCREW	.42	8404	9000	NEUTRAL LAMP	2.20
8177	3001	USE 8177 3010 SCREW	.18	8405	5000	HIGH BEAM SOCKET	.52
8177	3010	HOLDER SCREW	.18	8405	9000	HIGH BEAM LAMP	2.20
8177	8000	USE 8177 3010 SCREW	.18	8406	9000	5TH GEAR LITE SOC	1.06
8177	9000	HOLDER SCREW	.36	8421	3002	LAMP SOCKET	.46
8178	8010	SHIELD RUBBER	.82	8421	5000	SPEEDO LIGHT SOCK	.52
8179	8010	USE 8179 9000 RING	.08	8421	8000	SPEEDO LIGHT SOCK	.52
8179	9000	SOCKET SET RING	.08	8421	9000	LIGHT SOCKET	.52
8201	3010	BLE NOT AVAILABLE	.00	8422	3002	CHARGE SOCKET	.52
8201	3010	CBK COMBO LIGHT BLK 1	11.76	8423	3002	NEUTRAL LAMP SOCK	.52
8201	3010	CUR COMBO LIGHT RED 1	11.76	8423	5000	NEUTRAL LITE SOCK	.52
8201	3040	CBK COMBO LIGHT BLK 6	12.20	8423	8000	USE 8423 5000 SOCKT	.52
8201	3040	CUR COMBO LIGHT RED 6	12.20	8424	3000	SPEEDOMETER BULB	.50
8202	3110	TAIL LAMP ASSY	5.58	8424	3010	SPEEDOMETER BULB	.50
8202	5010	USE 8205 5011 LIGHT	13.66	8424	8000	SPEEDOMETER BULB	.58
8203	3010	REFLECTOR ASSY	2.66	8427	3000	SPEEDO GASKET	.08
8205	3011	TAIL LIGHT ASSY	13.66	8428	9000	WASHER SPEEDOMETE	.58
8205	5011	TAIL LIGHT ASSY	13.66	8429	5010	SPEEDOMTR SET SPR	.58
8205	5021	TAIL LIGHT ASSY	13.66	8429	5020	SPEEDOMETER SET S	.58
8205	8000	TAIL LAMP ASSY	13.20	8429	9000	SET SPRING INSTRM	.36
8205	9000	TAIL LAMP ASSY	19.26	8435	8200	CUSHION RUBBER	1.92
8206	5610	FT REFLECTOR ASSY	2.92	8435	9000	METER CUSHION	1.92
8207	5610	REAR REFLECTOR AS	3.22	8443	3210	USE 3443 3210 SUPPT	5.26
8207	8200	REAR REFLECTOR AS	3.22	8501	3000	IGNITION COIL	11.56
8207	9010	REAR REFLECTOR AS	3.00	8501	5001	IGNITION COIL	18.48
8211	3001	COMBO LIGHT BODY	4.30	8501	5600	IGNITION COIL	18.48
8240	3010	TAIL LIGHT BASE	2.98	8501	8000	IGNITION COIL	25.08
8240	3030	TAIL LAMP BASE	6.02	8502	8010	USE 8502 9000 COIL	24.92
8240	5010	SUCKET ASSY	5.96	8502	9000	L IGNITION COIL	24.92
8251	3001	TAILLIGHT LENS	2.58	8503	8010	USE 8503 9000 COIL	24.92
8251	3020	TAILLITE LENS	4.08	8503	9000	R IGNITION COIL	24.92
8251	3110	TAIL LAMP LENS	1.76	8520	5000	PLUG CAP	1.00
8251	8000	TAIL LAMP LENS	3.40	8520	5010	USE 8520 5000 CAP	1.00
8251	9000	LENS TAIL LIGHT	3.62	8521	3000	SPARK PLUG CAP	.92
8252	3000	BULB TAILLIGHT 12	.50	8531	3000	IGNITION WIRE	.92
8252	3020	TAIL LAMP BULB	.50	8535	3000	COIL IGNITION WIR	.82
8252	3030	USE 8252 3031 BULB	.82	8601	3002	MAIN SWITCH 7D	4.22
8252	3031	BULB TAIL LIGHT	.82	8601	3013	MAIN SWITCH 7S	4.22
8252	3040	TAIL LIGHT BULB	1.78	8601	3100	MAIN SWITCH	5.12
8253	3020	TAIL LENS PACKING	.18	8601	3200	MAIN SWITCH	6.88
8253	8000	TAIL LAMP GASKET	.58	8601	5000	MAIN SWITCH ASSY	6.20
8253	9000	GASKET TAIL LAMP	.76	8601	5010	SWITCH	4.60
8256	3010	GROMMET TAILLIGHT	.08	8601	5020	MAIN SWITCH ASSY	6.88
8259	3001	DISTANCE PIECE	.08	8601	5600	MAIN SWITCH	10.50
8271	5610	REFLECTOR FRONT	2.48	8601	8000	MAIN SWITCH ASSY	10.50
8272	5610	REFLECTOR BRACKET	.60	8601	9000	MAIN SWITCH	10.42
8281	5610	REFLECTOR REAR	2.48	8602	8000	STOP SWITCH ASSY	3.96
8281	9010	USE 8207 9010	3.00	8603	8000	USE 6803 8000 SWTCH	2.88
8282	5610	REAR REFLECTOR CL	.82	8621	3002	11 ENGINE KEY 11	.50
8282	8200	REFLECTOR CLAMP	.82	8621	3002	12 ENGINE KEY 12	.50
8283	5610	REAR REFLECTOR SP	.26	8621	3002	13 ENGINE KEY 13	.50
8283	8200	REFLECTOR SPACER	.26	8621	3002	14 ENGINE KEY 14	.50
8303	3101	L TURN SIGNAL	2.40	8621	3002	77 ENGINE KEY 77	.50
8304	3101	R TURN SIGNAL	2.40	8621	3002	78 ENGINE KEY 78	.50
8305	3002	TURN SIGNAL UNIT	3.22	8621	3002	79 ENGINE KEY 79	.50
8305	3012	FLASHER UNIT	3.22	8621	3002	80 ENGINE KEY 80	.50
8331	3101	FT TURN SIGNAL LE	.50	8621	3011	67 ENGINE KEY 67	.50
8332	3000	BULB REAR SIGNAL	.50	8621	3011	68 ENGINE KEY 68	.50
8332	3010	TURN SIGNAL BULB	.50	8621	3011	69 ENGINE KEY 69	.50
8332	3020	WINKER BULB	.50	8621	3011	70 ENGINE KEY 70	.50
8332	3100	TURN SIGNAL BULB	.42	8622	3000	NOT AVAILABLE	.00
8332	3110	BULB FRONT SIG 12	.42	8627	5600	MAIN SWITCH BRACK	1.78
8352	3000	REAR SIGNAL BASE	1.16	8650	3000	USE 8650 5000 SWTCH	2.90
8362	3000	REAR SIGNAL BASE	1.16	8650	5000	STOP SWITCH	2.90
8371	3000	LENS REAR SIGNAL	1.16	8661	3001	STOP SWITCH SPRIN	.42
8371	3011	WINKER LENS	1.06	8661	5000	USE 8661 3001 SPRNG	.42
8371	3100	REAR SIGNAL LENS	.46	8661	5001	SPRING STOP SWITC	.42
8401	3004	MILE SPEEDOMETER	16.78	8661	5600	STOP SWITCH SPRIN	.42
8401	3030	SPEEDOMETER	17.26	8661	9000	SPRING STOP SWITC	.26
8401	3210	SPEEDOMETER	17.76	8701	3002	BATTERY 12V-6A	16.62
8401	5001	NOT USED	.00	8701	3032	USE 8701 3002 BATTY	16.62
8401	5011	SPEEDOMETER	20.20	8701	3040	BATTERY 6V 2A	6.76
8401	5030	SPEEDOMETER	20.20	8701	3050	USE 8701 3040 BATTY	6.76

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST			
8701	5010	BATTERY 6V-3A	9.88	9387	9010	40MM NUT WRENCH	11.82	
8702	3001	RECTIFIER ASSY	1.82	9388	9010	SOCKET BAR	1.52	
8702	3200	USE 8702 5000 RECTR	3.56	9389	9010	CLUTCH HUB STOPPE	13.36	
8702	5000	RECTIFIER ASSY	3.56	9391	9010	CLUTCH STOPPER	12.88	
8702	8000	RECTIFIER ASSY	14.80	9392	9010	NOT AVAILABLE	.00	
8703	3001	REGULATOR ASSY	27.26	9393	9010	GEAR STOPPER	7.32	
8703	9000	REGULATOR	26.08	9411	3000	INNER CABLE	1.08	
8802	3011	FUSE ASSEMBLY	1.08	9411	5000	INNER CABLE	1.32	
8802	3021	FUSE ASSEMBLY	1.08	9411	8000	INNER CABLE	1.32	
8802	3030	FUSE ASSY	1.08	9411	8200	INNER CABLE	1.66	
8802	3200	FUSE ASSY	1.00	9412	3000	OUTER TUBE METER	1.58	
8802	5000	FUSE ASSY	1.00	9421	3001	CABLE A CLUTCH	1.08	
8802	8000	FUSE ASSY	1.40	9422	3001	CABLE B CLUTCH	1.66	
8802	9000	FUSE ASSEMBLY	1.36	9423	3000	CABLE CONNECTOR	.50	
8810	3000	WIRE HARNESS	5.42	9424	3000	WIRE HOOK	.18	
8810	3011	WIRE HARNESS	3.62	9425	3000	CLIP CLUTCH CABLE	.08	
8810	3100	WIRE HARNESS	7.02	07	6001	01	BALL BEARING	2.98
8810	3200	USE 8810 5010 WIRE	4.38	07	6003	01	BALL BEARING	3.40
8810	5010	WIRE HARNESS	4.38	07	6005	01	BALL BEARING	3.72
8810	5600	WIRE HARNESS	7.46	07	6006	01	BALL BEARING	4.60
8810	5610	WIRE HARNESS	8.78	07	6007	01	BALL BEARING	5.66
8811	5610	USE 8810 5610 WIRE	8.78	07	6201	01	USE 07 6201 03 BEAR	3.06
8811	8000	WIRE HARNESS	4.60	07	6201	03	BALL BEARING 6201	3.06
8811	9000	WIRE HARNESS	7.58	07	6202	41	USE 999 61620 202	2.60
8813	5610	SUB WIRE HARNESS	.98	07	6203	03	BALL BEARING	3.22
8813	8200	SUB WIRE HARNESS	.98	07	6204	23	BALL BEARING	3.96
8813	9010	SUB WIRE HARNESS	1.00	07	6204	43	BALL BEARING	3.96
8821	5000	USE 8810 5010 WIRE	4.38	07	6302	01	USE 07 6302 03 BEAR	3.40
8822	3000	BATTERY WIRE	.42	07	6302	03	BALL BEARING	3.40
8824	5010	CONNECTOR	.76	07	6302	43	BALL BEARING	3.16
8825	8000	CONNECTING WIRE	.26	07	6303	01	USE 07 6303 03 BEAR	3.96
8829	3001	COVER TUBE	.66	07	6303	03	BALL BEARING	3.96
8831	3000	WIRE EARTH	.66	07	6303	43	BALL BEARING	3.88
8831	8000	BODY EARTH WIRE	.82	07	6304	01	USE 07 6304 03 BEAR	3.78
8831	9000	EARTH WIRE	.82	07	6304	03	BALL BEARING	3.78
8831	9010	BODY EARTH WIRE	.82	07	6304	61	BALL BEARING	4.08
8833	5001	EARTH WIRE	.58	07	6305	63	BALL BEARING	4.98
8834	5000	EARTH WIRE	.26	07	6403	43	BALL BEARING	7.02
8835	5000	USE 8833 5001 WIRE	.58	09001	101	47 SNAP RING	.58	
8836	8200	STOP SWITCH CONNE	.82	09002	101	12 SNAP RING	.42	
8852	3031	USE 8252 3031 BULB	.82	09002	102	28 SNAP RING	.36	
8861	3000	USE 8861 3020 FUSE	.18	09002	103	17MM CIRCLIP	.26	
8861	3010	FUSE 6V	.18	09002	104	16 SNAP RING	.26	
8861	3020	FUSE	.18	09002	105	20B SNAP RING	.26	
8861	3030	FUSE 12V	.18	09002	107	25B SNAP RING	.36	
9116	5010	OIL INJECTION LAB	1.00	09002	108	18B SNAP RING	.18	
9116	8000	OIL INJECTION LAB	.58	09004	101	10 SNAP RING	.18	
9201	3000	TOOL KIT	4.08	09004	102	10D SNAP RING	.08	
9201	3201	SERVICE TOOL SET	5.42	09006	101	15MM SNAP RING	.26	
9201	5000	STD TOOL SET	8.66	09006	102	15 SNAP RING	.18	
9201	8000	SERVICE TOOL SET	10.22	09006	103	11 SNAP RING	.26	
9201	9000	SERVICE TOOL SET	13.38	09006	104	15 SNAP RING	.26	
9211	3001	NUT AVAILABLE	.00	09008	101	16B CIRCLIP	.08	
9211	5000	TOOL BAG	.76	09011	101	12 X 10 HEX BOLT	.36	
9212	3001	8X9 SPANNER	.66	09011	102	8X100 HEXAGON BOL	.52	
9213	5000	10MM HANDLE DRIVE	.76	09011	103	6X90 HEXAGON BOLT	.26	
9215	5000	10X12 SPANNER	1.40	09011	106	6 X 70 HEX BOLT	.18	
9216	3000	10X14 DOUBLE SPAN	1.76	09012	105	20B SNAP RING	.82	
9217	5000	14X17 SPANNER	2.30	09016	101	6X40 STUD	.42	
9218	3000	USE 823 20000 200 SK	.82	09016	106	8 X 60 STUD	.42	
9218	5000	BUX SPANNER	.82	09016	113	8 X 50 STUD	.42	
9219	8000	BUX WRENCH 10X12	1.32	09016	114	8 X 156 STUD	1.18	
9221	8000	AXLE WRENCH	2.56	09021	101	14 HEX NUT	.26	
9225	5000	PLIERS	2.58	09021	102	16 HEXAGON NUT	.36	
9226	5000	DRIVER NO 1	.76	09021	103	12MM HEX NUT	.18	
9227	3000	SCREW DRIVER B	.82	09021	104	6MM HEX NUT LONG	.18	
9228	5000	DRIVER	.76	09028	101	40 RING NUT	2.10	
9231	3000	DRIVER GRIP	.50	09029	101	14 LEFT THREAD NU	.42	
9236	8000	TIMING BOLT	.86	09029	102	LEFT THREAD NUT	.18	
9237	8000	TIMING PIN 3MM	.98	09029	103	10MM LEFT TURN NU	.42	
9237	8010	TIMING PIN 5MM	.98	09029	104	20L THREAD NUT	.58	
9300	3010	SPECIAL TOOLS	25.00	09040	112	USE 09041 112 WASH	.08	
9300	3110	SPECIAL TOOLS	25.00	09041	101	17MM PLAIN WASHER	.18	
9300	5010	SPECIAL TOOLS	25.00	09041	102	10 PLAIN WASHER	.08	
9300	9010	350 SP TOOLS ONLY	48.00	09041	104	15 PLAIN WASHER	.18	
9301	3010	BEARING PULLER	11.50	09041	105	14 PLAIN WASHER	.08	
9328	3001	CLUTCH TOOL	2.72	09041	106	15MM WASHER	.08	
9373	5000	NOT AVAILABLE	.00	09041	107	WASHER	.08	
9374	5000	NUT AVAILABLE	.00	09041	108	10 PLAIN WASHER	.08	
9375	5000	MAGNETO PULLER	7.98	09041	109	15MM WASHER	.26	
9376	5010	NOT AVAILABLE	.00	09041	110	16 PLAIN WASHER	.08	
9378	8010	CARB GAGE	3.86	09041	111	7 PLAIN WASHER	.08	
9379	8010	CLUTCH TOOL	5.92	09041	112	6 PLAIN WASHER	.08	
9386	9010	28MM SOCKET	11.06	09041	113	10 PLAIN WASHER	.08	

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
09041	114	4 PLAIN WASHER	.08	09066	128	5 O RING	.18
09041	115	USE 09041 106 WASH	.08	09067	101	USE 0671 3013 KEY	.18
09045	101	TOOTH WASHER	.08	09067	102	USE 0671 3013 KEY	.18
09045	102	TOOTHED WASHER	.18	09070	109	NEEDLE BEARING	2.90
09045	103	20 EXTERNAL WASHE	.42	09070	110	NEEDLE BEARING	3.40
09046	101	10 WAVE WASHER	.18	09070	112	NEEDLE BEARING	2.52
09046	102	USE 09546 104 WASH	.08	09070	113	NEEDLE BEARING	2.78
09046	104	12 WAVE WASHER	.18	A 09070	113	1 PIECE BEARING	5.56
09046	105	15 WAVE WASHER	.18	A 09071	101	ROLLER BEARING O/	5.66
09047	101	14 LOCK WASHER	.26	A 09071	101	BEARING PINNED TY	5.66
09047	102	6 LOCK WASHER	.08	09075	101	USE 09071 101 BEAR	5.66
09047	103	17 LOCK WASHER	.26	09075	102	BALL BEARING	5.66
09047	104	16 LOCK WASHER	.26	09075	103	BALL BEARING	3.40
09047	106	40 LOCK WASHER	.26	09075	104	BALL BEARING	6.80
09048	101	12 THRUST WASHER	.36	09075	106	BALL BEARING	6.80
09048	102	13 THRUST WASHER	.36	09090	101	12 OIL SEAL	.86
09048	103	12 THRUST WASHER	.18	09090	102	15 OIL SEAL	.82
09048	104	15 THRUST WASHER	.42	09090	103	15 OIL SEAL	.82
09048	105	16 THRUST WASHER	.26	09090	104	17 OIL SEAL	.92
09048	106	17 THRUST WASHER	.08	09090	105	20 OIL SEAL	.92
09048	107	20 THRUST WASHER	.18	09090	106	20 OIL SEAL	.92
09048	111	20 THRUST WASHER	.26	09090	107	21 OIL SEAL	1.08
09048	112	20MM THRUST WASHE	.90	09090	108	25 OIL SEAL	1.66
09048	113	22MM SPLINE WASHE	1.18	09090	109	28 OIL SEAL	1.16
09048	114	20 THRUST WASHER	.58	09090	110	20 OIL SEAL	1.58
09048	115	17 THRUST WASHER	.42	09090	111	20 OIL SEAL	.82
09048	116	22 THRUST WASHER	.82	09090	112	18 OIL SEAL	1.16
09048	117	25 THRUST WASHER	.58	09090	113	20 OIL SEAL	1.16
09048	118	18 THRUST WASHER	.36	09090	116	28 OIL SEAL	1.58
09048	119	8 THRUST WASHER	.26	09090	117	57 OIL SEAL	1.82
09049	101	SHIM D 02MM	.18	09090	118	32 OIL SEAL	1.82
09049	102	SHIM E 03MM	.18	09090	119	47 OIL SEAL	1.68
09049	103	28 X 2 SHIM	.26	09090	124	22 OIL SEAL	1.18
09049	104	10 X 2 SHIM	.18	09090	126	25 OIL SEAL	1.68
09049	105	15 X 2 SHIM	.08	09501	101	42 A SNAP RING	1.00
09049	106	20X03 SHIM	.26	09501	102	47 A SNAP RING	1.16
09049	108	30 X .3 SHIM	.18	09502	101	14 B SNAP RING	.26
09049	109	25 X .3 SHIM	.18	09502	102	62B SNAP RING	1.80
09056	102	4X8 A DOWEL	.36	09502	103	788 SNAP RING	2.36
09056	105	6 X 10 DOWEL	.30	09504	101	5 D SNAP RING	.08
09056	106	USE 09063 104 ROLLR	.26	09507	101	40 SNAP RING	.32
09056	109	3 X 24A DOWEL	.08	09511	101	8X108 HEXAGON BOL	.68
09056	111	5X10 DOWELL	.26	09511	102	HEX BOLT	.32
09056	112	4 X 18 A DOWEL	.26	09511	103	HEX BOLT	.26
09057	101	6X10X108 DOWEL	.18	09511	104	12X38 HEX BOLT	.30
09057	102	8X12X148 DOWEL	.26	09511	105	8X28 HEX BOLT	.26
09058	101	14 DRAIN PLUG	.50	09511	106	8X62 HEX BOLT	.42
09058	102	16 DRAIN PLUG	1.00	09511	110	HEX BOLT	.32
09058	103	16 DRAIN PLUG	.82	09511	112	HEX BOLT	.18
09059	101	USE 09056 112 PIN	.26	09511	113	BOLT	.36
09062	101	8 X 8 ROLLER	.18	09511	114	BOLT	.36
09062	102	5 X 8 ROLLER	.18	09511	115	BOLT	.26
09062	103	3X15 DOWEL	.08	09511	116	AXLE PIPE BOLT	.26
09062	104	USE 09056 105 PIN	.30	09511	119	5X36 MM HEX BOLT	.26
09063	102	NOT AVAILABLE	.00	09511	121	USE 0122 1032 BOLT	.26
09063	103	NEEDLE ROLLER	.08	09511	124	8 X 26 HEX BOLT	.76
09063	104	3X10 ROLLER	.26	09511	125	8 X 32 HEX BOLT	.76
09064	101	14 FIBER GASKET	.08	09511	126	5X8 HEX BOLT	.08
09064	102	6 FIBER GASKET	.08	09511	127	12X50 HEXAGON BOL	.40
09064	103	8 FIBER GASKET	.08	09511	128	6X71 HEXAGON BOLT	.26
09065	101	12 ALUM WASHER	.08	09511	129	USE 09511 127 BOLT	.40
09065	102	16MM GASKET	.18	09511	130	USE 0133-0836 BOLT	.82
09065	103	6 ALUMINUM GASKET	.08	09511	131	6X45 HEXAGON BOLT	.18
09065	104	8 ALUMINUM GASKET	.08	09511	132	6X25 HEXAGON BOLT	.18
09066	101	20 O RING	.42	09511	133	8X98 HEX BOLT	.36
09066	102	17MM O RING	.42	09511	137	10X25 HEX BOLT	.42
09066	103	100 O RING	1.16	09511	138	10X30 HEX BOLT	.82
09066	104	23 O RING	.36	09511	142	10 X 32 HEX BOLT	.42
09066	105	14MM O RING	.38	09511	143	6X144 HEX BOLT	.42
09066	106	7 O RING	.26	09511	145	10 X 145 HEX BOLT	1.10
09066	107	21 O RING	.58	09511	146	10 X 35 HEX BOLT	.26
09066	111	10 O RING	.26	09511	147	8 X 26 HEX BOLT	.76
09066	112	20 O RING	.66	09511	148	6 X 18 HEX BOLT	.18
09066	117	6 O RING	.26	09511	149	12 X 45 HEX BOLT	.58
09066	118	15 O RING	.36	09511	150	10 X 38 HEX BOLT	.42
09066	119	17 O RING	.42	09511	153	12 X 60 HEX BOLT	2.42
09066	120	59 O RING	.58	09511	154	12 X 20 HEX BOLT	.36
09066	121	125 O RING	1.58	09516	101	6X82 STUD	.26
09066	122	33 O RING	.36	09521	102	USE 0231 1200 NUT	.18
09066	123	18 O RING	.36	09521	103	12 HEX NUT SPEC	.26
09066	124	35 O RING	.36	09521	106	USE 0261 1000 NUT	.18
09066	125	12 O RING	.18	09521	107	EXH PIPE CLAMP NU	.18
09066	126	20 O RING	.42	09522	101	HEX SLOTED NUT	.18
09066	127	13.5 O RING	.18	09522	102	HEX SLOTED NUT	.58

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
09522 103	HEX SLOTTED NUT	.18	09566 108	27 O RING	.80
09522 105	12 SLOTTED NUT	.26	09566 109	NOT AVAILABLE	.00
09524 101	12MM PAL NUT	.26	09566 110	50 O RING	.42
09525 101	12MM CAP NUT	.66	09566 112	9 O RING	.42
09525 102	BLIND NUT 8MM	.50	09590 101	32 OIL SEAL	.42
09525 104	6MM CAP NUT	.26	09590 102	20 OIL SEAL	1.00
09525 105	BLIND NUT	.42	09590 103	17 OIL SEAL	.42
09529 101	5 LEFT THREAD NUT	.42	09590 104	20 OIL SEAL	.92
09531 101	DRAIN PLUG	.08	09590 105	40 OIL SEAL	1.08
09531 102	USE 0311 0608 SCREW	.08	09590 106	17 OIL SEAL	.92
09534 101	SCREW	.26	09590 107	23 OIL SEAL	1.00
09534 102	OVAL HD SCREW	.08	09590 108	27 OIL SEAL	2.16
09535 102	35X48 DRAIN SCREW	.08	09590 109	27 OIL SEAL	2.16
09541 101	12 PLAIN WASHER	.08	09590 110	22 OIL SEAL	1.16
09541 102	12 PLAIN WASHER	.18	09590 111	48 OIL SEAL	1.40
09541 103	15 PLAIN WASHER	.18	09590 112	22 OIL SEAL	1.16
09541 104	11MM PLAIN WASHER	.08	09590 113	28 OIL SEAL	1.32
09541 105	6MM PLAIN WASHER	.18	09590 115	32 OIL SEAL	2.30
09541 107	USE 0411 1022 WASH	.08	09590 116	26 OIL SEAL	2.16
09541 108	13 PLAIN WASHER	.08	09590 120	OIL SEAL	2.16
09541 109	14 PLAIN WASHER	.08	09590 121	28 OIL SEAL	1.40
09541 111	USE 0411 1022 WASH	.08	09590 122	34 OIL SEAL	2.28
09541 117	12 PLAIN WASHER	.18	09590 123	28 OIL SEAL	1.42
09541 118	18 PLAIN WASHER	.18			
09541 119	USE 09541 109 WASH	.08			
09541 120	10 PLAIN WASHER	.18			
09541 121	8 PLAIN WASHER	.18			
09541 123	6 PLAIN WASHER	.16			
09546 101	WAVE WASHER	.10			
09546 102	10 WAVE WASHER	.42			
09546 103	8 WAVE WASHER	.26			
09546 104	WAVE WASHER	.08			
09548 101	14 THRUST WASHER	.36			
09555 101	USE 0551 1612 PIN	.08			
09564 101	10 FIBER GASKET	.08			
09566 101	40 O RING	.50			
09566 102	33 O RING	.42			
09566 103	29 O RING	.42			
09566 104	10 O RING	.42			
09566 105	USE 09566 110 RING	.42			
09566 106	18 O RING	.26			
09566 107	40 O RING	.50			

# ROCKFORD MODELS CHIBI, CHIBI DELUXE, TORA, TORA DELUXE, AND TAKA

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
002	11501 801	CYLINDER	28.36	114	34301 201	CLUTCH LEVER	1.50
002	11504 800	CYLINDER	28.98	114	34301 202	CLUTCH LEVER	1.50
009	34501 200	FRAME NUMBER PLT	.30	114	34501 200	USE 6122-8000 LEVER	2.90
014	11504 200	USE 014 11504 800	8.62	115	34301 200	USE 115 34301 202	1.50
014	11504 800	CYLINDER HEAD	8.62	115	34301 201	FRONT BRAKE LEVER	1.50
046	11501 800	USE 046 11501 801	30.76	115	34301 202	BRAKE LEVER	1.50
046	11501 801	CRANKSHAFT COMPLE	30.76	115	34501 200	USE 6152-8000 LEVER	2.90
046	12601 800	CRK SFT COMPL.	43.10	116	34301 200	USE 116 34301 201	1.82
048	34501 200	SLEEVE	2.50	116	34301 201	GRIP PIPE RH	1.82
049	34501 200	SLEEVE	2.50	116	34401 200	GRIP PIPE RH	1.68
050	34301 800	FRAME	47.52	116	34501 200	GRIP PIPE	1.68
050	34301 801	FRAME	43.20	118	34301 200	GRIP RUBBER RH	1.26
050	34302 800	FRAME COMPLETE	49.20	118	34401 200	GRIP RUBBER RH	1.42
050	34401 800	FRAME	51.84	118	34501 200	GRIP RUBBER R.H.	1.78
050	34402 800	FRAME	44.78	120	34301 200	CHOKE LEVER	.32
050	34501 801	FRAME	76.38	120	34301 201	CHOKE LEVER	.32
059	11501 200	CRANK SHAFT LEFT	13.80	120	34501 200	CHOKE LEVER	1.42
060	34301 200	FRONT RUBBER TANK	.42	121	34301 200	USE 0411 0613 WASH	.08
060	34501 200	TNK SPT RBR FRT	.36	121	34501 200	CHOKE LVR WASHER	.08
068	11501 200	WOODRUFF KEY	.36	122	34301 200	SPECIAL 5M M BOLT	.26
068	34301 800	FOOTREST SHAFT	5.70	123	34301 201	SWITCH SPRING	.26
068	34501 800	FOOT REST SFT COM	6.26	124	34301 201	SWITCH BUTTON	.20
076	11504 800	USE 076 11504 200	26.12	124	35100 200	CLIP	.06
076	11504 200	CRANKCASE RH	26.12	126	34501 200	USE 6126-5600 ADJTR	1.78
076	34301 200	ENGINE STAY	.58	127	34501 200	CHOKE LEVER BODY	1.26
076	34302 200	ENGINE STAY	1.00	128	34501 200	USE 6127-5600 NUT	.86
076	34401 800	ENGINE STAY COMPL	5.76	129	34301 201	STOP WIRE	1.16
077	11504 800	CRANK CASE LH	27.60	130	34501 800	HORN CORD COMPL.	2.20
087	34301 800	REAR FENDER	5.36	131	34501 200	USE 6125-8000 HOLDR	2.30
087	34302 800	REAR FENDER COMP	6.90	132	34501 200	FNT BRK LVR HLDR	3.22
087	34401 800	REAR FENDER COMPL	7.28	134	34401 800	LAMP CORD COMPL A	.86
087	34402 800	REAR FENDER COMPL	5.56	134	34402 200	STOP LAMP CORD	1.68
087	34501 800	REAR FENDER COMPL	13.92	134	34501 200	STOP LMP CORD COM	1.48
091	34301 200	OUTER RACE UPPER	1.68	135	34401 800	IGNITION WIRE B	.86
091	34401 200	RACE OUTER UPPER	1.68	135	34402 200	TAIL LAMP CORD	.86
091	34501 200	USE 091 34501 201	2.10	135	34501 200	TAIL LMP CORD COM	1.72
091	34501 201	RACE OUTER UPPER	2.10	137	34501 200	SWITCH PLUG	.76
092	34301 200	INNER RACE UPPER	.92	142	34401 200	PACKING	.06
092	34401 200	INNER RACE UPPER	2.10	148	34501 200	STEERING LOCK NUT	3.10
092	34501 200	INNER RAISE UPPER	1.68	149	34501 200	ENGINE BRKT R.H.	1.52
094	34301 200	OUTER RACE LOWER	1.26	150	20900 900	MAGNETO ASSY	32.72
094	34501 200	USE 094-34501-201	2.10	150	20901 900	MAGNETO ASSEMBLY	38.38
094	34501 201	OTR RACE LOWER	2.10	150	20902 900	MAGNETO ASSY	39.00
095	34301 200	INNER RACE LOWER	.82	150	21200 900	MAGNETO ASSEMBLY	55.16
096	34301 200	RACE LOCK NUT	.50	150	34301 800	HANDLE CLAMP KNOB	3.36
096	34401 200	RACE LOCK NUT	1.66	155	20900 800	FLYWHEEL MAGNETO	29.70
097	34501 200	RACE COVER	3.92	155	20902 800	FLYWHEEL MAGNETO	29.76
098	34501 200	ENGINE BRKT L.H.	1.52	155	21200 800	FLYWHEEL MAGNETO	49.20
100	12000 200	6X26 STUD BOLT	.08	153	20900 900	USE 167 20900 900	12.56
100	34301 800	USE 100 34301 801	7.58	155	34401 200	HANDLE BAR HOLDER	1.52
100	34301 801	HANDLE COMPLETE L	7.58	155	34501 200	HNDL HOLDER UPPER	1.60
100	34401 200	USE 100 34401 800	11.40	156	34401 800	HANDLE BAR HOLDR	2.36
100	34401 800	HANDLE BAR	11.40	159	20900 900	MAGNETO BASE ASSY	25.94
100	34501 800	HANDLE BAR	14.00	159	20901 900	MAGNETO BASE ASSY	27.06
101	34301 800	USE 101 34301 801	7.58	159	20902 900	MAGNETO BASE ASSY	34.44
101	34301 801	HANDLE COMPLETE R	7.58	159	21200 900	MAGNETO BASE ASSY	46.70
105	34301 200	GRIP L H	1.26	159	34301 900	USE 159 20901 900	27.06
105	34401 200	HANDLE GRIP LH	2.10	160	34301 800	NOT AVAILABLE	.00
105	34501 200	GRIP RUBBER L.H.	2.06	161	34301 800	FORK ASSY	15.52
106	34301 200	USE 106 34301 901	3.10	161	34302 800	FORK SUPPORT COMP	17.60
106	34301 900	USE 106 34301 901	3.10	162	34401 200	FORK SUPPORT PLAT	2.96
106	34301 901	HANDLE GRIP ASSY	3.10	162	34501 200	FURK UPPER BRIDGE	14.82
106	34401 900	HANDLE GRIP ASSY	3.10	164	34401 800	FRONT FORK PIPE	15.52
107	34301 900	USE 107 34301 901	1.86	164	34501 200	FRONT FORK PIPE	19.36
107	34301 901	STOP SWITCH SET	1.86	165	34401 800	FORK BRIDGE LOWER	23.32
110	34301 200	USE 110 34301 202	1.68	165	34501 800	FK BRGS LOW COMPL	27.88
110	34301 200	USE 110 34301 202	1.68	166	34301 200	FORK CUSHION RUBB	.50
110	34301 201	USE 110 34301 202	1.68	167	20900 900	IGNITION COIL ASS	12.56
110	34301 202	SWITCH BOX UPPER	1.68	167	21200 900	IGNITION COIL	14.72
110	34501 200	SWTCH BOX UP L.H.	2.52	168	20900 800	CONTACT BREAKER	6.26
111	34301 200	USE 111 34301 202	1.00	168	21200 800	CONTACT BREAKR AS	8.32
111	34301 201	USE 111 34301 202	1.00	169	34301 800	FORK HANDLE HOLDE	17.92
111	34301 202	SWITCH BOX LOWER	1.00	169	34301 801	FURK HANDLE HOLDE	17.92
111	34501 200	SWTH BOX LOW L.H.	2.40	170	20900 200	PRIMARY COIL	9.30
112	34301 200	NOT AVAILABLE	.00	170	20902 200	PRIMARM COIL	9.32
112	34301 201	NOT AVAILABLE	.00	170	21200 200	PRIMARY COIL	9.32
112	34301 202	SWITCH BOX UPPER	1.42	171	20901 800	LAMP COIL COMPL	13.80
112	34402 200	SWT BOX UPPER RH	1.42	171	20902 800	LIGHTING COIL	13.80
112	34501 200	SWTH BOX UPPER RH	2.16	171	21200 200	LIGHTING COIL	9.32
113	34301 200	NOT AVAILABLE	.00	171	34301 800	LOWER FORK PIPE R	12.08
113	34301 201	NOT AVAILABLE	.00	171	34401 200	USE 171 34401 800	11.06
113	34301 202	SWITCH BOX LOWER	1.00	171	34401 800	FRONT FORK BOT	11.06
113	34501 200	SWTH BOX LOWER RH	2.62	171	34501 200	FNT FK BTM CE RH	15.72
114	34301 200	USE 114 34301 202	1.50	173	34301 200	FORK UPPER BUSHIN	.38

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST				
173	34401	200	FORK PIPE GUIDE	1.96	242	34401	200	CRANKCASE COV LH	11.72
173	34501	200	FORK PIPE GUIDE	2.66	243	34302	200	CONTACT BREAKER C	3.78
174	34301	200	FURK BOTTOM BUSHI	.32	243	34401	200	CONTACT BREAKER C	3.78
174	34401	200	FRONT FORK PISTON	2.10	243	34501	200	CONT BRKR COVER	2.46
174	34501	200	FNT FURK PISTON	2.50	249	11501	200	DRAIN SPONGE	.08
177	20900	900	CUNDENSER	3.82	249	34501	200	DRAIN SPONGE	.48
178	34401	200	STOPPER RING	.10	250	20900	200	WIRE AND GROMMET	1.68
178	34501	200	STOPPER RING	.18	250	20901	200	WIRE & GROMMET	1.96
180	34301	200	FRONT SHAFT SPACE	.50	250	20902	200	WIRE HARNESS GROM	.10
182	34301	200	HANDLE HOLDER WAS	.06	250	21200	200	WIRE HARNESS GROM	3.68
182	34401	200	FORK SUPPORT WASH	.42	251	12110	200	SPARK PLUG CAP	.68
182	34501	200	FK SUPPORT WASHER	.10	251	34301	200	SWING SHAFT	2.50
183	34301	800	LOWER FORK PIPE L	12.08	251	34301	201	R FORK SWING SHAF	2.50
183	34501	200	FNT FK BM CSE LH	15.72	251	34401	200	USE 251 34401 201	1.78
184	34401	900	FRONT FORK PIPE A	26.70	251	34401	201	R FORK SWING SHAF	1.78
184	34501	900	FNT FK PPE ASY LH	41.40	251	34501	200	REAR FK SWG SHAFT	3.68
185	20900	900	OIL SLIPPER	.26	252	20900	900	CLAMP	.26
185	34501	900	FT FORK PIPE RH	41.40	252	21200	200	CLAMP	.32
186	34501	200	FNT FORK OIL SEAL	3.82	252	34301	200	SWING SHAFT COVER	.16
187	34301	200	FORK BOOT	2.50	252	34401	200	FORK SWING METAL	.10
187	34401	200	DUST SEAL	2.10	260	34301	200	CHAIN CASE SILVER	2.50
187	34501	200	DUST SEAL 31	1.88	260	34302	200	CHAIN CASE TGERIN	3.82
188	34301	200	STEERING SHIM	.06	260	34401	200	CHAIN CASE YELLOW	1.90
188	34501	200	STEERING SHIM	.16	260	34501	800	CHAIN CASE RED	5.76
189	34401	200	FORK SUPPORT WASH	.30	261	34301	800	CHAIN CASE STAY C	.68
190	34301	200	USE 190 34301 201	1.76	261	34401	800	CHAINCASE STAY CO	.42
190	34301	201	FORK SPRING	1.76	265	34301	800	REAR FORK BLUE	20.00
190	34401	200	FRONT CUSHION SPR	2.10	265	34301	801	REAR FORK BLUE	16.20
190	34501	200	CUSHION SPRING	2.96	265	34302	800	REAR FORK TGERINE	18.62
191	34401	800	HEAD LAMP BRACKET	1.60	265	34401	800	REAR FORK BLACK	15.88
191	34501	200	HEAD LAMP BRKT	2.50	265	34501	800	REAR FORK BLACK	25.80
192	34401	200	FORK PISTON SNAP	.26	274	34301	200	USE 4851 5000	1.48
192	34501	200	FNT FK SNAP RING	.30	274	34301	201	REAR FORK BUSHING	1.00
193	34401	200	CIRCLIP	.42	277	34301	200	REAR FORK COLLAR	.68
193	34501	200	CIRCLIP 31	.72	282	34301	200	FRONT HUB BODY	13.80
195	34301	800	FT FENDER SILVER	3.78	282	34401	200	FRONT HUB BODY	24.16
195	34302	800	FT FENDER TGERINE	5.36	283	34301	200	REAR HUB BODY	17.92
195	34401	800	FT FENDER YELLOW	4.10	283	34401	200	REAR HUB BODY	26.92
195	34501	800	FT FENDER RED	7.92	283	34501	200	USE 7311 3111 HUB	28.80
198	11109	200	CORD CLAMP	.16	283	34501	900	USE 7311 3111 HUB	28.80
198	34501	200	FNT FNDR BRKT	3.22	285	34301	200	HUB BEARING COLLA	.82
200	34402	911	TORA H D CUSHION	.00	285	34401	200	SPACER	.56
200	34501	800	USE 200 34501 900	30.26	286	34301	200	REAR HUB COLLAR	.82
200	34501	900	REAR CUSHION ASSY	30.26	286	34401	200	SPACER	.56
200	34501	911	TAKA H D CUSHION	.00	286	34501	200	CENTER PIPE	.82
201	34301	800	USE 201 34302 800	4.38	287	34401	200	USE 7115-3000 SUPPT	.08
201	34301	801	USE 201 34302 800	4.38	287	34501	200	USE 7115 3000 SUPPT	.08
201	34302	800	R CUSHION UPPER S	4.38	288	34501	200	USE 09566 101 RING	.50
201	34401	800	R CUSHION UPPER S	4.06	290	34301	200	FRONT HUB SHAFT	2.10
202	01003	200	GROMMET	.06	290	34401	200	FRONT HUB SHAFT	2.10
202	34301	200	REAR CUSHION RUBB	.20	290	34501	200	FRONT HUB SHAFT	4.02
202	34501	200	RR CSHN SUPT RUBR	.40	291	34301	200	REAR HUB SHAFT	1.92
203	34301	200	SUPPORT PIPE	.26	291	34401	200	REAR HUB SHAFT	2.10
203	34501	200	RR CSHN SUPT PIPE	.86	291	34501	200	USE 7421 3110 SHAFT	4.02
204	34301	800	USE 204 34302 800	4.38	292	34301	200	AXEL COLLAR LH	.68
204	34301	801	USE 201 34302 800	4.38	292	34401	200	F AXEL COLLAR LH	.92
204	34301	801	USE 204 34302800	4.38	292	34401	200	AXLE COLLAR	.92
204	34302	800	R CUSHION LOWER S	4.38	293	34301	200	AXEL COLLAR RH	.68
204	34401	800	R CUSHION BOTTOM	4.06	293	34401	200	F AXEL COLLAR RH	.52
206	34301	200	USE 206 34302 200	3.82	293	34501	200	FT AXLE COLLAR RH	.38
206	34302	200	R CUSHION SPRING	3.82	294	34301	200	REAR AXEL COLLAR	.58
206	34401	200	R CUSHION SPRING	4.42	294	34401	200	R AXEL COLLAR LH	1.10
209	34301	200	NOT USED	.00	294	34501	200	USE 7377 3110 COLLR	1.36
215	12110	200	USE 251 12110 200	.68	295	34301	200	REAR AXEL COLLAR	.92
215	12110	200	USE 251 12110 200	.68	295	34401	200	R AXEL COLLAR RH	1.28
215	34501	200	REAR FENDER CLAMP	1.58	295	34501	200	USE 7426 3110 COLLR	1.20
218	34501	200	CUP WASHER	.46	296	34301	200	AXEL COLLAR	.40
221	34301	200	ROT VALVE COVER	8.00	296	34501	200	FNT AXLE CLR RH85	.38
221	34401	200	ROTARY VALVE COVE	8.02	297	34301	900	CHAIN TENSION ASS	.26
225	34301	200	SWITCH COVER	.06	297	34501	200	USE 4861 3110 ADJTR	.98
227	34301	200	GROMMET	.16	298	34501	200	USE 4861 3002 ADJTR	.98
228	34501	200	USE 2145-5000 HOLDR	.66	301	34401	200	FRONT PANEL	10.00
228	34501	800	USE 7453 8000	1.22	302	34301	800	BRAKE COVER	4.12
230	20900	200	USE 159 20900 900	25.94	302	34301	801	USE 302 34302 800	4.12
232	34302	800	CRANK CASE COVER	26.10	302	34302	800	BRAKE COVER COMP	4.12
232	34401	800	CRANKCASE COV RH	26.50	304	34301	200	BRAKE WIRE HOLDER	.92
233	34301	201	DRAIN PIPE	.82	305	34501	200	USE 7422 3110 NUT	.72
233	34501	200	DRN PIPE BODY	.98	306	34301	800	BRAKE SHOE COMPL	2.36
233	34501	800	DRN FIL COMPL	1.08	306	34401	800	BRAKE SHOE	2.36
234	34301	200	17 O RING	.16	306	34501	200	USE 7140 3110 SHOE	4.02
235	34301	200	USE 2165 5000	1.16	307	34301	800	BRAKE CAM SHAFT	2.50
236	34301	201	OIL FILLER PLUG G	.06	307	34401	800	CAM SHAFT	4.22
239	34302	200	CARBURETOR COVER	6.28	307	34501	200	USE 7351 3110 CAM	5.10
242	34302	200	CRANK CASE COVER	11.32	308	34301	200	BRAKE SHAFT B	1.68

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
309	34301 200	BRAKE SHOE SPRING	378	34501 200	BRK PEDAL WASHER	.06
309	34401 200	SPRING	379	34401 200	USE 7134 3002 NIPPL	.30
309	34501 200	USE 7145 3110 SPRNG	380	34401 200	RUBBER PACKING	.08
310	34301 200	BRAKE TORQUE LOCK	391	34301 800	USE 391 34301 801	26.48
310	34401 200	FRONT BRAKE LOCK	391	34301 801	SEAT COMPLETE	26.48
310	34501 200	FNT BRK TQE LOCK	391	34302 800	SEAT COMPLETE	31.06
315	34401 200	REAR PANEL	391	34401 800	SEAT COMPLETE	25.58
315	34501 200	USE 7331 3111 PANEL	391	34501 800	SEAT COMPLETE	25.84
317	00200 200	6MM GASKET	398	34301 200	TOOL BOX	1.36
323	34501 200	USE 7371 3200 FLANG	399	34301 200	TOOL BOX RUBBER	.32
324	34501 200	USE 7319 3111 RUBBR	400	34301 800	TOOL BOX BAND	1.00
325	34501 200	USE 7376 5001 COLLR	400	34401 200	TOOL BAG BAND	1.00
326	34501 200	FLANGE COLLAR NUT	400	34501 200	TOOL BAND	.36
327	34501 200	USE 09507 101 RING	403	34501 800	TOOL BRKT COMPL.	8.42
328	34501 900	NOT AVAILABLE	405	34501 800	SIDE COVER RED	5.00
329	34401 900	USE 300X16 INVQE RS	410	11501 900	USE 410 11501 901	13.10
329	34501 200	USE 7253 9000 FLAP	410	11501 901	AIR CLEANER ASSY	13.10
329	34501 900	USE 325X19 CARL TIRE	410	12601 900	AIR CLEANER ASSY	23.56
330	34401 900	F WHEEL ASSEMBLY	410	34302 800	SEAT BASE PAN	17.26
330	34501 900	FRONT WHEEL ASSY	415	34302 900	SEAT CATCH ASSY	2.50
331	34401 900	R WHEEL ASSEMBLY	416	11501 800	USE 423 11501 201	4.20
331	34501 900	REAR WHEEL ASSY	416	12601 800	CLNR COVER COMPL.	6.66
332	34301 200	USE 400X8 CARL TIRE	418	34302 800	SEAT CATCH RATCHE	1.78
332	34401 200	USE 300X16 RS INVQE	419	12601 800	CLNR BODY COMPL.	12.18
333	34501 200	USE 325X18 KN CARL	420	11301 800	CLEANER ELEMENT C	3.78
334	11501 200	CLUTCH HUB	420	12601 800	CLNR ELEMENT COMP	5.96
334	34301 200	USE 350X8 TUBE	422	34302 200	SEAT CATCH BODY	.72
334	34401 200	USE 300 X 16 TUBE	423	11501 200	CLEANER BODY	2.10
334	34501 200	USE 300X19 TUBE	423	11501 201	CLEANER BODY	4.20
335	34501 200	USE 325X18 TUBE	424	11501 800	CLEANER CASE	6.88
336	34401 900	10 SPOKE ASSEMBLY	424	34302 200	SEAT CATCH SPRING	.26
336	34501 900	#10 SPOKE ASY FT	425	34302 200	SEAT CATCH SHAFT	.26
337	34501 900	#10 SPK ASY RR ST	430	12601 200	CLEANER CLIP	.58
338	34301 900	WHEEL DISCS SET O	430	34302 200	DAMPER SEAT	.60
338	34401 200	1.60AX16 RIM	430	34501 200	USE 430 12601 200	.58
338	34501 200	19 RIM FRONT	435	34302 200	SYMBOL MARK	.28
339	34501 200	18-RIM REAR	435	34401 200	SYMBOL MARK	.20
341	34301 200	BRAKE DRUM	435	34501 200	SYMBOL MARK	.26
343	34301 200	SPROCKET	436	34302 200	ROCKFORD MARK	.18
343	34401 200	USE 343 34401 201	437	34302 200	TANK TAPE	.60
343	34401 201	SPROCKET	437	34401 200	RACING STRIPE A	.60
343	34401 210	SPROCKET-47T	437	34501 200	STRIPE TAPE A	.72
343	34401 220	SPROCKET-49T	438	34401 200	RACING STRIPE B	3.02
343	34401 230	SPROCKET-51T	438	34501 200	STRIPE TAPE B	2.96
343	34501 200	SPROCKET WHEEL 43	439	34301 200	CLEANER CLAMP A	.08
344	34501 200	LUCK WSHR SPROKET	439	34501 200	CLEANER CLAMP A	.82
346	34301 200	CHAIN 420-86	440	34301 200	CLEANER CLAMP B	.26
346	34401 200	CHAIN 420-53	441	34401 200	RACING STRIPE C	4.60
346	34501 200	CHAIN 40-55	441	34501 200	STRIPE TAPE C	4.90
347	34401 200	16 IN TIRE FLAP	442	34501 200	STRIPE TAPE D	.48
348	34501 200	USE 7453 8000 FLAP	445	34501 200	USE 455 34501 200	1.88
350	34301 800	FRONT BRAKE WIRE	446	34501 200	JOINT RUBBER	2.36
350	34401 800	USE 350 34401 801	447	34401 800	CLEANER ELEMENT C	4.60
350	34401 801	F BRAKE WIRE COMP	450	34401 800	SIDE COVER	7.28
350	34501 800	FNT BRK WIRE COMP	453	11501 200	CLEANER COLLAR	.26
351	34401 200	INNER SPOKE	453	34401 800	SIDE COVER KNOB	.68
351	34501 200	INNER SPOKE	453	34501 800	TOOL BOX CVR KNOB	.78
352	34401 200	OUTER SPOKE	454	34401 200	SIDE COVER SPACER	.86
352	34501 200	OUTER SPOKE	455	20600 900	CARBURETOR ASSY	20.12
353	34401 200	NIPPLE	455	20800 900	CARBURETOR ASSEMB	25.52
353	34501 200	NIPPLE	455	20900 900	CARBURETOR ASSY	30.26
354	34501 200	REAR INNER SPOKE	455	34301 200	CLEANER PIPE JOIN	.76
355	34501 200	REAR OUTER SPOKE	455	34501 200	CLEANER PIPE JNT	1.88
361	34301 800	USE 361 34301 801	457	34302 900	HEAD LAMP TGERINE	15.88
361	34301 801	BRAKE PEDAL	457	34401 900	HEAD LAMP YELLOW	15.88
361	34401 800	BRAKE PEDAL	457	34402 900	HEAD LAMP YELLOW	31.06
361	34501 800	RR BRK PEDAL COMP	457	34501 900	HEAD LAMP RED	26.74
368	34301 200	BRAKE ROD	458	11501 200	CLEANER RUBBER	2.68
368	34401 200	REAR BRAKE ROD	458	34302 900	TAIL LAMP ASSY	6.90
368	34501 200	REAR BRAKE ROD	458	34401 900	TAIL LAMP ASSY	6.70
371	34301 200	BRAKE CAM ARM	458	34402 900	TAIL LAMP ASSY	22.32
371	34401 800	BRAKE ARM	458	34501 900	TAIL LAMP ASSY	23.98
371	34501 200	BRAKE ARM	459	34302 900	LAMP SWITCH ASSY	3.70
372	34301 200	BRAKE CAM ARM MET	459	34401 900	HEADLAMP SWITCH	3.70
373	34301 200	USE 3832-3000 NUT	460	34302 900	HEAD LAMP LENS AS	9.68
374	34301 200	BRAKE ARM SPRING	460	34402 900	HEAD LAMP LENS	20.00
374	34301 201	BRAKE ARM SPRING	460	34501 900	HEAD LAMP LENS UT	26.20
374	34501 200	RR BRK ARM SPRG	461	34302 200	LAMP BODY TGERINE	6.48
375	34301 200	BRAKE ROD SPRING	461	34401 800	LAMP BODY YELLOW	6.12
376	34301 200	BRAKE CAM SHAFT S	461	34402 800	LAMP BODY YELLOW	10.36
377	34301 200	R BRAKE TORQUE LD	461	34501 800	LAMP BODY RED	10.80
377	34401 200	REAR BRAKE LUCK	462	34302 200	RIM SET SPRING	.18
377	34501 200	USE 7366 5000 BAR	463	34302 200	REFLECTOR	3.20
378	34301 200	BRAKE PEDAL WASHE	463	34302 900	HEAD LAMP REFL&SU	3.82

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
464	34302 200	BULB, HEAD LAMP	1.78	594 20600 200	VALVE SPRING	.32
465	34302 200	LEAD WIRE, HEAD L	1.00	594 20800 200	THROTTLE VALVE SP	.48
466	34302 200	HEAD LAMP GASKET	.68	595 11501 900	TANK CAP ASSY	3.78
467	34302 200	HEAD LAMP LENS	2.96	595 20000 200	USE 595 20800 200	1.96
468	34302 200	HEAD LAMP RIM	3.82	595 20600 200	BODY CAP	1.00
469	34302 200	HEAD LAMP GROMMET	.18	595 20800 200	BODY CAP	1.96
469	34402 200	HEAD LAMP GROMMET	.86	595 20900 200	BODY CAP	2.06
470	34401 800	SOCKET & CORD COM	2.10	595 34401 900	USE 595 34501 902	3.82
471	34302 200	TAIL LAMP LENS	2.30	595 34401 900	USE 595 34501 902	3.82
472	34302 800	TAIL LAMP BASE&SO	2.30	595 34501 902	TANK CAP	3.82
472	34402 200	TAIL LAMP BASE	4.52	596 20600 200	LUCK NUT	1.08
473	34302 200	BULB, TAIL LAMP	.76	596 20800 200	CABLE ADJUST LCK	.10
474	34301 200	USE 490 34301 200	7.10	597 20600 200	CABLE ADJUSTER	2.00
474	34402 200	USE 474 34501 200	4.02	597 20800 200	CABLE ADJUSTER	.86
474	34501 200	HEAD LMP BULB CVR	4.02	598 20600 200	NEEDLE JET	1.92
475	34401 800	TAIL LAMP BRACKET	2.52	598 20800 200	NEEDLE JET	3.62
475	34402 200	TAIL LAMP BRKT	6.16	598 20900 200	NEEDLE JET	2.50
475	34501 200	TAIL LAMP BRACKET	6.16	599 20600 200	MAIN JET 90	.76
476	34401 200	TAIL LAMP BRACKET R	.86	599 20600 280	MAIN JET 80	.76
477	34301 200	TAIL LAMP COVER	.22	599 20600 282	MAIN JET 82	.76
482	34301 200	2ND GEAR A	16.12	599 20600 284	MAIN JET 84	.76
482	34401 200	2ND GEAR A	15.18	599 20600 286	MAIN JET 86	.76
483	34301 200	3RD GEAR A	11.96	599 20600 288	MAIN JET 88	.76
483	34401 200	3RD GEAR A	11.40	599 20800 200	MAIN JET 86	.68
484	34301 200	COUNTER SHAFT SPA	.68	599 20800 280	MAIN JET 80	.68
487	34401 200	4TH GEAR A	6.90	599 20800 282	MAIN JET 82	.68
490	34301 200	2ND GEAR B	7.10	599 20800 284	MAIN JET 84	.68
490	34401 200	2ND GEAR B	6.90	599 20900 200	MAIN JET	.72
491	34301 200	3RD GEAR B	18.00	599 20900 210	MAIN JET #100	.72
491	34401 200	3RD GEAR B	18.02	599 20900 220	MAIN JET #98	.72
492	34401 200	4TH GEAR B	6.90	599 20900 230	MAIN JET #96	.72
494	34301 200	DRIVE SHAFT SPACE	.92	600 20600 200	PILOT JET	.92
501	34301 200	KICK STARTER PEDA	1.58	600 20800 200	PILOT JET	.86
509	34301 200	GEAR CHANGE PEDAL	7.02	601 20600 200	PACKING	.06
509	34301 201	GEAR CHANGE PEDAL	7.02	602 20600 200	NEEDLE SEAT	1.26
509	34401 200	PEDAL	7.06	602 20800 200	NEEDLE SEAT	3.52
509	34501 900	SHIFT LEVER CUMP	7.38	603 20600 200	NEEDLE VALVE	2.10
510	34301 200	USE 2582-5000 RUBBR	.76	603 20800 800	NEEDLE VALVE ASSE	3.82
518	34012 800	RECTIFY	3.78	604 20600 200	FLOAT ASSY	4.06
521	34301 200	USE 521 34301 201	11.06	604 20800 800	FLOAT ASSEMBLY	4.46
521	34301 201	SHIFT DRUM	11.06	605 20600 200	FLOAT PIN	.26
522	20800 200	ADJUSTER SCREW	1.28	606 20600 200	FLOAT CHAMBER	2.42
523	20800 200	ADJUSTER SPRING	.22	606 20800 200	FLOAT CHAMBER	3.62
523	20900 200	ADJUSTER SPRING	1.08	606 20800 800	FLOAT CHAMBER	5.56
524	20800 200	ADJUSTER ROD	.62	607 20600 200	CHAMBER PACKING	.90
524	20900 200	ADJUSTER ROD	.72	607 20800 200	CHAMBER PACKING	.62
526	34501 200	DRUM STOPPER ARM	1.36	610 20600 200	STARTER PLUNGER	2.10
532	34301 200	SHIFT PIN B	.40	610 20800 200	STARTER PLUNGER	2.52
535	34301 200	2ND GEAR SPACER	1.36	610 20900 200	STARTER PLUNGER	3.18
542	34401 200	USE 542 34401 800	1.38	611 20600 200	PLUNGER SPRING	.32
542	34401 800	SFT STP CVR COMPL	1.38	611 20800 200	PLUNGER SPRING	2.10
543	34401 200	USE 543 34401 800	.46	612 20600 200	PLUNGER CAP	1.82
543	34401 800	SFT STP BUSS COMP	.46	613 20600 200	LOCK NUT	.16
547	34301 000	USE 547 34301 900	6.90	614 20600 200	CABLE ADJUSTER	1.26
547	34301 900	KICK STARTR ARM A	6.90	615 20600 200	AIR SCREW	.92
547	34501 900	USE 2680 5000	9.88	615 20800 200	AIR SCREW	1.10
560	34010 200	REFLECTOR RED	1.68	615 20900 200	AIR SCREW	1.02
560	34501 200	USE 2680 5000	9.88	616 20600 200	USE 616 20800 200	.08
561	34501 200	KICK STARTER PDL	2.96	616 20800 200	AIR SCREW SPRING	.08
562	34010 200	REFLECTOR BRKT A	.22	617 20600 200	USE 617 20800 200	.42
562	34301 200	STARTR PEDAL RUBB	.40	617 20800 200	BODY BAND BOLT	.42
563	34010 200	REFLECTOR BRKT B	.22	618 20600 200	BODY BAND NUT	.32
563	34301 200	KICK STRTR PEDAL	.26	619 20600 200	THROTTLE SPRING S	.16
564	34010 200	REFT BRKT COLLARA	.86	619 20800 200	THROTTLE SPRING	.26
569	34301 200	SPECIAL WASHER	.06	620 20600 200	AIR JET	.50
570	34301 200	SNAP RING	.16	629 11501 200	FUEL CAP PLASTIC	.26
579	34301 201	RELEASE PUSH SCRE	1.38	642 34401 200	CAP PACKING	.86
588	34501 200	DRN PIPE CAP	.72	643 34401 200	TANK RUBBER	.60
590	20600 200	USE 455 20600 900	20.12	644 34501 200	TNK SPT RBR REAR	.42
590	20800 200	USE 455 20800 900	25.52	646 11501 200	VALVE	.40
591	11501 800	FUEL TANK BLUE	30.76	655 20900 900	USE 455 20900 900	30.26
591	11502 800	FUEL TANK TANGER	27.06	659 34404 900	SPEED O KIT	31.18
591	20600 200	THROTTLE VALVE	4.72	660 34501 900	SPEEDOMETER ASSY	30.26
591	20800 200	THROTTLE VALVE	5.98	661 34501 200	SPEEDOMETER BRKT	1.62
591	20900 200	THROTTLE VALVE	6.08	662 34501 200	SPDMP DMP RUBBER	.32
591	34302 800	USE 591 11501 800	30.76	663 34404 800	SPEED O CABLE	3.92
591	34401 800	FUEL TANK YELLOW	27.60	663 34501 800	SPEEDOMETER CABLE	3.92
591	34501 800	FUEL TANK RED	39.30	664 34404 900	SPEED O DRIVE	17.96
592	11501 900	FUEL COCK ASSY	4.72	664 34501 900	SPDMR GEAR UNIT	17.96
592	20600 200	JET NEEDLE	1.68	680 34402 900	HAND STOP SWT ASY	4.48
592	20800 200	JET NEEDLE	1.52	682 34401 200	USE 642 34401 200	.86
592	20900 200	JET NEEDLE	1.72	688 11501 200	VALVE SPRING	.20
593	20600 200	USE 593 20800 200	.08	700 11501 200	FUEL PIPE	.76
593	20800 200	JET NEEDLE CLIP	.08	700 11502 200	FUEL PIPE	.86

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST	
700	11504 200	FUEL PIPE	.76	831 34402 200	KEY	1.68
700	34501 200	FUEL PIPE	1.28	831 34501 900	USE 831 34402 200	1.68
701	34501 200	OIL PIPE	.82	832 34402 800	MAIN SWTH BRK COM	.36
706	11501 800	MUFFLER COMPLETE	24.16	833 34402 200	MAIN SWITCH COVER	1.26
706	11501 801	MUFFLER COMPLETE	24.16	840 34402 900	FUSE HOLDER ASSY	2.02
706	11502 800	MUFFLER COMP	24.16	840 34501 900	FUSE HOLDER COMPL	2.46
706	34401 800	MUFFLER COMPLETE	24.16	843 20000 200	USE 943 20000 200	1.52
706	34501 800	MUFFLER COMPLETE	27.42	846 34402 900	DIMMER SWT COMP.	3.22
709	11501 800	USE 709 11501 801	1.50	846 34501 900	USE 846 34501 901	7.78
709	11501 801	DIFFUSER PIPE COM	1.50	846 34501 901	DIM SWITCH ASSY	7.78
709	11502 800	DIFFUSER PIPE COM	1.52	854 34402 800	DIMMER SWT LVR CM	.60
709	34401 800	DIFFUSER PIPE	5.36	854 34501 801	DIM SWTH LVR COMP	1.26
709	34501 800	DIFFUSER PIPE COM	3.92	859 34501 200	LEVER GUIDE	2.16
710	34401 200	DIFFUSER JOINT RU	.80	860 20000 200	PLUS DRIVER	.88
711	34501 200	USE 6362-5000 JOINT	1.98	885 11501 800	NOT AVAILABLE	.00
712	34501 200	USE 6364-5000 RING	.26	885 11501 801	THROTTLE WIRE ASS	4.08
713	34501 200	EXHAUST PIPE	8.56	885 34401 800	THROTTLE WIRE	4.08
714	34501 200	MUFFLER STAY	2.30	885 34501 800	THROTTLE WIRE	6.26
716	34501 211	MUFFLER SPACER	.90	886 34301 900	CLUTCH WIRE ASSY	3.78
726	34501 200	MUFFLER CLAMP NUT	1.48	886 34401 800	CLUTCH WIRE ASSEM	3.78
737	11501 201	EXHAUST PIPE GASK	.30	886 34501 800	CLUTCH WIRE	4.08
738	11501 200	MUFFLER PROTECTOR	6.90	888 11501 800	CHOKE WIRE ASSY	1.36
738	11502 200	MUFFLER PROTECTOR	3.38	888 34401 800	CHOKE WIRE ASSEMB	1.36
738	34501 200	MUFFLER PROTECTOR	6.90	888 34501 800	CHOKE WIRE	1.42
744	34401 200	TAILLIGHT BRACKET	1.26	898 11501 200	THROTTLE WIRE BOS	.26
750	34301 800	FOOTREST RUBBER C	1.92	900 34501 900	OIL PUMP ASSY	43.84
751	34301 200	USE 3763 5000 PIN	.18	901 34501 800	GEAR CASE COMPL	7.70
752	34301 200	FOOT REST RUBBER	.92	903 34010 200	WIRE BAND	.10
752	34501 200	USE 3721-3002 RUBBR	1.30	905 34501 800	USE 907 34501 800	16.70
754	34301 200	USE 3762 5000 WASHR	.08	906 11501 200	NAME PLATE TANK	.26
755	34301 200	USE 750 34301 800	1.92	906 11502 200	NAME PLATE TANK	.28
755	34501 200	USE 3711-5010 SHAFT	1.82	906 11504 200	TURA DECAL	.32
756	34501 200	USE 3723-5010 BOLT	.82	906 12601 200	NAME PLATE	.36
757	34501 200	USE 3722-5010 WASH	.76	907 34501 800	PLUNGER COMP	16.70
760	34301 800	STAND SILVER	4.80	908 34501 200	PLUNGER SPRING	.18
760	34301 801	STAND TANGERINE	2.50	909 11501 200	MARK TANK CAP	.16
760	34401 800	STAND BLACK	2.96	909 34501 200	CONTROL LEVER	6.46
760	34501 800	STAND BLACK	6.02	910 34501 200	LEVER RETURN SPG	.38
763	34301 200	STAND SPRING	.32	911 34501 200	ADJUSTING SCREW	.38
763	34501 200	STAND SPRING	.82	912 34501 800	PUMP CASE COMPL.	15.28
764	34401 200	STAND BOLT	.28	914 34501 200	STOPPER BOLT	4.66
764	34501 200	STAND BOLT	.82	915 34501 200	ROD	.26
770	34401 800	ENGINE PROTECTOR	3.82	916 34501 200	5 MM COPPER GSMT	.16
770	34501 800	ENGINE PROTECTOR	8.16	918 11501 200	CLEANER MARK	.38
772	34401 200	STAY COLLAR A	.26	919 11501 200	MARK TANK CAP OPE	.16
773	34401 200	STAY COLLAR B	.26	919 34501 200	GEAR CASE GSMT	.16
774	34501 200	U-BOLT	.28	921 34501 200	UNION BOLT	1.48
776	34401 200	WIRE HOLDER	.18	923 34501 200	BALL CHECK SPG B	.10
776	34501 200	WIRE HOLDERS	.38	925 12601 200	MADE IN JAPAN MRK	.06
777	34401 200	USE 903 34010 200	.10	928 34501 200	5 MM FIBER PKG	.16
777	34501 200	WIRE BAND	.30	931 34501 200	USE 931 34501 210	.32
778	34501 200	WIRE CLAMP	.28	931 34501 210	2.5 O-RING	.32
780	34401 200	FRK SUPPORT BOLT	.80	932 34501 200	9 O-RING	.30
780	34501 200	FNT FORK BOLT	3.18	933 34501 200	6 MM ALUMN GSMT	.10
789	34402 200	GROMMET	.10	934 34501 200	UNION BOLT B	.72
791	34402 200	HORN BRACKET	.30	935 34501 200	#4 THRUST WASHER	.10
792	34402 800	WIRE HARNESS	6.12	941 34501 200	OIL PIPE GROMMET	.30
792	34501 800	WIRE HARNESS COMP	6.86	943 20000 200	TOOL BAG	1.52
793	34402 200	WIRE HARNESS COVR	.76	951 20000 200	8X120 BOX HANDLE	.30
799	34501 200	USE 800 34501 200	2.36	960 34501 800	OIL TANK RED	24.80
800	34501 200	REFLECTOR RED	2.36	961 34501 200	OIL TANK JOINT	.48
801	34303 200	REFLECTOR AMBER	1.68	963 34501 200	OIL TANK JNT PCKG	.10
801	34501 200	REFLECTOR AMBER	2.36	965 34501 200	OIL TANK SPT RBR	.46
802	20000 200	9X10 SPANNER	.76	980 11050 070	5X7 MM SCREW	.10
803	34303 200	REFLECTOR BRK B	.26	980 21050 100	5X10 MM BOLT	.08
803	34501 200	REFLECTOR BRKT B	.70	990 11030 051	3 X 5 SCREW	.10
804	34501 200	TAIL RFLTR BRKT	2.70	990 11030 060	USE 990 11030 051	.10
808	20000 200	10-13 SPANNER	.90	990 11030 300	USE 0372 0330 SCREW	.08
809	34501 800	USE 809 34501 801	15.32	990 11040 061	4X6 PLUS SCREW	.10
809	34501 801	RECTIFIER	15.32	990 11040 100	USE 0361 0410 SCREW	.06
811	34501 800	USE 3353-3001 BAND	.50	990 11040 500	SCREW 4X50 MM	.10
813	34402 200	BATTERY BOX	2.02	990 11040 501	USE 990 11040 500	.10
818	34402 200	FOOT SWT SPRG	.28	990 11050 220	SCREW 5X22 MM	.10
818	34501 200	FT BRK SWTH SPRG	.30	990 11060 085	SCREW 6X8 MM	.10
819	34402 200	USE 819 34501 200	.18	990 11060 121	6X12 SCREW	.12
819	34501 200	FT BRK SWTH BRKT	.18	990 21050 081	5X 8 HEX BOLT	.10
820	34402 200	USE 820 34402 900	4.10	990 21050 100	USE 980 21050 100	.08
820	34402 900	FOOT SWT ASSY	4.10	990 21060 350	6X35 MM BOLT	.12
820	34501 900	FT BRK SWTH ASSY	4.70	990 21060 451	USE 09511 131 BOLT	.18
823	20000 200	17X21 BOX SPANNER	.82	990 21060 251	USE 990 21061 251	.68
829	34402 200	USE 829 34501 200	1.26	990 21061 251	6-25-25 BOLT	.68
829	34501 200	TAL LMP SKT CD CM	1.26	990 21080 201	8-20 BOLT	.10
830	34402 900	MAIN SWITCH ASSY	8.70	990 21080 220	8X22 MM BOLT	.10
830	34501 900	MAIN SWITCH ASSY	10.80	990 21080 926	USE 0113 0890 BOLT	.26

PART NUMBER	DESCRIPTION	LIST
990 21081 006	8-100-20 BOLT	.50
990 21081 106	8X110 MM BOLT	.60
990 21081 300	8X130 MM BOLT	.68
990 21081 306	USE 990 21081 300	.68
990 21100 146	10-14 BOLT	.76
990 21100 206	10X20 BOLT	.16
990 21100 306	10 X 30 MM BOLT	.82
990 31080 356	8-35 BOLT	.06
991 01040 013	4 MM NUT	.06
991 01050 001	USE 991 01050 013	.08
991 01050 011	USE 991 01050 013	.08
991 01050 011	5 MM HEX NUT	.08
991 01080 013	8 MM NUT	.10
991 01050 013	USE 991 01050 011	.08
991 81100 001	10MM LOCK NUT	.26
992 01040 001	USE 0411 0410 WASH	.08
992 01100 001	USE 569 34301 200	.06
992 04100 030	WAVE WSMR 10 MM	.10
992 08050 006	5 SPECIAL WASHER	.06
992 10100 032	10MM SPECIAL WASH	.06
992 90120 120	USE 0551 1010 PIN	.08
993 20020 142	TAPER PIN 2X14	.18
993 22030 120	PARALLEL PIN3X12	.16
993 22030 200	USE 993 22030 120	.16
993 24030 200	3X20 SPRING PIN	.10
993 24303 200	USE 993 24030 200	.10
993 30030 000	DRIVE SCREW	.06
993 30210 200	2-14X4 DRY SCREW	.18
999 61620 202	BEARING 62022	2.60
999 66049 301	4 MM OIL SEAL	.88
999 66173 250	OIL SEAL	.26
999 66234 050	USE 09590 107 SEAL	1.00
999 66253 508	OIL SEAL	1.52
999 66459 801	4.5 OIL SEAL	.88
999 67010 000	P 10 O RING	.26
999 67023 000	O-RING	.22
999 67026 000	USE 09566 108 RING	.80
999 67101 502	15 O RING	.40

# MCB BY ROCKFORD

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
81 614 060	USE NGK B9H PLUG	1.30	0248 144 000	CHANGE LEVER	24.90
82 005 466	HEX SCREW FOR GRD	6.00	0249 112 000	CUP	1.88
82 005 574	HEX BOLT CHAIN LK	.32	0249 120 000	DOWEL TUBE	.94
82 005 647	HEX SCREW FOR STY	.32	0250 107 000	SEALING RING	.46
82 005 908	HEX SCREW	.32	0250 112 100	SEALING RING	.06
82 511 331	NUT	.40	0250 118 000	SEALING RING	.12
82 801 501	WASHR R SIDE	.14	0250 128 000	OIL SEAL	2.76
82 801 504	WASHER	.24	0250 131 000	SEALING RING	.04
82 801 600	WASHER	.12	0250 148 000	SEALING RING	.32
82 995 105	WASHER	.94	0251 107 000	SECURNG PLATM6&M4	.46
0230 002 000	OIL SEAL	3.30	0251 107 001	SECURNG PLATM8&M4	.56
0230 015 000	SEALING RING	.12	0259 109 000	OUTER PLATE	1.68
0232 129 000	BUSHING	.80	0260 024 001	RUBBER CAP	.26
0232 131 000	RING	.80	0260 041 000	PROTECTION CAP	.26
0232 151 000	BUSHING	4.16	0260 125 000	USE 12040 CABLE	4.84
0234 070 111	SPIRAL PINION	6.96	0265 073 000	CABLE CONNECTOR	1.22
0234 071 000	SPIRAL GEAR	6.40	0265 077 001	LEAD FOR CONDENSER	1.22
0237 120 200	SELECTOR ROD	20.30	0265 109 100	USE 265-07-900 PLUG	4.56
0237 122 200	STARTER SHAFT	23.40	0265 137 002	NOT AVAILABLE	.00
0239 015 000	NOT USED	.00	0265 139 012	USE 282-07-903 COIL	10.80
0239 119 000	PAWL SPRING	.52	0265 139 013	USE 282-07-901 COIL	5.50
0239 120 000	RETURN SPRING	.74	0265 139 014	USE 282-07-900 COIL	5.50
0239 122 000	KICKSTARTER SPRNG	1.14	0265 140 009	USE 285-07-900 PLATE	53.20
0239 123 000	TENSION SPRING	.60	0265 141 004	USE 281-07-905 COIL	7.36
0239 126 000	FURK SPRING	.74	0265 150 000	USE 282-07-101 CAP	.40
0240 043 002	ADJUSTING SCREW	.52	0265 151 000	USE 517-16-108 CAP	.32
0240 066 009	PIVOT PIN	1.42	0276 011 105	PULLR-CHAIN SPR	13.26
0240 100 000	OIL DRAIN SCREW	.68	0276 019 101	SPACER PLATE TOOL	9.66
0240 106 100	PHILLIPS SCREW	.20	0277 086 406	SPANNER	19.88
0240 120 002	FILLISTER HEAD BT	.40	0283 100 402	USE 285-07-714 MAG	102.90
0240 122 002	USE DIN 84-293 BOLT	.14	0283 101 100	USE 276-07-914 POINT	6.04
0240 133 100	SCREW	2.96	0283 105 017	NOT AVAILABLE	.00
0240 139 000	SCREW	.22	0283 107 000	SPACES FOR CONT B	1.42
0240 140 000	PLUG	.56	0283 108 018	USE 285-07-902 FLYWL	58.96
0240 153 000	FILLISTER HEAD BT	.18	0283 109 000	USE 283-07-702 COIL	19.44
0241 040 001	FILLISTER HEAD BT	.12	0284 007 000	INNER PLATE	3.38
0241 048 000	SCREW	.94	0286 317 000	SELECTOR BASE	24.66
0241 049 100	CONNECTNG SCREW	2.56	0286 320 000	USE 0284 007 000	3.38
0241 053 100	OIL LEVEL SCREW	.46	0286 324 201	NOT USED	.00
0242 103 100	GROOVED NUT	.82	0289 028 001	KICK STARTR CRKCM	19.80
0242 106 005	NUT	2.16	0289 028 020	KICK STARTR CRKCM	19.80
0242 109 000	NUT	.30	0290 106 211	SELECTOR SHAFT	30.80
0244 055 000	WASHER	.20	0290 112 101	NOT USED	.00
0244 055 001	WASHER	.20	0291 006 000	USE 12040 CABLE	4.84
0244 055 002	WASHER	.20	0299 059 009	NOT AVAILABLE	.00
0244 055 003	WASHER AS REQ	.20	0299 059 016	NOT AVAILABLE	.00
0244 075 008	WASHER	.18	0299 059 026	NOT AVAILABLE	.00
0244 082 002	WASHER	.18	0299 141 000	USE 12040 CABLE	4.84
0244 100 000	WASHER	.06	501 009 049	CLEANR HOSE CLAMP	1.08
0244 100 001	WASHER	.06	0611 113 000	MAGNETO SIDE COVR	26.22
0244 100 002	WASHER	.06	0611 114 100	CLUTCH SIDE COVER	30.50
0244 100 003	WASHER	.06	0613 106 004	CYLINDER HEAD	58.96
0244 102 000	WASHER	.12	0615 101 005	PISTON RING	5.52
0244 102 001	WASHER	.10	0615 101 006	PISTON RING	5.52
0244 102 002	WASHER	.10	0615 101 007	PISTON RING	5.52
0244 102 003	WASHER	.10	0615 101 008	PISTON RING	5.52
0244 102 102	WASHER	.10	0615 103 005	L RING	19.88
0244 108 000	WASHER	.56	0615 103 006	L RING	19.60
0244 118 000	WASHER	.22	0615 103 007	L RING	19.60
0244 118 001	WASHER	.22	0615 103 008	L RING	19.60
0244 118 002	WASHER	.22	0616 100 000	USE 285 03 120 PIN	6.06
0244 118 003	WASHER	.22	0619 001 000	SELECTOR KEY	9.34
0244 118 004	WASHER	.22	0619 001 100	SELECTOR KEY	8.28
0245 020 005	CIRCLIP 16MM	.22	0619 004 000	SELECTOR ROD	22.36
0245 022 000	SPRNG WASH FORM10	.22	0630 001 000	OIL SEAL	3.68
0245 023 000	SPRING WASHER	.30	0632 017 201	ROLLER BEARING	21.80
0245 023 002	SPRING WASHER	.30	0632 111 000	USE 285 03. 123	6.26
0245 112 000	RETAINING PLATE	.06	0634 005 001	RATCHET WHEEL	16.12
0246 008 000	WASHER	.10	0634 106 000	1ST GEAR46-34TEET	32.00
0246 008 001	WASHER	.12	0634 106 100	1ST GEAR 46-34 T	31.50
0246 009 006	WASHER	.10	0634 107 000	2ND GEAR 41 TEETH	22.36
0246 015 000	WASHER	.12	0634 108 000	3RD GEAR 37 TEETH	20.70
0246 015 001	WASHER	.12	0634 109 000	4TH GEAR 33 TEETH	16.56
0246 015 002	WASHER	.12	0634 110 000	5TH GEAR 31 TEETH	15.00
0246 015 003	WASHER	.12	0634 111 000	STARTER GEAR	18.30
0246 047 000	WASHER	.10	0634 112 000	DRIVE GEAR	17.10
0246 052 000	CUP	3.06	0636 106 000	SPROCKET 14 TEETH	12.80
0247 106 001	USE 276-07-909 BUSH	.48	0636 107 000	SPROCKET 13 TEETH	12.80
0247 106 002	USE 283-07-904 BUSH	.82	0637 102 000	MAIN SHAFT	39.36
0248 131 100	GEAR CHANGE LEVER	12.36	0639 100 000	SPRING	.26
0248 133 000	NOT USED	.00	0639 100 100	SPRING	.26
0248 133 001	SELECTOR ADJ PLAT	2.62	0639 101 000	ANNULAR SPRING	.68
0248 135 100	SELECTOR SHOE	7.56	0639 103 000	USE 285 04 917 SPRNG	.24
0248 136 000	SELECTOR PAWL	6.24	0639 104 000	USE 285 04 920 SPRNG	1.26

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
0639	105	000	SPRING		.74
0639	106	000	CLUTCH SPRING		.36
0640	002	000	SLOTTED SCREW		.10
0640	005	005	STOP BOLT		1.88
0640	011	102	FILLISTER HEAD BT		.40
0640	105	000	USE 220 04 904 SCREW		.96
0640	106	000	USE 285 04 916 SCREW		1.12
0640	107	000	ADJUSTING SCREW		.46
0640	108	001	STUD BOLT		.80
0640	109	001	PIVOT SCREW		.80
0640	110	000	ECCENTRIC SCREW		3.44
0642	103	001	NUT L H		2.36
0642	104	101	NUT FOR DO		1.88
0642	105	001	NUT		1.88
0642	106	000	USE 285 04 954 COVER		2.06
0642	107	001	THROAT BOLT		.68
0642	108	000	NUT		.36
0644	017	000	WASHER		.26
0644	103	000	WASHER		1.00
0644	104	000	WASHER		.80
0644	104	001	WASHER		.80
0644	104	002	WASHER		.80
0644	104	003	WASHER		.80
0644	104	004	WASHER		.80
0644	105	000	WASHER		.60
0644	105	001	WASHER		.60
0644	105	002	WASHER		.60
0644	105	003	WASHER		.60
0644	105	004	WASHER		.60
0644	105	103	WASHER		.54
0644	105	104	WASHER		.54
0644	106	000	WASHER		.68
0644	109	100	PRIFILL WASHER		.56
0644	111	000	WASHER		.54
0647	101	000	RING		2.00
0647	103	000	ECCENTRIC BUSHING		2.28
0648	105	100	GEAR CHAN LEVER L		17.28
0648	106	000	GEAR CHAN LEVER U		9.44
0649	103	000	USE 285 04 923 PIN		.24
0649	105	000	CUP		2.16
0650	004	000	SEALING RING		.04
0650	017	000	SEALING RING		.60
0650	105	000	CRANK CASE GASKET		.80
0650	106	000	GASKET SIDE COVER		.80
0650	107	200	GASKET		.74
0650	110	000	USE 285 04 919 GASKT		1.12
0650	111	000	GASKET		1.14
0650	112	000	PACKING RING		.74
0650	114	000	GASKET		1.34
0651	102	000	CLAMP		3.24
0658	001	000	CLUTCH HUB		15.12
0658	002	000	NOT USED		.00
0658	002	100	CLUTCH CASE 41 5M		5.88
0658	003	000	PRESSURE PLATE		3.80
0661	005	000	SPRING		.36
0661	007	000	SCREW		1.28
0661	110	000	TICKLER COMP		1.56
0661	112	000	USE 285 04 922 FLOAT		2.28
0661	113	000	LOCK PLATE		.32
0661	114	000	THROTTLE NEEDLE		1.42
0661	115	000	SPRAYER		3.16
0661	116	001	NEEDLE JET 2 76		2.90
0661	117	000	MIXING TUBE		3.36
0661	118	000	USE 285 04 902 JET		3.38
0661	119	000	CAP FOR THROTTLE		2.16
0661	120	000	THROTTLE		4.60
0661	121	000	USE 285 04 921 FLOAT		5.50
0661	122	000	USE 285 04 957 HOUSG		4.02
0661	123	000	CARBURETOR BODY		37.20
0663	002	000	STOP		.28
0667	103	000	RUBBER BELLOWS		4.36
0676	012	200	PROTECTIVE CAP		4.60
0676	021	000	SPANNER		9.38
0676	109	000	PINION TOOL		13.80
0676	110	000	CLUTCH HUB TOOL		11.88
0681	005	011	CARBURETOR		63.72
0684	002	000	PRESSURE PLATE		7.40
0684	003	000	CAM CAP		7.40
0685	100	000	GEAR		20.48
0685	101	100	LAYSHAFT		49.46
0685	102	000	NOT USED		.00
0685	102	100	MAIN SHAFT COMP		55.00
0686	100	000	STARTER SLIDE		2.28
0686	207	015	PISTON		43.64
0686	207	016	PISTON		43.64
0686	207	017	PISTON		43.64
0686	207	018	PISTON		43.64
0686	209	000	RACE WITH WASHER		3.50
0687	107	205	CRANKCASE		130.00
0687	107	305	CRANKCASE		130.00
0687	108	025	CYLINDER		198.00
0688	005	100	CRANKSHAFT W CON		119.00
0690	002	000	SELECTOR AUT COMP		46.88
0932	061	005	BUSH		6.08
0940	017	101	STUD BOLT		1.40
0940	119	102	HEAD BOLT		.60
0940	128	202	HEAD BOLT		.54
0941	087	000	HEX BOLT		.20
0942	067	100	NUT		.32
0942	072	110	USE 265 07 105 NUT		2.06
0944	003	000	WASHER		.10
0944	003	001	WASHER		.10
0944	003	002	WASHER		.10
0944	003	003	WASHER		.10
0944	003	004	WASHER		.10
0944	019	000	SPRING WASHER		.48
0944	046	000	WASHER		.12
0944	046	001	WASHER		.12
0944	046	002	WASHER		.12
0944	046	003	WASHER		.12
0944	046	004	WASHER		.12
0944	046	005	WASHER		.12
0944	046	006	WASHER		.12
0944	055	001	LUCK WASHER		.54
0945	063	000	USE DIN 73123 650		.16
0945	064	000	CIRCLIP		.30
0945	105	000	CIRCLIP		.06
0947	125	000	BUSHING		2.16
0949	003	002	GROOVED PIN		.06
0949	090	000	DWEL TUBE		.20
0961	018	001	NUT		.20
0961	067	000	USE 285 04 915 PSRNG		.16
0961	081	000	USE 267 04 938 SCREW		.82
0961	106	000	MAIN JET 125		1.00
0961	106	000	MAIN JET 130		1.00
0961	106	000	MAIN JET 135		1.00
0961	106	000	MAIN JET 140		1.00
0962	083	000	USE 285 04 913 WASH		.08
0965	091	000	USE 277-07-909 COND		2.42
0986	432	000	CONNECTING NIPPLE		1.28
1068			FURK STOP		.26
1445	017	000	LOCKING WASHER		.68
1550	99		SILVER TOUCH UP		5.69
1940	114	000	HEX SCREW		.80
1940	134	000	HEX SCREW		.74
1950	023	000	SEALING RING		.10
1950	024	000	SEALING WASHER		.30
2015	008	000	SCREW		1.50
2311	1377	00	STRAP BLK PER YD		.74
2740	024	002	HEX BOLT		.74
2865	008	000	USE 265-07-919 WICK		.16
2876	003	100	PROTECTIVE CAP		3.02
5113			FRONT REFLECTOR		2.02
5141			REAR REFLECTOR		.67
5551			HURN		8.12
5770			NUT		.08
5843			SELF LOCKING NUT		.40
5845			SELF LOCKING NUT		.62
5861			WASHER		.06
5863			USE 0411-0613 WASH		.08
5864			USE 0411-0818 WASH		.08
5866			USE 0411-1022 WASH		.08
5901			USE 0431-0615 WASH		.08
5903			USE 0431-0820 WASH		.08
5913			SPRING WASHER		.06
7025			BOX SPANNER		11.04
7026			BOX SPANNER		12.14
7161			PHILIPS DRIVER		2.02
9343			STOP SWITCH & CAP		5.69
10081			EXHAUST PIPE		21.20
10267			SHOCK ABSORBER		34.34
10305	6		CONTACT SCREW		.14
10305	9		CABLE INLET		.24
10315	1		USE 10316 LAMP		6.68
10315	2		USE 10316 LAMP		6.68
10315	3		LAMP SOCKET		2.90
10316			REAR LAMP COMP		6.68
10316	2		REAR LAMP COMPL		24.56

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
10322	BRAKE LIG CON PED	3.30	11421	USE 520 23 700 LOCK	12.86
10382	GAS VALVE	7.30	11447	USE 300X21 TUBE	
10407	45MGAS HD PER YD	1.42	11448	USE 350X18 TUBE	
10496	GAS TANK	87.00	11463	USE 520 15 186 BAND	1.06
10496 1	KNEE PAD OF RUBBE	3.68	11500 3	STOP SCREW	.22
10496 2	REAR GAS TANK HLD	4.96	11506	USE 520-17-718 GRIP	27.66
10496 3	USE 517 15 112 BUSH	1.10	11506 5	USE 520-17-922 SCREW	3.08
10496 4	HOSE CLIP	.40	11506 6	USE 520-17-922 SCREW	3.08
10546	FILLER CAP	5.40	11510 2	USE 400-17-912 SCREW	.36
10618 10	BUSHING	.44	11510 5	USE 425-17-902 SCREW	.94
10619	BRAKE PEDAL COMP	26.00	11510 7	USE 425-17-718 SCREW	1.54
10619 9	SLEEVE	1.88	11588	USE 516-17-705 GRIP	1.92
10717 3	STOP NUT	.82	11598	USE 520-17-920 GRIP	1.76
10717 5	SAFETY LOCK	.20	11671	SPEEDOMETER HEAD	22.48
10732	FOOT BRAKE CABLE	8.62	11671 1	SPEEDOMETER CABLE	5.88
10776 27	BATTERY BOX	13.47	11738	F WHEEL COMPLETE	140.66
10776 28	BATTERY BOX BAND	1.08	11805	R WHEEL CUMP	181.02
10803 165	SPOKE-REAR-AL RIM	.36	11861	USE COMPLETECABLE	.00
10803 225	SPOKE FRNT-ST RIM	.36	11875	USE COMPLETECABLE	.00
10803 203	SPOKE FRNT-AL RIM	.36	11891	USE COMPLETECABLE	.00
10803 190	SPOKE REAR-ST RIM	.36	11892	USE COMPLETECABLE	.00
10815	SPOKE NIPPLE	.24	11894	USE COMPLETECABLE	.00
10918	FOOT REST COMP	14.36	11940	THROTTLE CABLE CU	3.02
10918 1	FOOT REST	6.84	11986	BRAKE CABLE COMP	3.24
10918 2	FOOT REST	8.28	12040	CLUTCH CABLE COMP	4.84
10918 3	ALLEN HEAD SCREW	1.14	12047	AIR CABLE COMP	2.90
11036	FR RIM ALUM 21 IN	48.56	12075	NOT AVAILABLE	.00
11037	R RIM ALUM 18 IN	48.60	12081	NOT AVAILABLE	.00
11038	R RIM STEEL 18 IN	26.72	12083	CABLE SHOE	.12
11039	FR RIM STEEL 21IN	26.72	12118	USE 11986 CABLE	3.24
11095 14	CABLE BEARER	.30	12121	NOT AVAILABLE	.00
11146	FURK COMPLETE	368.50	12138	NOT AVAILABLE	.00
11146 1	UP BRACKET ENAMEL	49.26	12150	NOT AVAILABLE	.00
11146 2	ALLEN HEAD SCREW	1.14	12193	NOT AVAILABLE	.00
11146 3	HANDLE BAR HOLDER	3.80	12194	NOT AVAILABLE	.00
11146 4	SPACER	2.90	12195	NOT AVAILABLE	.00
11146 5	COVER NUT FOR TUB	9.34	12198	NOT AVAILABLE	.00
11146 6	STOP NUT	7.40	12199	NOT AVAILABLE	.00
11146 7	OIL FILLER SCREW	12.36	12219	CABLE CONNECTOR	.18
11146 9	SCREW FOR OIL FIL	.20	12224	CONTACT	.38
11146 10	SPRING FOR DU	.46	12264 118	CHAIN	18.16
11146 11	USE 0611 0532 BALL	.08	12383	CHAIN LOCK	.81
11146 12	GASKET FOR OIL FI	1.28	12384	USE 12383 CHN CONN	.81
11146 13	WASHER FOR OIL FI	.40	12414	USE 12383 CHN CONN	.81
11146 14	ALLEN HEAD SCREW	1.48	12468	CHAIN ADJ COMP	5.56
11146 15	LOWER BRACKET	44.94	12480	USE 510 18 218 GUIDE	4.00
11146 16	FORK TUBE	19.04	12540 54	SPROCKET 54T	24.80
11146 17	ALLEN HEAD SCREW	1.56	12540 57	SPROCKET 57T	26.72
11146 18	HEX SCREW	1.02	12540 60	CHAIN WHEEL 60T	28.58
11146 19	USE 0411-0818 WASH	.08	12541 54	54T SPROCKET	24.80
11146 20	INNER TUBE COMP	97.20	12671	CHAIN GUARD	15.12
11146 21	INNER TUBE ONLY	77.98	12810 2	CLAMP HEAD	.74
11146 22	BULT FOR SPRING	28.04	12831	MUFFLER	38.14
11146 23	BUSHING	4.78	12831 1	MUFFLER CLIP	4.10
11146 24	LOCK RING	.56	12831 3	MUFFLER HOLDER	2.42
11146 25	SPRING	2.08	12831 4	MUFFLER EXTENSION	9.34
11146 26	RING	2.76	12831 5	HEAT SHIELD	16.46
11146 27	VALVE	3.02	12832	MUFFLER	43.64
11146 28	VALVE BUSHING	6.00	12832 5	HEAT SHIELD	16.56
11146 29	LUCK RING	.88	13063 35	USE DIN 472 450	.52
11146 30	LUCK RING	2.70	13076 2	SPINDLE SLEEVE	4.90
11146 31	JOINTING RING	3.30	13076 3	DUST CAP FOR BALL	.56
11146 32	LOCK RING	.34	13076 4	BRAKE SHOE PAIR	10.94
11146 33	BUSHING	15.02	13076 5	SPRING BRAKE SHOE	.56
11146 34	SPRING	9.56	13076 6	WASHER	.28
11146 35	RUBBER CAP	5.70	13076 7	BRAKE SHIELD	19.22
11146 36	CLIP RUBBER CAP	4.34	13076 8	EXCENTRIC	4.90
11146 37	LOWER OUT TUBE R	177.56	13076 9	PACKING RING	.26
11146 38	LOW OUT TUBE LEFT	177.56	13076 11	BRAKE ARM	1.22
11146 39	LOW OUT TUBE RIGH	70.42	13076 12	NUT	.68
11146 40	LOW OUT TUBE LEF	70.42	13076 13	JOINTING RING	2.02
11146 41	SLOTTED SCREW	.20	13076 14	NUT	.68
11146 42	GASKET	.26	13077	FRONT HUB COMP	65.62
11146 44	ALLEN HEAD SCREW	.94	13077 1	HUB SLEEVE	36.60
11146 45	GASKET	.26	13077 15	SPINDLE	21.04
11146 46	HEAD LAMP BRACKET	7.40	13077 17	CLIP FOR CABLE	1.34
11146 47	ALLEN HEAD SCREW	.40	13077 18	RUBBER STOP FOR C	.40
11146 48	GASKET SET	4.66	13077 19	BUSHING	.62
11146 50	SLEEVE	.66	13077 20	WASHER	.36
11254	BULB	.62	13077 21	DISTANCE RING	1.22
11254 2	USE 8252 3031 BULB	.82	13077 22	NUT	1.28
11284	BULB	3.02	13077 23	JOINTING RING	2.02
11360	USE 300 X 21 HK TIRE		13077 24	WORM GEAR SPEEDOM	8.28
11362	USE 350 X 18 HK CARL		13077 25	BUSHING	1.34

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST			
13077	26	GEAR	8.28	15262	4	REFLECTOR COMP	10.94	
13077	27	BUSHING	.68	15262	5	DETENT SPRING	.40	
13077	28	LOCKING SCREW	.34	15262	6	HEADLAMP SOCKET	7.56	
13077	29	GREASE CAP	.68	15262	7	DETENT SPRING	.52	
13078		F HUB ASSY SACHS	65.62	15262	8	HEADLAMP CASING	19.38	
13087		REAR HUB COMP	97.20	15262	15	GROUND CABLE CPL	1.48	
13087	1	HUB SLEEVE	42.80	15500		USE 282-07-121 WIRE	.80	
13087	2	SPINDLE SLEEVE	12.14	15516		USE 265-07-900 PLUG	4.56	
13087	3	SPACER	.44	15555		USE NGK B9H PLUG	1.30	
13087	6	WASHER	.32	15807		BOX SPANNER	2.62	
13087	7	BRAKE SHIELD	22.46	17400		USE SC-1643 PLATE	5.00	
13087	10	BRAKE ARM SPRING	.58	17400	10	ATTACHMENT NUMBER	2.90	
13087	11	BRAKE ARM	4.66	17400	11	RUBBER	.40	
13087	13	BUSHING	4.54	17401		USE SC-1643 PLATE	5.00	
13087	18	SPINDLE	21.04	17402		USE SC-1643 PLATE	5.00	
13087	19	RUBBER	1.14	17551		USE 520-13-616 BAR	39.60	
13087	20	AXLE SPROCKET	5.40	17552		HANDLE BAR ENDRO	16.56	
13087	21	DISTANCE RING	.54	18315		USE 18515 TUBE	1.14	
13087	22	HUB SPROCKET	17.12	18515		T-TUBE	1.14	
13087	24	LOCK WASHER	.48	18572		USE 516-17-704 LEVER	16.76	
13087	25	SQUARE NUT	.18	18572	4	USE 516 17. 908	8.58	
13087	26	DISTANCE RING	.82	18574		USE 520-17-706 LEVER	17.36	
13088		R HUB ASSY SACHS	97.20	18574	4	USE 516-17-907 LEVER	8.58	
13457		PACKING STAND COM	9.28	18574	9	USE 516-17-907 LEVER	8.58	
13457	4	SPRING	.68	19003		BALL BEARING	4.84	
13500		INSUL TUBE PER YD	.28	19003	5	BALL BEARING	7.18	
13503		INSUL TUBE PER YD	.34	19004		BALL BEARING	5.02	
13815		FRAME	190.94	19004	5	BALL BEARING	7.52	
13815	1	SWING FORK	66.96	19012		BALL BEARING	4.42	
13815	2	AXLE	4.54	19117		BALL BEARING	11.26	
13815	3	SILENT BLOCK	3.98	19021		BALL BEARING	4.60	
13815	4	SELF LOCKING NUT	.74	19044		BALL BEARING	5.58	
13815	5	ENGINE COVER	21.54	19045		BALL BEARING	5.70	
13815	6	ENGINE SUPPORT F	2.56	19135		PILOT BEARING	13.92	
13815	10	ENGINE SUPPORT R	32.82	19501	686	RUBBER PLATE	.88	
13815	15	STAY BRAKE SHIELD	5.86	19501	204	WING SCREW	.06	
13815	20	DUST CAP	3.92	21250	4	NUT	.04	
13850		AIR CLEANER COMP	35.88	21260	2	NOT AVAILABLE	.00	
13850	1	CAP AT PLASTIC	10.22	21425	6	RUBBER STOPPER	1.68	
13850	2	AIR FILTER	10.98	21708	4	USE 428 17 715 ADJ	1.06	
13850	3	CONNECTION	8.28	21757		AIR GRIP COMP	5.64	
13850	4	CLAMP	3.06	21757	1	HOLDER	5.52	
13850	5	INNER CAP	5.08	21757	2	LEVER	3.12	
13850	6	OUTER CAP	3.02	21757	3	SLOTTED SCREW	.34	
14031		SADDLE	42.08	21757	6	SCREW	.48	
14321		HEX SCREW	.08	22915	2	RUBBER WASHER	.22	
14323		USE DIN 933 346 SCRM	.16	23068	3	WASHER	.16	
14324		USE 0113 0620 BOLT	.08	23305	1	MUFFLER CLIP	1.28	
14331		HEX SCREW	.10	23355		USE 23357 SWITCH	6.07	
14332		SCREW	.10	23357		LIGHTING SWITCH	6.07	
14333		HEX SCREW	.10	23358		SWITCH W/WIRE HAR	27.06	
14354		HEX SCREW	.12	24140	2	SLEEVE	.36	
14368		HEX SCREW	.60	24160	2	LOCK WASHER	.20	
14454	614	USE 0112-0614 BOLT	.18	24200	1	SLOTTED SCREW	.26	
14454	616	USE 0111-0616 BOLT	.06	24367	3	RUBBER WASHER	.18	
14454	620	USE 0113-0620 BOLT	.08	25500	19	SELF LOCKING NUT	.32	
14454	635	USE DIN 84-480 BOLT	.24	25569		LOCK WASHER	.12	
14454	645	USE 0113-0645 BOLT	.18	27061		CLAMPING PLIERS	5.52	
14454	816	USE 0123-0816 BOLT	.18	27384		ALLEN WRENCH SPNN	.40	
14454	820	USE 0112-0822 BOLT	.16	27389		ALLEN WRENCH SPNN	1.34	
14454	822	USE 0112-0822 BOLT	.16	27390		ALLEN WRENCH SPNN	2.70	
14454	835	USE 0133-0836 BOLT	.82	27401		PULLER	5.20	
14454	860	USE 09511-106 BOLT	.42	27950	22	BLUE TOUCH UP PAI	5.81	
14454	875	HEX SCREW	.68	27493		WOOD MOUNT	2.36	
44541	045	HEX SCREW	.88	28001	60	LOCK RING	.68	
44548	150	HEX SCREW	1.02	28001	195	RUBBER SLEEVE	.62	
14500		NUT	.42	28200	126	LOCKING RING	.12	
14501		USE DIN 934-480 NUT	.16	29036	160	WOODRUFF KEY	.32	
14502		USE 0211-0800 NUT	.08	9	06000	215	CLIP	1.22
14595		CIRCLIP	.18	9	06000	356	HOLDER W/RUBBER	.74
14918		F MUD GUARD	21.52	MEV6	V	MCB BATTERY	15.90	
14919		R MUD GUARD	24.90					
14919	1	R MUD GUARD FPACT	24.90					
14920		R MUDGUARD RPACT	24.90					
14920	2	NOT AVAILABLE	.00					
14920	3	NOT AVAILABLE	.00					
15044		STAY FOR F MUD GR	24.74					
15091		STAY FOR R MUDGUA	21.54					
15105		LUBRICANT NIPPLE	1.88					
15150		CONNECTION TERM B	.88					
15262		HEADLAMP COMP	35.18					
15262	1	INSERT COMP W/OSO	20.98					
15262	2	HEADLAMP ARM COMP	9.44					
15262	3	RIM SCREW	1.02					

# ZUNDAPP MOTO CROSS AND ENDURO

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST			
DIN 7	760	8M6 X 36 PIN	.80	DIN 933	670	OIL PLUG M10X18	.50	
DIN 84	250	M4X6 SCREW	.08	DIN 934	280	M4 HEX NUT	.08	
DIN 84	270	AM4X10 BOLT	.08	DIN 934	320	M5 HEX NUT	.10	
DIN 84	280	AM4X12 BOLT	.14	DIN 934	400	M6 HEX NUT	.10	
DIN 84	293	AM4X16 BOLT	.14	DIN 934	440	M7 HEX BOLT	.12	
DIN 84	340	AM5X12 BOLT	.12	DIN 934	480	M8 HEX NUT	.16	
DIN 84	380	AM5X22 BOLT	.16	DIN 934	560	M10 HEX NUT	.22	
DIN 84	450	BM 6X22 BOLT	.16	DIN 936	400	M8X1 HEX NUT	.14	
DIN 84	480	AM6X35 BOLT	.24	DIN 936	560	M10X1 HEX NUT	.22	
DIN 84	500	BM6X45 BOLT	.36	DIN 964	440	AM5X20 OVAL SCREW	.22	
DIN 84	520	BM 6X55 BOLT	.50	DIN 1440	505	8 DIA WASHER	.16	
DIN 84	540	BM6X65 BOLT	.58	DIN 1476	200	RIVET 2X3	.08	
DIN 85	325	AM5X8 OVAL SCREW	.10	DIN 1476	250	2X5 PIN	.08	
DIN 85	500	AM6X12 OVAL SCREW	.16	DIN 1481	200	2X12 SLEEVE	.10	
DIN 85	535	M6X16 SCREW	.16	DIN 1481	260	3X12 BOLT	.12	
DIN 91	465	USE DIN 964 440 SCRW	.22	DIN 1481	420	4X10 SLEEVE	.12	
DIN 94	260	2X12 SPLIT PIN	.04	DIN 1481	695	SLEEVE 5X80	.28	
DIN 125	250	A4.3 WASHER	.04	DIN 2098	500	1X10X26 SPRING	1.88	
DIN 125	300	A5.3 WASHER	.04	DIN 3760	850	B22X40X7 SEAL	4.62	
DIN 125	400	A6.4 WASHER	.08	DIN 5401	280	4.5 DIA BALL	.08	
DIN 125	450	A7.4 WASHER	.08	DIN 5401	350	5 DIA BALL	.08	
DIN 125	550	A8.4 WASHER	.10	DIN 5401	500	6.DIA BALL	.10	
DIN 127	240	B4 SPRING WASHER	.08	DIN 5401	650	8DIA BALL	.12	
DIN 127	320	B5 SPRING WASHER	.08	DIN 5402	400	3.5X5 ROLLER	.24	
DIN 127	400	B6 SPRING WASHER	.08	DIN 6797	200	A4.3 WASHER	.10	
DIN 127	480	B7 SPRING WASHER	.10	DIN 6797	240	A5.3 TOOTH WASHER	.10	
DIN 127	560	B8 SPRING WASHER	.10	DIN 6797	400	A6.4 TOOTH WASHER	.10	
DIN 127	640	B10 SPRING WASHER	.12	DIN 6797	470	J6.4 WASHER	.10	
DIN 127	760	B16 SPRING WASHER	.20	DIN 6799	500	8 RET WASHER	.10	
DIN 137	440	B7 SPRING WASHER	.10	DIN 6888	300	3X3.7 KEY	.20	
DIN 137	480	B8 SPRING WASHER	.10	DIN 7346	300	3X12 SLEEVE	.08	
DIN 433	400	6.4 WASHER	.08	DIN 7513	400	BM4X10 MM SCREW	.26	
DIN 433	500	8.4 WASHER	.10	DIN 7603	200	A6X10 SEAL RING	.04	
DIN 471	350	L6X1 RET RING	.16	DIN 7603	235	A6.5X9.5 BOLT	.68	
DIN 471	530	20X1.2 RET. RING	.24	DIN 7603	440	SEAL RING 10X14	.12	
DIN 471	535	20X1.75 RET. RING	.26	DIN 7604	400	AM10X1 LOCK SCREW	.88	
DIN 472	225	22X1 RET. RING	.26	DIN 7971	460	BZ4.2X6.5 SCREW	.20	
DIN 472	240	24X1.2 WASHER	.24	DIN 9021	600	A6.4 WASHER	.10	
DIN 472	350	32X1.2 RET RING	.52	DIN 9021	700	A8.4 WASHER	.12	
DIN 472	450	35X1.5 RET RING	.52	DIN 9045	700	25 CIRCLIP	.56	
DIN 557	400	M5 SQ NUT	.12	DIN 46247	500	6X3.1 SLEEVE	.62	
DIN 625	260	6003 C38 BEARING	5.34	DIN 72581	500	8A FUSE	.20	
DIN 625	275	6003Z8 BEARING	6.00	DIN 72601	710	SL6V21 BULB	2.68	
DIN 625	295	6004Z8 BEARING	7.10	DIN 73123	650	A15X1.2 SNAP RING	.16	
DIN 625	410	6201Z8 BEARING	5.28	DIN 73379	390	A5X9 FUEL TUBE	.86	
DIN 625	440	6202ZC38 BEARING	5.76	600	Z5	RUBBER MOUNT	7.64	
DIN 625	485	6203Z8 BEARING	6.28	616	25	RUBBER SLEEVE	1.14	
DIN 625	515	6204-C3 BEARING	6.90	1236	209	RETAINING RING	1.10	
DIN 625	665	USE 07 6303 03 BEAR	3.96	1301	Z1019	WASHER	.26	
DIN 625	672	USE 07 6303 03 BEAR	3.96	1871	155	FRAME BEARING RAC	11.40	
DIN 625	695	BEARING 16005C3	6.52	1871	156	FORK BEARING RACE	11.40	
DIN 660	340	2.6X5 RIVET	.02	2401	K52	USE 285 04.953 SPRNG	.24	
DIN 912	350	M6X25 BOLT	.38	2401	K80	USE 285 04.952 CLAMP	.08	
DIN 912	400	M8X25 BOLT	.72	2403	K51	USE 285 04.954 COVER	2.06	
DIN 912	610	M8X40 HEX BOLT	.72	2403	K97	USE 285 04.955 PLATE	1.18	
DIN 920	400	M6X15 OVAL SCREW	.32	6060	Z107	BATTERY	55.60	
DIN 931	320	M6X45 HEX BOLT	.34	6160	Z237	COUPLER WITH FUSE	1.40	
DIN 931	408	M7X45 CYL BOLT	.44	M	181Z	138	BUSHING	.36
DIN 931	524	M8X35 BOLT	.46	M	1806	Z59	RUBBER SLEEVE	.26
DIN 931	540	M8X40 HEX SCREW	.48	220	04.	904	AIR REG SCREW	.96
DIN 931	550	M8X42X22 HEX BOLT	.50	247	01.	126	MODEL PLATE	.72
DIN 931	590	M8X55 SCREW	.60	247	05.	233	THRUST PIN	.32
DIN 931	630	M8X70 SCREW	.86	251	04.	927	NUT	.16
DIN 931	706	M10X40 SCREW	.62	261	06.	155	SPRING SLEEVE	.20
DIN 933	280	M6X8 HEX BOLT	.16	265	02.	120	WASHER	.88
DIN 933	300	M6X10 HEX BOLT	.16	265	05.	175	WASHER 23X0.5	.40
DIN 933	320	M6X12 SCREW	.16	265	05.	176	WASHER 23X0.2	.20
DIN 933	346	M6X16 SCREW	.16	265	05.	177	WASHER 23X0.1	.20
DIN 933	350	M6X18 HEX BOLT	.20	265	05.	245	WASHER 28X1.0	.36
DIN 933	365	M6X22 SCREW	.20	265	05.	255	WASHER 32X0.2	.20
DIN 933	380	M6X30 HEX BOLT	.26	265	05.	256	WASHER 32X0.1	.20
DIN 933	450	USE DIN 933 453 SCRW	.28	265	05.	257	WASHER 22.1X32X03	.20
DIN 933	453	M7X16 SCREW	.28	265	05.	294	WASHER 11.8X0.4	.20
DIN 933	489	M7X35 HEX BOLT	.50	265	05.	295	WASHER 11.8X0.2	.20
DIN 933	501	M7X40 HEX BOLT	.60	265	05.	296	WASHER 11.8X0.8	.20
DIN 933	524	M7X50 BOLT	.60	265	06.	104	CLUTCH TONGUE	3.36
DIN 933	530	M8X10 HEX BOLT	.24	265	06.	106	SET SCREW	1.46
DIN 933	540	M8X12 HEX BOLT	.26	265	06.	109	RETAINING SPRING	.12
DIN 933	554	M8X16 HEX BOLT	.26	265	06.	112	SPRING	.44
DIN 933	570	M8X18 HEX BOLT	.28	265	06.	127	COVER PLATE	4.74
DIN 933	590	M8X22 HEX BOLT	.34	265	06.	130	CLUTCH PLATE	1.88
DIN 933	610	M8X25 HEX SCREW	.36	265	06.	131	CLUTCH PLATE	1.88
DIN 933	614	M8X28 SCREW	.36	265	06.	135	FRICITION PLATE	3.86
DIN 933	663	M10X12 SCREW	.48	265	06.	202	HEX NUT	.94

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
265	06. 216	THRUST PLATE	3.00	285	01. 197	BOLT	1.32
265	06. 602	CLUTCH LEVER	8.46	285	01. 203	BUSHING	4.62
265	07. 105	COLLAR NUT	2.06	285	01. 204	20X28X6 SEAL	3.90
265	07. 900	SUPPRESSOR PLUG	4.56	285	01. 210	WASHER 51.9X0.05	.36
265	07. 919	LUBRICATING WICK	.16	285	01. 211	WASHER 51.9X0.1	.46
265	07. 914	RUBBER CAP	.32	285	01. 212	WASHER 51.9X0.2	.46
267	01. 128	BUSHING	3.46	285	01. 220	SEAL 20X30X8.1	4.22
267	04. 938	ADJUSTER SCREW	.82	285	01. 223	20X13 SLEEVE	4.28
267	04. 940	GROMMET	.82	285	01. 224	WASHER 19.9X1.0MM	.44
267	04. 946	SEALING RING	.08	285	01. 901	HOUSING GASKET	2.96
267	05. 112	SETTING BELL	3.36	285	01. 902	HOUSING GASKET	2.96
267	05. 113	SHIM	.20	285	01. 909	CASING RIGHT	73.46
267	05. 125	BOLT	2.20	285	01. 910	CASING LEFT	61.16
267	05. 126	SPRING	.26	285	01. 919	CASING RIGHT	73.46
267	05. 130	RUBBER CAP	.48	285	01. 920	CASING LEFT	61.16
267	05. 244	WASHER 22.8X0.1	.20	285	01. 921	CASING LEFT	61.16
267	05. 310	WASHER 28X0.1	.26	285	02. 137	PISTON RING 54DIA	3.76
267	05. 312	WASHER 28X1.0	.48	285	02. 150	CYLINDER HEAD	37.72
267	05. 313	USE 278 01.130 WASH	.44	285	02. 152	CYLINDER GASKET	.80
267	05. 315	WASHER 28X0.2	.16	285	02. 153	CYLINDER HEAD GAS	1.62
267	05. 319	SPRING	.36	285	02. 162	GASKET	1.14
267	05. 334	BRAKE SPRING	.98	285	02. 163	CYLINDER HEAD	44.64
267	05. 585	SPRING	.24	285	02. 176	PISTON RING	8.62
267	05. 586	LATCH	2.76	285	02. 177	CYLINDER HEAD	44.64
267	05. 597	WASHER	.34	285	02. 632	FLANGE	19.30
267	05. 910	DOG COMPLETE	7.80	285	02. 713	PISTON WITH RINGS	34.50
276	01. 154	SECURITY RING	1.82	285	02. 717	CYLINDER W PISTON	277.20
276	04. 916	SPLIT PIN	.10	285	02. 727	CYLINDER WITH PIS	290.40
276	04. 920	BUTTON SPRING	.10	285	02. 728	CYLINDER WITH PIS	298.96
276	05. 119	HEX NUT	1.18	285	02. 729	PISTON WITH RINGS	34.88
276	05. 198	RETAINING WASHER	.34	285	03. 120	PISTON PIN 15MM	6.06
276	07. 102	SPARK PLUG W260	3.30	285	03. 123	NEEDLE CAGE	6.26
276	07. 909	BUSHING	.48	285	03. 700	USE 285 03.904 BEAR	9.70
276	07. 914	CONTACT BREAKER	6.04	285	03. 902	CRANKSHAFT W PIN	161.04
277	07. 909	CONDENSER	2.42	285	03. 904	BALL BEARING	9.70
278	01. 130	WASHER	.44	285	03. 905	BALL BEARING	11.52
278	05. 100	RETURN SPRING	1.62	285	03. 907	CRANKSHAFT W PIN	173.84
278	05. 101	BALL 7MM DIA	.20	285	03. 908	CRANKSHAFT W PIN	161.04
281	01. 135	OIL FILLER SCREW	2.20	285	04. 108	GASKET	.98
281	01. 140	BUSHING	9.68	285	04. 109	INTAKE MANIFOLD	32.98
281	04. 909	MAIN JET 100	1.10	285	04. 184	INTAKE MANIFOLD	20.80
281	04. 926	MAIN JET 105	1.10	285	04. 185	AIR TUBE	2.36
281	05. 152	23.9X0.6 SPACER	1.52	285	04. 717	CARBURETOR COMP	72.88
281	05. 153	24.9X1 SPACER	.48	285	04. 722	CARBURETOR COMP	75.04
281	06. 114	WASHER 2MM THICK	.24	285	04. 725	CARBURETOR COMP	75.04
281	06. 115	WASHER 5MM THICK	.24	285	04. 901	IDLE JET 35	3.38
281	07. 905	GENERATOR COIL	7.36	285	04. 902	IDLE JET 40	3.38
282	01. 123	NEEDLE SLEEVE	3.84	285	04. 904	USE 220 04.904 SCREW	.96
282	04. 903	FIXING SCREW	.72	285	04. 908	PRIMING BUTTON	1.12
282	05. 700	FOOT SHAFT SLEEVE	15.72	285	04. 909	CLAMPING RING	1.32
282	07. 101	PROTECTING CAP	.40	285	04. 910	LOCK NUT	.24
282	07. 121	IGNITION CABLE	.80	285	04. 912	CHOKE TUBE	1.98
282	07. 900	BRAKE COIL 18W	5.50	285	04. 913	WASHER	.08
282	07. 901	TAILLIGHT COIL 5W	5.50	285	04. 915	SPRING	.16
282	07. 903	IGN COIL PRIMARY	10.86	285	04. 916	SET SCREW	1.12
283	05. 115	WASHER 25X30X0.2	.36	285	04. 917	SPRING	.24
283	05. 116	WASHER 25X30X0.3	.46	285	04. 918	FLOAT HOUSING	3.22
283	05. 608	PULL COTTER	33.08	285	04. 919	GASKET	1.12
283	07. 100	CABLE GROMMET	.74	285	04. 920	SPRING	1.26
283	07. 702	IGN COIL SECOND	19.44	285	04. 921	FLOAT	5.50
283	07. 904	BUSHING	.82	285	04. 922	FLOAT NEEDLE	2.28
284	06. 104	RETAINING PLATE	.24	285	04. 923	PIN	.24
284	07. 904	CHARGING COIL	26.54	285	04. 931	GASKET	.80
284	07. 907	ELECTRO BOX W/COIL	64.32	285	04. 936	NEEDLE JET 2.73	1.18
285	01. 105	CUNNECTOR CAP	7.70	285	04. 937	NEEDLE JET 2.70	1.18
285	01. 113	CASING COVER RIGH	39.16	285	04. 938	NEEDLE JET 2.76	1.18
285	01. 123	USE 285 01 192 RING	4.02	285	04. 939	ATOMIZER	5.50
285	01. 144	WASHER 46.9X1.05	2.06	285	04. 941	PRIMER BUTTON CAP	2.28
285	01. 145	WASHER 46.9X1.10	2.06	285	04. 942	COVER PLATE	1.32
285	01. 146	WASHER 46.9X1.15	2.06	285	04. 943	SLIDE	5.22
285	01. 147	WASHER 46.9X1.20	2.06	285	04. 945	MAIN JET 108	1.10
285	01. 158	WASHER 46.9X1.25	2.12	285	04. 946	MAIN JET 112	1.10
285	01. 159	WASHER 46.9X1.30	2.12	285	04. 947	JET NEEDLE F4	1.40
285	01. 160	WASHER 46.9X1.35	2.12	285	04. 948	MAIN JET 110	1.10
285	01. 161	WASHER 46.9X1.40	2.12	285	04. 949	MAIN JET 115	1.10
285	01. 164	STUD	3.46	285	04. 950	MAIN JET 120	1.10
285	01. 177	CASING COVER LEFT	26.82	285	04. 951	MAIN JET 125	1.10
285	01. 180	6X154 MM BOLT	1.62	285	04. 952	CLAMP	.08
285	01. 181	CYLINDER BOLT	1.62	285	04. 953	SLIDE SPRING	.24
285	01. 183	SEAL 70X30X7	3.30	285	04. 954	COVER	2.06
285	01. 184	WASHER 46.9X1.00	2.06	285	04. 955	COVER PLATE	1.18
285	01. 185	WASHER 46.9X0.95	2.06	285	04. 957	FLOAT HOUSING	4.02
285	01. 192	123X2.5 RING	4.02	285	04. 958	SLIDE	5.82
285	01. 194	SEAL 20X30X7	1.26	285	05. 124	GUIDE BOLT	2.08

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
285	05. 136	SPACER TUBE	428	20. 901	GASKET FUEL VALVE .08
285	05. 151	NUT	428	20. 902	RUBBER GASKET .40
285	05. 169	STARTER GEAR 22T	428	20. 903	GLASS .72
285	05. 175	NOT USED	428	20. 904	JACKET SCREW 2.10
285	05. 176	17.1X23X0.2 WASHE	432	10. 210	RUBBER SLEEVE .36
285	05. 177	17.1X23X0.1 WASHE	432	16. 600	SPEEDOMETER CABLE 3.56
285	05. 178	LOCKING PLATE	432	20. 610	TANK CAP 2.62
285	05. 179	NOT USED	433	15. 102	SPACER TUBE 2.04
285	05. 199	SPROCKET 13 TEETH	433	15. 131	NUT 1.76
285	05. 200	SPROCKET 14 TEETH	433	17. 100	SPRING SEAT .50
285	05. 201	SPROCKET 15 TEETH	434	20. 703	FUEL VALVE 9.12
285	05. 207	STARTER SPRING	435	10. 205	MODEL PLATE 1.10
285	05. 208	SCREW 17X35 MM	435	10. 900	MODEL PLATE 1.14
285	05. 209	STARTER STOP	440	20. 100	ROUND TANK MARK 4.06
285	05. 211	SCREW	442	10. 182	ZUNDAPP DECAL 1.06
285	05. 234	STARTER LEVER	510	12. 171	SPRING SUPPORT 4.56
285	05. 235	STARTER SPINDLE	510	12. 178	LOCK SCREW 5.76
285	05. 237	5TH GEAR 19 TEETH	510	12. 179	FORK CAP SCREW 2.82
285	05. 238	5TH GEAR 20 TEETH	510	17. 726	CLUTCH LEVER COMP 28.84
285	05. 239	4TH GEAR 24 TEETH	510	17. 727	BRAKE LEVER COMP 28.84
285	05. 240	4TH GEAR 24 TEETH	510	17. 908	USE 516 17. 908 8.58
285	05. 241	3RD GEAR 23 TEETH	510	18. 218	CHAIN GUIDE 4.00
285	05. 242	2ND GEAR 26 TEETH	510	20. 130	ZUNDAPP DECAL 3.66
285	05. 243	1ST GEAR 34 TEETH	512	12. 136	BUSHING 3.28
285	05. 256	PAWL GUIDE	512	12. 150	BOTTOM SPRING 4.28
285	05. 279	SPROCKET 16 TEETH	512	12. 236	TOP SUPPORT 4.94
285	05. 286	SPROCKET 12 TEETH	512	21. 100	MIRROR CLAMP 5.72
285	05. 299	SPRING	512	21. 701	MIRROR COMPLETE 8.84
285	05. 300	WASHER 16.5X1.0	514	10. 118	SPACER RUBBER 1.12
285	05. 302	O-RING 12X2MM	515	15. 100	THREADED SOCKET 2.58
285	05. 303	STARTER SLEEVE	515	15. 106	SPEEDO PINION 7.48
285	05. 607	CHANGE SHAFT	515	15. 605	SPEEDO DRIVE DOG 7.82
285	05. 609	SELECTOR SHAFT	515	16. 938	IGNITION SWITCH 13.00
285	05. 637	D SHAFT W 5 GEARS	515	16. 939	IGNITION KEY 1.04
285	05. 638	U SHAFT W 5 GEARS	515	17. 715	CLUTCH CABLE ADJ 1.22
285	05. 665	STARTER LEVER COM	516	17. 704	CLUTCH LEVER ASSY 16.76
285	05. 666	USE 283 05.608 DRUM	516	17. 705	FIXED GRIP 1.92
285	05. 701	CHANGE SHAFT COMP	516	17. 901	USE 516 17. 908 8.58
285	05. 723	CHANGE SHAFT COMP	516	17. 907	BRAKE LEVER 8.58
285	05. 901	CLUTCH WHEEL COMP	516	17. 908	CLUTCH LEVER 8.58
285	06. 101	PINION	517	15. 112	RUBBER BUSHING 1.10
285	06. 106	CLUTCH SPRING	517	15. 127	DRAW SPRING 1.12
285	06. 107	CLUTCH SPRING	517	15. 133	BRAKE SHOE SPRING 1.10
285	06. 600	RETAINING PLATE	517	15. 607	BRAKE LEVER 3.18
285	07. 105	CABLE SLEEVE	517	15. 609	BRAKE SHOE PAIR 14.68
285	07. 112	USE 285 37. 122	517	15. 634	SPACER 4.02
285	07. 114	SPARK PLUG W280M1	517	15. 635	HUB BODY 38.28
285	07. 115	COLLAR NUT	517	16. 108	PROTECTING CAP .32
285	07. 121	NOT AVAILABLE	517	17. 103	BRAKE ROD SPRING 1.52
285	07. 122	SWITCH BRACKET	517	17. 111	RUBBER SLEEVE .48
285	07. 125	CABLE SLEEVE	517	20. 126	KNEE PAD LEFT 2.74
285	07. 126	CABLE GROMMET L	517	20. 127	KNEE PAD RIGHT 2.74
285	07. 700	USE 285 07 714 MAG	517	21. 109	STAND SPRING 1.46
285	07. 714	IGNITION MAGNETO	517	21. 114	RUBBER WASHER .20
285	07. 718	MHKZ MAGNETO COMP	517	22. 111	RETAINING NUT M6 .36
285	07. 726	PLUG CAP W/WIRE	518	12. 100	BELLOW 9.90
285	07. 728	HKZ MAGNETO MC	518	12. 102	BELLOW CLAMP .88
285	07. 729	HKZ MAGNETO GS	518	12. 103	BELLOW CLAMP .96
285	07. 732	PLUG CAP	518	16. 130	RECTIFIER 8.72
285	07. 900	ARMATURE PLATE	518	16. 131	CLAMP .24
285	07. 901	USE 285 07 902 FLYWL	519	12. 110	CONE NUT 2.64
285	07. 902	FLYWHEEL	519	12. 146	RUBBER RING 2.58
285	07. 903	GENERATE COIL 35W	519	12. 900	SLIDE BUSHING 10.44
285	07. 904	BRAKE COIL 18W	519	15. 119	LOCK NUT M10 .80
285	07. 905	TAILLIGHT COIL 5W	519	15. 123	USE 520 15.223 RIM 40.98
285	07. 906	FLYWHEEL	519	15. 126	USE 350 X 18 RS TIRE
285	07. 907	ARMATURE PLATE	519	15. 139	USE 350 X 18 TUBE
286	04. 900	MAIN JET 98	519	16. 100	USE 6060 Z107 BATTY 55.60
286	05. 102	PINION	519	16. 900	LENS COVER RING 11.92
304	07. 249	SLEEVE 19.1X0.3	519	16. 901	SCREW LENS COVER .80
304	07. 251	SLEEVE 19.4X0.4	519	16. 902	LAMP 46.86
304	07. 260	PLUG HOUSING	519	16. 903	SPRING CLIP .48
304	07. 276	INSULATING SLEEVE	519	16. 908	WASHER .46
304	16. 204	FLAT PLUG CONTACT	519	16. 909	MOUNTING SCREW .80
304	16. 216	PLUG CONTACT	519	16. 910	SLEEVE LEFT 10X20 .48
304	16. 242	RUBBER CAP	519	17. 106	PIN 3.84
400	17. 912	BRACKET SCREW	519	17. 110	SPRING 1.28
405	15. 388	SEALING RING	519	17. 702	THROTTLE GRIP 19.50
425	17. 718	CABLE ADJ SCREW	519	17. 906	RUBBER BELLOW 1.48
425	17. 902	LEVER SCREW	519	18. 607	CHAIN 114 LINKS 21.64
425	17. 910	CLUTCH BRACKET	520	10. 253	SNAP FASTENER .50
428	17. 103	WING NUT	520	10. 288	RUBBER MOUNTING 8.02
428	17. 635	PLASTIC DILER	520	10. 296	TOGGLE LEVER 2.08
428	17. 715	BRAKE CABLE ADJ.	520	10. 311	AIR FILTER CASE 19.60

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST		
520	10. 312	FILTER COVER	7.14	520	15. 156	BEARING PIN	5.16
520	10. 317	AIR BELLOW	5.22	520	15. 165	NUT	1.46
520	10. 318	HOSE CLIP	1.24	520	15. 166	TONGUE ARM	2.08
520	10. 345	FILTER SUPPORT	2.26	520	15. 169	BUSHING	2.04
520	10. 363	USE 520 10.717 CASE	48.82	520	15. 171	BRAKE CAM BUSHING	.72
520	10. 366	BUSHING 9X14X8	.80	520	15. 172	IN SPOKE 159 WNPL	.98
520	10. 370	USE 520 10.717 CASE	48.82	520	15. 173	OT SPOKE 159 WNPL	.98
520	10. 372	GASKET 34.8X18	1.14	520	15. 174	SPOKE 226 W NPL	.92
520	10. 373	NUT AVAILABLE	.00	520	15. 177	TORQUE ARM	2.04
520	10. 608	FILTER INSERT	9.52	520	15. 179	FRONT AXLE	11.68
520	10. 617	COVER	62.04	520	15. 186	RIM BAND	1.06
520	10. 662	FRAME RED	345.00	520	15. 187	SPROCKET 60 TEETH	43.12
520	10. 664	COVER	62.04	520	15. 189	USE 300X21 HK TIRE	
520	10. 665	FRAME RED	345.00	520	15. 190	USE 300 X 21 TUBE	
520	10. 666	FILTER COVER	6.82	520	15. 191	RIM BAND	1.06
520	10. 703	HOSE CLIP	.96	520	15. 193	SPACER TUBE	2.04
520	10. 717	FILTER CASE	48.82	520	15. 195	FELT RING	.46
520	10. 900	FILTER COVER NS	14.30	520	15. 196	SPEEDOMETER GEAR	7.48
520	12. 142	SHAFT SEAL	4.94	520	15. 201	USE 520 15.222 RIM	31.48
520	12. 143	LOCK NUT	7.26	520	15. 203	IN SPOKE 226 WNPL	.80
520	12. 168	GUIDE	2.36	520	15. 204	OT SPOKE 226WNPL	.80
520	12. 169	O-RING 6X1.5	.44	520	15. 206	REAR AXLE	10.66
520	12. 171	BOTTOM SUPPORT	7.58	520	15. 207	IN SPOKE 159 WNPL	.98
520	12. 172	CONNECTING TUBE	1.46	520	15. 208	OT SPOKE 159 WNPL	.98
520	12. 198	LOCK SCREW	5.12	520	15. 209	FLANGE COLLAR	11.88
520	12. 199	LOCK SCREW	1.38	520	15. 214	NOT AVAILABLE	.00
520	12. 204	TOP FORK MOUNT	39.24	520	15. 216	25X42X6.1 SEAL	4.50
520	12. 212	SLEEVE	.50	520	15. 222	RIM 1.6AX21	31.48
520	12. 213	WASHER 4.1X7X1	.22	520	15. 223	RIM 1.85 X818	40.98
520	12. 215	PISTON	3.30	520	15. 608	BRAKE CAM	4.90
520	12. 216	THREAD ROD	4.18	520	15. 609	HUB BODY	38.28
520	12. 217	FORK SPRING CENTE	4.12	520	15. 611	HUB COVER	10.34
520	12. 223	TOP FORK MOUNT	37.92	520	15. 613	CHAIN ADJUSTER L	5.66
520	12. 226	SHAFT SEAL	4.18	520	15. 614	CHAIN ADJUSTER R	4.44
520	12. 235	NOT AVAILABLE	.00	520	15. 615	USE 520 15.650 ARM	8.14
520	12. 257	RUBBER RING	1.38	520	15. 629	DRIVE FLANGE	14.96
520	12. 258	THREADED RING	4.12	520	15. 631	USE 520 15 613	5.66
520	12. 262	UPPER FORK TUBE	26.44	520	15. 632	BRAKE LEVER	5.28
520	12. 263	PLUG	.38	520	15. 633	USE 520 15 614	4.44
520	12. 264	THREADED ROD	5.16	520	15. 636	BRAKE PLATE	23.06
520	12. 265	PISTON	3.30	520	15. 637	BRAKE PLATE	26.54
520	12. 266	HEX NUT	.24	520	15. 638	USE 520 15 901 HUB	65.56
520	12. 267	FORK SPRING	.24	520	15. 640	TORQUE ARM	2.60
520	12. 271	O-RING 6X15 MM	.46	520	15. 644	BRAKE PLATE	23.06
520	12. 272	SPRING SUPPORT	4.56	520	15. 645	BRAKE PLATE	26.54
520	12. 273	FORK SPRING	8.46	520	15. 650	TORQUE ARM	8.14
520	12. 274	GUIDE	3.84	520	15. 900	DRIVE GEAR PLATE	8.90
520	12. 276	USE 520 12.198 SCREW	5.12	520	15. 901	REAR HUB	65.56
520	12. 277	USE 520 12.263 PLUG	.38	520	15. 902	DRIVE FLANGE	14.96
520	12. 615	BOTTOM FORK MOUNT	52.80	520	16. 117	RUBBER PLATE	1.12
520	12. 621	DAMPER TUBE	13.96	520	16. 243	SWITCH SLEEVE	1.14
520	12. 634	BUSHING	11.10	520	16. 255	ROUND PLUG	.34
520	12. 648	USE 520 12.658 MOUNT	52.36	520	16. 256	ROUND PLUG SLEEVE	.36
520	12. 656	FORK TUBE	38.72	520	16. 257	PROTECTOR CAP	.88
520	12. 657	DAMPER TUBE	16.94	520	16. 607	SPEEDOMETER CABLE	9.92
520	12. 658	BOTTOM FORK MONT	52.36	520	16. 608	BATTERY HOLDER	4.40
520	12. 718	LOWER TUBE LEFT	50.16	520	16. 610	RUBBER BAND	4.90
520	12. 719	LOWER TUBE RIGHT	51.04	520	16. 646	REAR REFLECT RED	2.00
520	12. 720	LOWER TUBE LEFT	77.00	520	16. 647	REAR REFLECT YELL	2.00
520	12. 721	LOWER FORK TUBE R	74.80	520	16. 655	CLAMP BRACKET RED	1.88
520	13. 146	TOP MOUNT BRACKET	8.24	520	16. 656	R LAMP MOUNT RED	3.92
520	13. 147	BOTTOM MOUNT	9.34	520	16. 657	L LAMP MOUNT RED	3.92
520	13. 616	HANDLE BAR	39.60	520	16. 701	TAIL LIGHT	14.48
520	14. 143	WASHER 8.5X17X1.5	.16	520	16. 713	SPEEDOMETER	43.72
520	14. 216	REAR AXLE	5.72	520	16. 725	STOP SWITCH COMP	3.14
520	14. 217	AXLE NUT	1.52	520	16. 728	STOP SWITCH ONLY	9.52
520	14. 218	USE 520 14.216 AXLE	5.72	520	16. 750	HEADLAMP COMP RED	93.26
520	14. 237	RUBBER CAP	1.12	520	16. 751	RESISTER	14.74
520	14. 241	RUBBER CAP	3.74	520	16. 753	DIMMER SWITCH	18.76
520	14. 627	RUBBER BUSHING	5.60	520	16. 766	HORN	18.10
520	14. 628	RUBBER BUSHING	4.06	520	16. 767	KILL SWITCH	14.06
520	14. 647	USE 520 10.617 COVER	62.04	520	16. 900	TAIL LIGHT LENS	6.44
520	14. 706	REAR CUSHION	45.44	520	16. 901	PROTECTOR CAP	1.48
520	14. 716	USE 520 14.706 CUSH	45.44	520	16. 922	LAMP SOCKET	10.04
520	14. 724	USE 520 14.731 REST	17.60	520	16. 923	IGN.SWITCHW/CABLE	27.22
520	14. 725	USE 520 14.732 REST	18.02	520	16. 924	IGNITION KEY	2.66
520	14. 727	REAR FORK RED	71.70	520	16. 925	RECTIFIER & TERM	53.24
520	14. 728	REAR FORK RED	67.76	520	16. 926	RECTIFIER ONLY	31.94
520	14. 731	FOOT REST LEFT	17.60	520	16. 927	FUSE 15 AMP	.72
520	14. 732	FOOT REST RIGHT	18.02	520	16. 928	BULB 6V 1.5W.	3.42
520	15. 148	FLANGE COLLAR	11.00	520	16. 929	USE 520 16.750 LAMP	93.26
520	15. 150	SPRING CLIP	1.12	520	16. 930	SLEEVE RIGHT12X21	.50
520	15. 151	REAR AXLE	8.24	520	17. 141	RING	.80
520	15. 155	SPROCKET 46 TEETH	30.98	520	17. 149	BEARING SLEEVE	7.36

PART NUMBER	DESCRIPTION	LIST	PART NUMBER	DESCRIPTION	LIST
520 17. 176	PROTECTING CAP R	2.42	520 20. 167	BUSHING 8.21D	.58
520 17. 177	PROTECTING CAP	2.08	520 20. 176	ZUNDAPP DECAL	.92
520 17. 618	FOOT BRAKE LEVER	18.26	520 20. 702	FUEL COCK	7.78
520 17. 619	BRAKE ROD	6.38	520 20. 713	TOOL KIT	23.76
520 17. 620	BRAKE CABLE	10.78	520 20. 716	FUEL TANK RED	153.56
520 17. 630	CLUTCH CABLE	10.56	520 20. 718	FUEL TANK RED	166.32
520 17. 631	STARTER CABLE	5.72	520 20. 720	FUEL TANK	122.60
520 17. 632	STARTER CABLE	6.26	520 21. 608	SEAT	86.08
520 17. 633	THROTTLE CABLE	5.72	520 21. 620	SIDE STAND	18.02
520 17. 706	BRAKE LEVER ASSY	17.36	520 21. 623	SEAT	86.08
520 17. 717	STARTER LEVER	12.60	520 22. 113	HEAT SHIELD	21.78
520 17. 718	THROTTLE GRIP ASY	27.66	520 22. 114	1.5X264 INS CORD	.52
520 17. 909	LEVER BRACKET	16.76	520 22. 117	USE 520 22.113 SHIEL	21.78
520 17. 910	BRAKE LEVER	13.66	520 22. 607	MUFFLER COMP	92.84
520 17. 911	CLUTCH LEVER	13.66	520 22. 710	MUFFLER COMP	104.28
520 17. 912	LEVER SCREW	.96	520 22. 714	MUFFLER CUMP	125.84
520 17. 913	LOCK NUT	.72	520 22. 900	MUFFLER CORE	25.60
520 17. 914	COVER	2.20	520 22. 904	MUFFLER CORE	15.32
520 17. 915	OVAL HEAD SCREW	.26	520 23. 700	TIRE LOCK	12.86
520 17. 916	ADJUSTED SCREW	5.62	520 23. 701	TIRE LOCK	12.86
520 17. 917	PROTECTING CAP	2.34	561 15. 111	USE 561 17.111 NUT	.46
520 17. 918	CABLE CONNECTUR	.84	561 15. 620	BRAKE CAM	5.12
520 17. 919	THROTTLE TUBE	10.98	561 17. 111	M8 RETAINING NUT	.46
520 17. 920	RUBBER GRIP	1.76	686 16. 129	SPACER	4.00
520 17. 921	THROTTLE HOUSING	19.78	SKA 206	CLUTCH GAGE	6.74
520 17. 922	SCREW WITH SPRING	3.08	SKA 235	HOUSING PULLER	14.48
520 17. 923	PROTECTING CAP	1.62	SKA 263	FLYWHEEL PULLER	2.57
520 17. 924	BRAKE BRACKET	11.52	SKA 268	PISTON PIN PULLER	7.14
520 18. 613	RUBBER MOUNT	8.36	SKA 279	USE SKA 297 STOPPER	9.61
520 18. 615	FRONT SUPPORT	9.68	SKA 297	SPROCKET STOPPER	9.61
520 18. 617	GUIDE BRACKET	2.18	SKA 300	CENTERING GAGE	1.64
520 18. 618	CHAIN 120 LINKS	22.76	SKA 301	ASSEMBLING SLEEVE	2.88
520 18. 702	ENGINE MOUNT REAR	14.62	SKA 326	STUDS FOR SKA235	1.83
520 19. 108	NO PLATE BRACKET	1.80			
520 19. 145	FRONT FENDER	23.30			
520 19. 154	MOUNTING BRACKET	12.42			
520 19. 608	BRACKET HOLDER	8.58			
520 19. 629	REAR FENDER	30.88			
520 19. 630	REAR FENDER	35.36			
520 19. 631	MUUNTING BRACKET	10.34			
520 20. 120	TOOL BOX	5.00			
520 20. 145	BUSHING	1.06			

# SPARK PLUGS

## NGK SPARK PLUGS

<u>NGK NUMBER</u>	<u>LIST</u>
B-4	\$1.30
B-6	1.30
B-6H	1.30
B-7S	1.30
B-7C	1.30
B-7HS	1.30
B-7HC	1.30
B-7HZ	1.30
B-8S	1.30
B-8HS	1.30
B-8N	2.00
B-8HN	2.50
B-9H	1.30
B-9HN	2.50
B-10H	1.30

## BOSCH SPARK PLUGS (ZUNDAPP)

W280 MI	3.00
---------	------

LITERATURE

OWNER'S MANUALS

<u>Model</u>	<u>Stock Number</u>	<u>Suggested List</u>
BS-HMS	SC1311	\$ .90
BS-90	SC1312	.90
BS-90T and 90M	SC1313	.90
BS-90 Sp	SC1314	.90
BS-50 Sp and 60 Sp	SC1315	.90
BS-175DT and 175 HS	SC1316	.90
BS-7S and 7D	SC1334	.90
BS-350 GTR	SC1510	1.20
Rockford Chibi	SC1598	.90
Rockford Chibi Deluxe	SC1628	.90
Rockford Tora and Town Deluxe	SC1625	.90
Rockford Taka	SC1632	.90
Zundapp	SC1636	1.00

SERVICE MANUALS

BS-7S and 7D	SC1306	1.20
BS-50 Sp, 60 Sp, 90 & 100 and 175 CC Models	SC1470	2.40
BS-350GTR	SC1508	2.40
Rockford Chibi and Tora	SC1633	1.80
Rockford Taka	SC1634	2.00
Zundapp	SC1637	2.00

ILLUSTRATED PARTS LISTS

BS-7S and 7D	SC1300	1.20
BS-HMS	SC1301	1.20
BS-90 and 100	SC1302	1.20
BS-50Sp and 60 Sp	SC1303	1.20
BS-175	SC1304	1.20
BS-350	SC1614	1.80
Rockford Chibi and Tora	SC1631	1.80
Rockford Taka	SC1641	2.00

ORDER FORMS

Dealer Barts Order Blanks	SC1358	N/C
Dealer Service Material Check List	SP1031	N/C
Dealer Warranty Forms	SC1359	N/C
Dealer Parts Price List	SP1064	N/C
Dealer Service Material Price List	SP1063	N/C

SPROCKETS AND PARTS		STOCK NO.	SUGG. LIST
Overlay Sprocket (72 Tooth)	7S, 7D, HMS	SC1253	17.94
Solid Sprocket for 90SP, 100SP, Taka	36 Tooth	7381-5000	8.92
	46 Tooth	7381-5020	8.92
	44 Tooth	7381-5030	8.92
	42 Tooth	7381-5040	8.92
	40 Tooth	7381-5050	8.92
	38 Tooth	7381-5060	8.92
Solid Sprocket--15 Tooth	175	2484-8010	5.42
Parts for Quick Change Sprockets (Standard Equipment)			
34 Tooth Road Sprocket	90T and 90M	7416-5010	5.80
47 Tooth	90T	7411-5010	35.00
64 Tooth	90M	7411-5020	41.80
Rear Sprocket 47T	Tora	343-34401-210	6.90
Rear Sprocket 49T	Tora	343-34401-220	6.90
Rear Sprocket 51T	Tora	343-34401-230	6.90

#### CHAIN EXTENSION AND SHOCK MODIFICATION KITS

72T Overlay Sprocket Extension	HMS	SC1254	\$ 1.80
47T Trail Sprocket Extension	BS 90T-BS 100TMX	7502-5010	1.80
64T Mountain Sprocket Extension	BS90M	7502-5020	1.80
Shock Modification Kit	50SP, 60SP, 90cc and 100SP Models	SC1290	1.86
Tora Hydraulic Shock		200-34402-911	-
Taka H. D. Shock		200-34501-911	-

#### BRIDGESTONE TOUCH-UP PAINT

Silver Grey Metallic (12 cans/case) (SC1387*)		SC1413	1.00
Red 60 Sport (12 cans/case) (SC1388*)		SC1414	1.00
Black (12 cans/case) (SC1389*)		SC1415	1.00
Candy Apple Blue (12 cans/case) (SC1391*)		SC1417	1.00
Aluminum Base Coat (12 cans/case) (SC1392*)		SC1418	1.00
Bare Metal Primer (12 cans/case) (SC1393*)		SC1419	1.00

\*Number to use when ordering per can

#### CUSTOM REPAIR PARTS & SERVICE

##### Stud Repair Kits

Cylinder Head Bolts for 90 Sport (Set of 4)		SC1450	2.40
Cylinder Crank Case Bolts for 175		SC1489	1.92 ea.
Cylinder Repair Kits (Include Rebored Cylinder Complete with Over-Size Pistons and Rings)			
50HM/S		SC1298	18.88
7 Standard and Deluxe		SC1466	16.88

<u>DESCRIPTION</u>	<u>MODEL</u>	<u>STOCK NO.</u>	<u>SUGG. LIST</u>
<u>ACCESSORIES</u>			
Helmet Reflector Kit Luminescent		SC1490	\$ 1.20
Seat Cover, for 90cc Silver-Blue		SC1369	8.00
Battery - 6 Volt, 2 Amp.	HMS-7S-50SP-60SP	8701-3040	6.76
Battery - 6 Volt, 3 Amp (EAE87110)	90cc, Tora Del., Taka	8701-5010	9.88
Battery - 12 Volt, 6 Amp	7D-175-350	8701-3002	16.62
Windshield 7/8" Bar	175	SC1295	12.00
Windshield 3/4" Bar	All Other	SC1252	10.00
Safety Bars	7S, 7D	SC1270	15.60
Safety Bars	HM/S	SC1271	15.60
Safety Bars-Deluxe	50, 60, 90 and 100cc Models	SC1424	21.60
Safety Bars-Standard	50, 60, 90 and 100cc Models	SC1425	15.60
Safety Bars	50SP and 60SP	SC1278	12.00
Saddle Bags-Red, Blue	All	SC1281	7.00
Luggage Carrier	All 90cc Oil Injection	6531-5021	11.96
Luggage Carrier	50SP-60SP-90T- 90STD	6531-3220	11.96
Luggage Carrier- Heavy Duty	90 and 100 Models	SC1449	20.40
Weather Cover, Leatherette, White	All	SC1346	5.00
Weather Cover, Plastic, Blue	All except 350GTR	SC1486	4.00
Mirror for 3/4" Bar	All except 175	4601-3101	3.72
Mirror for 7/8" Bar	175	4601-8000	3.88
Head Temperature Gauge	175	SC1459	20.00
Head Temperature Gauge	50SP, 60SP, 90 (all) 100SP	SC1465	20.00
Fiberglass Saddle Bags (Black or White)	All	SC1383	25.00
Mounting Kits for Fiberglass Saddle Bags			
	w/one raised muffler	SC1385	5.90
	w/two raised mufflers	SC1386	5.90
	350GTR	SC1505	5.90
Tora Speedometer	659-34404-900		24.95
Tachometer	Honda, H-D, BSA, etc. 2-cylinder, single point, 4-cycle	SC1463	\$25.00
Bunji Cords-Four-way Cord (Green Hooks)-Packed 10 per ctn.		SC1451	1.80 ea.
Bunji Cords-12" Cord (Yellow Hooks)-Packed 10 per ctn.		SC1452	.50 ea.
Bunji Cords-24" Cords (Blue Hooks)-Packed 10 per ctn.		SC1454	.84 ea.
Low Handle Bars 7/8" Dia.		SC1456	2.00
Spark Arrestor (See Service Letter #R-6) Tora, Taka		SC1640	15.90



